		WORK INSTRUCTION							Effectivity Date: September 8, 2023				
			Process Name/Title:	TAPING ASSEMBLY PROCESS					Validity Date: n/a				
	- 1		Model code/Part number:	700B /	7N0039-7020A	Customer: TRJ	Car Model:	TOYOTA-LAND CRUISER	Document No.:	WI-ENG-PDE-715A			
			Purpose:	☐ PROTOTYPE	: [PRE-LAUNCH	MASSP	PRO	Revision No.:	1	Page No.:	1 of 6	
PARTS:		1. Assy	parts; AVSSf 0.3 wires G I	L=643±3mm; Connector 6098-3810 (W); Black SV tube (Vinyl) ø5 L= 72±3mm; Black tape					JIG:	Insertion jig Locking jig			
NO	٥.	F	PROCESS NAME	WORK PROCEDURE/ ILLUSTRATION					TOOLS/PPE		QUALITY POINTERS		
1		P1	Table lay-out	Connector 6098-33 (W)/Connector tr Assy parts Insertion Jig B		Locking lie	0054-7075	Black SV tube (Vinyl) Ø5 L= 72±3mm	Safety Instruction Be sure to wear prescribed personal protective equipment during operation (gloves, finger cots, etc.) Housekeeping 1. Maintain and always practice 5's. 2. Personal things on the workplace is prohibited. Keep it in your locker. Alert level For any trouble, inform the Assembly Assistant Supervisor or Line Leader for immediate corrective action.	2. No exce	ent references: to WI-PNG-PDE-E ASSEMBLY PR to WI-PRO-CNC-P Length Toleran	OCESS 017 for Wire	
	Revision History									Reviewed by	Approved by	Noted by	
09/08/23 08/08/23	0	Change purpose from pre-launch to Masspro. Additional Table lay-out and update Quality Checkpoint M. Ariola J. Loterte C. Villanueva Initial Issue. M. Ariola J. Loterte C. Villanueva							rañes M. Arbola	J. Lowerte	b/out/ iffor C. Villanueva	A Arañes	
Eff. Date	Rev. No			Details of C	hange		Revised	Reviewed Approved N	oted Est. Date: Augu	st 08, 2023			











