
										Effectivity Date:		April 11, 2025		
NBC		7	Process Name/Title: TAPING ASSEMBLY PROCESS						Validity Date:			n/a		
		7	Model code/Part number:	310D / 7N0245-7020	Customer: TRJ	Car Model:	TOYO	TA-RAV4	Docur	ment No.:		WI-ENG-PDE-1230		
			Purpose:	☐ PROTOTYPE	☐ PRE-LAUNCH	■ MASSPF	RO		Revisi	ion No.:	1	Page No.:	1 of 4	
2. BI			SV tube (Vinyl) ø5 L=93±3m							JIG:	n/a			
NO.		P	ROCESS NAME	WORK PROCEDURE/ ILLUSTRATION						TOOLS/PPE	'	QUALITY POINTERS		
1		P1	Table Lay out	TABLE LAY-OUT Pre-assy parts Blue tape						afety Instruction Be sure to wear rescribed personal otective equipment during operation ploves, finger cots etc.) Housekeeping Maintain and alwa practice 5's. Personal things of the work place is obibited. Keep it in	Docum 1. Refer Strip Len 1. No miss 2. No exce	Document reference/s: 1. Refer to WI-PRO-CNC-017 for Wire and Strip Length Tolerance 1. No missing parts/tools 2. No excess parts/tools		
				3 4 5 6 7 8 9 10 1 2 3 4 5 6 7	8 9 (1) 1 2 3 4 5 6 7 8	9 th i 2 3 4 \$	67896	1012345	the S Le	Alert level any trouble, infort Assembly Assistates ader for immediate corrective action.	ant			
	Revision History									Prepared by	Checked by	Reviewed by	Approved by	
04/11/25		Change pr	re-launch to masspro						Arañes Arañes	Slexandra A.Byban	J.Lorerte	C.Villanueva	AAranes	
Eff. Date				Details of Change		Revised	Checked	Reviewed Ap	proved		March 17, 2025	J. Villariueva	, n. Maries	

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.



CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

			WORK IN	Effectivity Date:	April 11, 2025					
		Process Name/Title:		Validity Date:	n/a					
		Model code/Part number:	TAPING ASSEMBLY PROCESS 310D / 7N0245-7020 Customer: TRJ Car Model: TOYOTA-RAV4				Document No.:	WI-ENG-PDE-1230		
		Purpose:	☐ PROTOTYPE	PRE-LAUNCH	MASSPR	RO	Revision No.:	1	Page No.:	3 of 4
PARTS:	1.Assy Parts PROCESS NAME		WORK	JIG:	n/a QUALITY POINTERS					
4	P1	Measurement	② 40±4	(3) 194 ±4 Vinyl Tube (B) Ø5 (4) 20 +1	© 0 The state of	#10 0 White MEASURING TAPE 6 7 8 9 10 1 2 3 4 5 6 7 8 9 1	n/a	1. No wrong 2. No deform 1. No flip-c 2. No peel- 3. No loose 4. No miss 5. No wron 6. No wron 1. Please measurin measurer Docume	out tape -off tape e tape ing dimension ng use of tape nt reminders/n use calibrated/w g tape when get	olerance 0 - 1 mm note/s: erified ting the


CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

		WORK INSTRUCTION							Effectivity Date:	April 11, 2025		
		Process Name/Title:	TAPING ASSEMBLY PROCESS						Validity Date: n/a			
		Model code/Part number:	310D / 7N0245-7020	Custom	er: T	ΓRJ	Car Model:	TOYOTA-RAV4	Document No.:		WI-ENG-PDE-1	230
		Purpose:	☐ PROTOTYPE	☐ PRE-LAU	NCH		■ MASSPE	RO	Revision No.:	1	Page No.:	4 of 4
										1		
PARTS: 1. As		Parts							JIG:	n/a		

VISUAL INSPECTION/ QUALITY CHECKPOINTS

TAPING P-1

7N0245-7020



No Missing and No Wrong used of tape

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.