


,			WORK INSTRUCTION							Effectivity Date: March 12, 2025				
			Process Name/Title:	TAPING	Validity Date:		n/a							
			Model code/Part number:	559D / 7N0238-7020B	Car Model:	Car Model: TOYO1		Document No.:		WI-ENG-PDE-974C				
			Purpose:	PROTOTYPE	PRE-LAUNCH	■ MASSPI	RO		Revision No.:	0	Page No.:	1 of 7		
PARTS:		1. Assy	parts; Black SV tube (vinyl) ø	25 L= 490±3mm	JIG:	1. Tape ho	1. Tape holder							
N	0.	P	ROCESS NAME	WORK I	TOOLS/PP	E	QUALITY POINTERS							
1		TABLE LAY-OUT Black SV tube (vinyl) ø5 L= 490±3mm Black Tape w/ ho						e w/ holder	Safety Instruct Be sure to we prescribed perser protective equip during operatin (gloves, finger of etc.) Housekeepin 1. Maintain and a practice 5's. 2. Personal thing the workplace prohibited. Keep your locker. Alert level For any trouble, if the Assemby Ass Supervisor or L Leader for imme corrective actions	g ways s on is it in	1. No missing parts/tools 2. No excess parts/tools			
				Revision History					Prepared by	Checked by	Reviewed by	Approved by		
03/12/25	0	Initial issi	ue.			A.Hernandez	J.Loterte	C.Villanueva A	OKINCIN DE Arañes A.Hernandez		Lough form	Agrañas		
Eff. Date				Details of Change		Revised	Checked		proved Est. Date:	March 12, 2025	D. Villaride Va	/ A.Ridayo		




			WORK INS	Effectivity Date: March 12, 202						
		Process Name/Title:	TAPIN	Validity Date:		n/a				
		Model code/Part number:	559D / 7N0238-7020B	Customer: TRJ	Car Model: TOYOTA HI-ACE	Document No.:	WI-ENG-PDE-974C			
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	0	Page No.:	2 of 7	
PARTS:	Assy parts Black tape				JIG:	n/a				
NO.	PROCESS NAME		WORK I	PROCEDURE/ ILLUST	TOOLS/PPE	(QUALITY POINT	ERS		
2	P3	Spot Tape 1	1. Combine the assy parts then and then conduct measurement 20mm		2. Get the Black tape using right hand then conduct 2 windings of spot taping using both hands. R er taping, check the measurement aping condition.	6 7 8 9 1 2 3 4 5 6 7 8 9 1 1 2 3 4 5 6 7 8 9	1. No flip-o 2. No peel- 3. No loose 4. No missi 5. No wron	ut tape off tape e tape	rerified	
3		Spot Tape 2	1. Conduct measurement from wires to pointed tip 120±3mm using both hands. 100mm 100mm 20mm	terminal	2. Get the Black tape using right hand then conduct 2 windings of spot taping using both hands. The conduct 2 windings of spot taping using both hands.	6 7 8 9 10 1 2 3 4 5 6 7 8 9 1	1. No flip-o 2. No peel- 3. No loose 4. No missi 5. No wron	off tape e tape	/verified	










		WORK INSTRUCTION							Effectivity Date:	March 12, 2025		
		Process Name/Title:	TAPING ASSEMBLY PROCESS						Validity Date:	n/a		
		Model code/Part number:	559D / 7N0238-7020B	Cu	ustomer:	TRJ	Car Model:	TOYOTA HI-ACE	Document No.:		WI-ENG-PDE-97	74C
		Purpose:	PROTOTYPE	☐ PRI	RE-LAUNCH		MASSPE	RO	Revision No.:	0	Page No.:	7 of 7
PARTS:	n/a								JIG:	n/a		

VISUAL INSPECTION/ QUALITY CHECKPOINTS

TAPING - P3

7N0238-7020B



- 1 No Missing SV tube (vinyl)
- 2 No Wrong Facing of Y-Taping

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.