
TAPING ASSEMBLY PROC	ESS	V-E-E- D-1-	_			
	_00	Validity Date:	n/a	n/a		
0B / 7M0557-7021B Customer: TRJ	Car Model: TOYOTA RAV4	Document No.:	WI-ENG-PD	E-1133A		
ROTOTYPE PRE-LAUNCH	■ MASSPRO	Revision No.:	1 Page No.:	1 of 5		
PARTS: 1. Black Corrugated tube (No slit) ø5 L=149±3mm; Black Sunprene tube ø9 L=97±3mm; Assy parts		JIG: 1. Terminal cover jig				
WORK PROCEDURE/ ILLUSTRA	TION	TOOLS/PPE	QUALITY P	QUALITY POINTERS		
Black Corrugated ube ø5 L=149±3mm (no slit) Assy parts Terminal cover jig	Safety Instruction Be sure to wear required personal protective equipment during operation (gloves, finger cots, etc.) Housekeeping 1. Maintain and always practice 5's. 2. Personal things on the workplace is prohibited. Keep it in your locker. Alert level For any trouble, inform the Assembly Assistant Supervisor or Line Leader for immediate corrective action.	No missing parts/tools No excess parts/tools				
Revision History		Prepared by Re	eviewed by Approved by	Noted by		
ge pre-launch to mass pro			ALL CALLED)		
Initial issue.	A Hernandez	Villantieva A Arados	n/a			
Details of Change				11/0		
Buk	Revision History	Revision History Revision History Revision History A. Arañes A	Safety Instruction	## Black Surprene tube ## JIG: 1. Terminal cover jig WORK PROCEDURE/ ILLUSTRATION Tools/PPE QUALITY PC Safety Instruction Be sure to wear required personal protective equipment during operation (gloves, finger cots, etc.) Housekeeping 1. Maintain and always practice 5? 2. Personal things on the workplace is prohibited. Keep it in your locker. Assy parts Assy parts Revision History Prepared by Revision History Prepared by Revision History Approved by Appro		



	WORK INSTRUCTION					Effectivity Date:	October 22, 2024				
	Process Name/Title: TAPING ASSEMBLY PROCESS				Validity Date:						
		Model code/Part number:	310B / 7M0557-7021B Customer: TRJ Car Model: TOYOTA RAV4					WI-ENG-PDE-11	33A		
		Purpose:	☐ PROTOTYPE	PRE-LAUN	СН	MASSPF	RO	Revision No.:	1	Page No.:	2 of 5
PARTS:	1. Black Corrugated tube ø5 L=149±3mm (no slit) 2. Assy parts				JIG:	1. Terminal	1. Terminal cover jig				
NO.	F	PROCESS NAME	WORK	PROCEDUR	E/ ILLUSTR	ATION		TOOLS/PPE	QUALITY POINTERS		
2	P1	Wire insertion to Black Corrugated tube ø5 L=149±3mm (no slit)	1. Get the terminal cover jig using right hand then insert the G and B/W wires.	R	using right wires	Corrugated Ø5 hand and inse	R S L=203±3mm (no slit) rt the G and B/W	Terminal cover jig		g usage of parts rmed terminal	




	WORK INSTRUCTION Process Name/Title: TAPING ASSEMBLY PROCESS						Effectivity Date: Octobe			24	
		Process Name/Title:	Validity Date:	n/a							
		Model code/Part number:	odel code/Part number: 310B / 7M0557-7021B Customer: TRJ Car Model: TOYOTA RA		TOYOTA RAV4	Document No.:	WI-ENG-PDE-1133A				
		Purpose:	☐ PROTOTYPE	PRE-LAUNCH	■ MASSPR	0	Revision No.:	1	Page No.:	4 of 5	
PARTS:	1. Assy parts 2. Black VM tube (sunprene) ø9 L=97±3mm						JIG:				
NO.	PROCESS NAME WORK PROCEDURE/ ILLUSTRATION						TOOLS/PPE	QUALITY POINTERS			
4		Wire insertion to Black VM tube (sunprene) ø9 L=97±3mm	1. Get the Black VM tube (sunprene L=97±3mm using right hand then ins Green and Black/White wire using le	sert the	2. Insert the Sunprer (Tape width) using b	ne to COT 20mm	n/a		1. No wrong use of 2. No deformed ter		
5	P1	Taping 2 COT to VM tube (sunprene)	1. Hold the COT using left hand and measunprene tube up to terminal tip 39mm u hands. 20±3mm	asure the using both	2. Hold the COT using taping using both hand 3. After taping, check thaping condition.	s.	MEASURING TAPE 6 7 8 9 (0) 1 2 3 4 5 6 7 8 9 (6. No wron Importa	off tape e tape ing tape g dimension g use of tape ont reminders/Note e use calibrated/ve ng tape when gett	rified	

			Effectivity Date:	October 22, 2024					
		Process Name/Title:	TAPIN	Validity Date:	n/a				
NBC		Model code/Part number:	310B / 7M0557-7021B	Customer: TRJ	Car Model: TOYOTA RAV4	Document No.:		WI-ENG-PDE-11	33A
		Purpose:	☐ PROTOTYPE	☐ PRE-LAUNCH	MASSPRO	Revision No.:	1	Page No.:	5 of 5
						T	1		
PARTS:	n/a					JIG:	n/a		

VISUAL INSPECTION/ QUALITY CHECKPOINTS

TAPING - P1

7M0557-7021B



- 1 No Missing Tape
- 2 (taping on COT-wire and taping on Sunprene tube)

3 No Missing VM tube (Sunprene)

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.