			WORK INSTRUCTION Effectivity Date:										April 4, 2023			
			Process Name/Title: TAPING ASSEMBLY PROCESS Validity Date:									n/a				
			Model Code/Product Number:	895B	/	7N0092-7020	Customer:	TRJ			Docu	ment No.:		WI-ENG-PI	DE-500B	
			Purpose:	☐ F	PROTOTYP	PE	PRE-LAUNCH	MASS	PRO		Revis	sion No.:	7	Page No.:		1 of 4
PARTS:		Assy parts Black tape										JIG	n/a			
N	0.	P	ROCESS NAME	WORK PROCEDURE/ ILLUSTRATION						T	OOLS/PPE		QUALITY P	OINTER	RS	
1	ı	P2	Table Lay-out	maly		Assy parts	TABLE LAY-OUT	ae la	Tape hold tap	er/Black	ecop file alvanta alva	ety Instruction Be sure to wear Be scribed personal protective quipment during peration (gloves, inger cots, etc.) COUSE KEEPING Maintain and vays practice 5's. Personal things the workplace is ohibited. Keep it in your locker. Alert level for any trouble, form the Assembly sistant Supervisor I Line Leader for immediate prective action.		ng parts/ tools s parts/ tools		
		1				Revision History		1	1	<u> </u>		Prepared by	Reviewed	by Approv	ed by	Noted by
04/04/23								M. Ariola	J. Loterte	C. Villanueva	A.Arañes					
03/30/23	6		e process of Y-taping and transfer to P3 due to new process distribution. Change Table lay-out; Standarized tube tion; SV tube (Vinyl) M.					M. Ariola J. Loterte C. Villanueva		A.Arañes						
11/10/22		connector. M.Catapang J. Loterte C. Villanueva A.Arañes M. Arioka									J. Lovert) formal nueva .	A.A.Cardes		
Eff.Date	Rev.No				Details of C	Change		Revised	Reviewed	Approved	Noted	Est. Date:	May 23, 2022	2		

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

			WORK INS	Effectivity Date:	April 4, 2023					
		Process Name/Title:	TAPIN	IG ASSEMB	Validity Date:	n/a				
		Model Code/Product Number:	895B / 7N0092-7020 Customer: TRJ		omer: TRJ	Document No.:	WI-ENG-PDE-500B			
		Purpose:	PROTOTYPE	☐ PRE-L	LAUNCH MASSPRO	Revision No.:	7 Page No.: 2 of 4			
PARTS:	Assy parts Black tape				JIG	n/a				
NO.	F	PROCESS NAME	WORK	PROCEDURE	E/ ILLUSTRATION	TOOLS/PPE	QUALITY POINTERS			
2	P2	Taping 1 Black Corrugated tube to SV tube (Vinyl)	No gap between COT and Vinyl 1. Fix the COT and vinyl tube using both hands. L 25±3mm L 25±3mm 25±3mm	R	2. Fix the corrugated tube to SV tube (Vinyl) using left hand then get black tape and start taping using right hand. 3. Confirm measurement of 25±3mm from end of tape up to end of COT then continue the taping process using both hands. 4. Confirm measurement of 25±3mm from end of COT up to end of tape using both hands.	MEASURING TAPE 6 7 8 9 1 2 3 4 5 6 7 8 9 West Print, Street Mark Street, Str	1. No flip-out tape 2. No peel-off tape 3. No loose tape 4. No missing tape 5. No wrong dimension 6. No wrong use of tape Important reminders/Note/s: 1. Please use calibrated/verified measuring tape when getting the measurement.			

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

	_		W	Effectivity Date:		April 4, 2023							
		Process Name/Title:		TAPING ASS		Validity Date:		n/a					
		Model Code/Product Number:	895B / 7N0092-7020 Customer: TRJ				Document No.:		WI-ENG-PDE-500B				
		Purpose:	☐ PROTOTYPE		PRE-LAUNCH	MASSPRO	Revision No.:		7 P	Page No.:	3 of 4		
	,	<u> </u>					-			<u> </u>			
PARTS:	1. Assy 2. Black							JIG	n/a				
NO.	F	PROCESS NAME		TOOLS/F	PPE	QUALITY POINTERS							
3	P2	Taping 2 Black Corrugated to Wire near terminal	1. Hold the COT using left h tape using right hand then s using both hands.		3. Confirm mea of tape up to te taping process	m end of COT up to terminal pointed en continue the taping process using essurement of 35(+3/-1mm) from end erminal pointed tip then continue the using both hands.	MEASURING 6 7 8 9 10 1 2 3 4 4 1 1 2 3 1 4 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	5 6 7 8 9	1. No flip-c 2. No peel 3. No loos 4. No miss 5. No wron 6. No wron 1. Please	off tape e tape sing tape ng dimension ng use of tape unt reminders/ e use calibrated ng tape when g	Note/s: /verified		


CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

				Effectivity Date:	Effectivity Date:			April 4, 2023				
	P	Process Name/Title:	Validity Date:	Validity Date:			n/a					
	М	lodel Code/Product Number:	895B	/	7N0092-7020	Customer:	TRJ	Document No.:			WI-ENG-PI	DE-500B
	P	Purpose:	☐ PR	ROTOTYP	E	PRE-LAUNCH	MASSPRO	Revision No.:		7	Page No.:	4 of 4
PARTS:	n/a								JIG	n/a		

QUALITY CHECKPOINTS

P2

7N0092-7020



1 2 No Missing tape

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.