
_			WORK	Effectivity Date: June 24, 2024			14				
		Process Name/Title:	CL	Validity Date:	n/a						
		Model code/Part number:	920B / 7R0118-702	Customer: TRMX	Car Model:	TOYOTA TACOMA	Document No.:		WI-ENG-PDE-8	96	
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO)	Revision No.:	0	Page No.:	1 of 5	
PARTS:			W); Clamp 82711-3A640 (B); Black tape	0 (B); Black tape			JIG:		Clamp assembly jig		
N	0.	PROCESS NAME	WOF	RK PROCEDURE/ ILLUSTR	TOOLS/PPE		QUALITY POIN	TERS			
1	Clamp assembly jig Bando gun						Safety Instruction Be sure to wear prescribed personal protective equipment during operation (gloves, finger cots, etc.) Housekeeping 1. Maintain and always practice 5's. 2. Personal things on the workplace is prohibited. Keep it in your locker. Alert level For any trouble, inform the Assembly Assistant Supervisor or Line Leader for immediate corrective action. BANDO GUN	1. Refer to Taping as 1. No missi 2. No excers 600D	BAND CLAMP ILLUST NG 1-12A60 (W) 8	22711-52090 (W)	
			Revision History	oi y			Prepared by	Reviewed by	Approved by	Noted by	
06/24/24	0 Initia	ial issue.			D.Castillo C.V	/illanueva A. Arañes N	J/A D. Castillo	//out/):/for		N/A	
Eff. Date			Details of Change		-	 	D. Castillo 7	e 24, 2024	A. A NIARE S	N/A	



			Effectivity Date:	June 24, 2024					
		Process Name/Title:		ASSEMBLY PROC		Validity Date:		n/a	
		Model code/Part number:	920B / 7R0118-7023	Customer: TRMX	Car Model: TOYOTA TACOMA	Document No.:		WI-ENG-PDE-8	896
		Purpose:	☐ PROTOTYPE [PRE-LAUNCH	MASSPRO	Revision No.:	0	Page No.:	2 of 5
PARTS:	1. Clamp 82711-12A60 (W) [5pcs. 2. Clamp 82711-3A640 (B)		.]	3. Black tape		JIG:	Clamp assembly jig		
NO.	F	PROCESS NAME	WORK PROCEDURE/ ILLUSTRATION			TOOLS/PPE	(QUALITY POIN	ITERS
2	Clamp		1. Get 2pcs. of clamp 82711-12A60 (W) to clamp location 1 and 2 then lock using hands. Press	2 3 W) then set and both 2. Get 2pcs then lock using I	82711-3A64 6 82711-3A64 6 cs. of clamp 82711-12A60 (W) then set to both hands. c. of clamp 82711-12A60 (W) then set to both hands.	to clamp location 3 and 4 o clamp location 5 then o clamp location 6 using	Importal 1. Please start of assclamp. 1. No loose 2. No dama 3. No missi	ANDARD TAPII CLAMP One wind for under Int reminders/N Check the Clamp I Seembly to avoid w e attachment of cla laged clamp sing parts CLAMP ILLUSTRATION NG BAND CLAMP ILLUSTRATION NG BAND CLAMP ILLUSTRATION NG READ NG	Note/s: first before wrong use of lamp


			Effectivity Date: June 24, 20			:4					
		Process Name/Title:	Validity Date:	n/a							
		Model code/Part number:	920B / 7R011	8-7023	Customer: TRMX	Car Model: TOYOTA TACOMA	Document No.:		WI-ENG-PDE-	396	
		Purpose:	PROTOTYPE		PRE-LAUNCH	MASSPRO	Revision No.:	0	Page No.:	3 of 5	
PARTS: 1. As		Assy parts					JIG:	Clamp assembly jig			
NO.	F	PROCESS NAME	WORK PROCEDURE/ ILLUSTRATION			TOOLS/PPE	(QUALITY POINTERS			
3	Clamp Assy	Clamp assembly	Checker 1 1. Get the assy parts and sepicture for correct setting to Checker 1 then pull the connector 6189-1161 (Brixture for continuity checkin Color sensor light will beet Last, set the end of PCB wit clamp. Continue if the clamp. 2. Initially tighten the band cusing both hands. 3. Get the Bando gun using location 1, 2, 3, 4 and 5 usin cut the tape using both hands. 4. Hold the tape on clamp locut the tape using both hands. 5. After taping, CONDUCT POINT CHECKING before removing the harness from jig.	et to jig usin). First, set checker fixte) to Check gright hand go location 1 clamp on cla cl	the connector 6189-1142 (ure for continuity checking. er 2 then push the checker e to set the harness in jig. nsor detects Green tape. oper jig then press the togg was ON. amp location 1, 2, 3, 4 and then cut the clamp on ids.	Set Set GOOD BAND CLAMP CUT POSITION FOR LOCATION 5 Then 1 then 1 by 1 from cuter depends on the size the COT // inv/ tube	PERPENDICULARITY NG OK NG Fixed setting of	1. Make sand PCB 2. Make 2 GOOD STILL GOOD	BANDO GUN ILLUSTRA	Note/s: een stopper amp taping stration	



			Effectivity Date:	June 24, 2024					
		Process Name/Title:	CLAN	Validity Date:		n/a			
		Model code/Part number:	920B / 7R0118-7023	Customer: TRMX	Car Model: TOYOTA TACOMA	Document No.:		WI-ENG-PDE-	896
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	0	Page No.:	5 of 5
PARTS:	PARTS: 1. Assy parts						n/a		
VISUAL INSPECTION/ QUALITY CHECKPOINTS									

CLAMP ASSY

7R0118-7023



1 No Wrong facing of clamp

2 3 4 No Missing Tape (Black tape)

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.