
				WORK INSTRUCTION	Effectivity Date:	February 6, 2024					
			Process Name/Title:	TAPING ASSEMBLY PROCE	Validity Date: n/a						
			Model code/Part number:	930B / 7N0204-7020A Customer: TRJ	Car Model: TOYOTA-4 RUNNER	Document No.:		WI-ENG-PDE-79	2B		
			Purpose:	PROTOTYPE PRE-LAUNCH	MASSPRO	Revision No.:	0	Page No.:	1 of 4		
PARTS:		1. All pa	arts: Assy parts; Black tape	e	JIG:	n/a					
NC	Э.	F	ROCESS NAME	WORK PROCEDURE/ ILLUSTRA	RATION TOOLS/PPE			QUALITY POINTERS			
1		Table Lay-out Continue Conti									
	1			Revision History		Prepared by Re	eviewed by	Approved by	Noted by		
							/ L · /L				
00/00/04		Initial ia-			D Contillo C Villanusia A Arañas	gentulo //o	The Marin	- Marie I			
02/06/24 Eff. Date I	-	Initial iss	ue	Details of Change			Villanueva ary 6, 2024	A Aranjes	n/a		

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.





CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.



	<u> </u>			WORK INSTRUCT	Effectivity Date: February 6, 2024			24		
		Process Name/Title:	Validity Date:		n/a					
		Model code/Part number:	TAPING ASSEMBLY PROCESS 930B / 7N0204-7020A Customer: TRJ Car Model: TOYOTA-4 RUNNE				R Document No.: WI-ENG-		WI-ENG-PDE-79	2B
		Purpose:	PROTOTYPE	☐ PRE	E-LAUNCH	MASSPRO	Revision No.:	0	Page No.:	3 of 4
PARTS:				JIG:	n/a					
NO.	F	PROCESS NAME		TOOLS/PPE	QUALITY POINTERS					
3	Note: Do not exert excessive force durin pulling & winding of tape 1			2. Start taping Corrugated to 2 corrugated to 2 corrugated to 2 corrugated to 2 corrugated Taping Corrugated 5. Winding the other side of control of the con	rrugated tube . g at the middle of combined ubes, then winding the tape going to tubes, width must be Tape width. e tape 1/3 shifting until it reach the corrugated tube, width must be e shifting 9mm below ± 3mm 25 ± 3mm 1/2 shifting going to other side of an cut the tape. After taping, check	MEASURING TAPE	Important reminders/Note/s: 1. Use YELLOW TAPE for easy visualization of shifting lines, but actual should be BLACK TAPE. 2. Please use calibrated/verified measuring tape when getting the measurement. Document references: 1. Refer to WI-PRO-ASY-001 for Taping process 1. No flip-out tape 2. No peel-off tape 3. No loose tape 4. No missing tape 5. No wrong dimension 6. No wrong use of tape			

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.


NBC (Philippines)
MASTER COPY

			WORK INSTRU	Effectivity Date:	February 6, 2024						
		Process Name/Title:			TAPING A	SSEMBLY	Validity Date:	n/a			
		Model code/Part number:	Part number: 930B / 7N0204-7020A Customer: TRJ Car Model: TOYOTA-4 RUNNER Document No.:		Document No.:	WI-ENG-PDE-792B					
		Purpose:	□Р	ROTOTYPE		PRE-LAUNCH	MASSPRO	Revision No.:	0	Page No.:	4 of 4
PARTS:	1 Assv	/ parts						.IIG·	n/a		

QUALITY CHECKPOINTS

P2

7N0204-7020A



1

No Missing tape

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines)
MASTER COPY