Process Name/ Title: WI-QAD-QAC-264 Document No: **PACKING INSTRUCTION** WORK INSTRUCTION Effective Date: June 27, 2024 Product Code/Name: Customer Code/ Customer Rev. No.: Page No.: Page 1 of 1 7R0125 **TRMX** Records/Remarks/ Work Procedure/ Illustration No. **Quality Pointers** (1) 50pcs\*8 Qty/box 400 bdls Mat'l Dim. Qty. Put Vinyl Sheet name (1250 x 1250) TRMX inside TRMX box. 544\*370\* 1 228mm box Vinyl 1250\* 1 sheet 1250 2 343\* Plastic vinyl bag of **Partition** 50pcs × 4bdls 1 CSW assy board 510 Vinyl 420\* 8 Put the products inside 280 bag the box (opposite direction per bundle) Note: (50pcs\* 4 bundles) Step 5 is applicable only in QC FG inspection. For CSW process, use Oricon box 1st LAYER instead of TRMX box. 3 Layout partition board 4 Put another bundles inside the box (opposite direction per bundle) (50pcs\* 4 bundles) 2ND LAYER (5) Fold the vinyl sheet. Put NBP Identification tag at the top and tape the flaps (two side and top portion). Then Warehouse Identification tag at Note : If need to attach 4M tag
Put 4M tag at the left side of the box right side of the box.

							Prepared by	Checked by	Apprøvjed by	Noted by
								1. /	( / .	
06/27/24	1	Change vinyl sheet size to 1250 x 1250. Transferred from WI-ENG-PDE-571	S. Malabuyoc	R. Pascua	O. Merin	-	madern	ML	16	
07/29/22	0	Initial Issue	M. Ariola	J. Loterte	C. Villanueva	A. Arañes	(S) Malabuyoc	R Plasoua	O. Merin	-
Eff. Date	Rev. No.	Details of change	Prepared	Checked	Approved	Noted	Establish Date:	July 29, 2022		