
	WORK INSTRUCTION Process Name/Title: TAPING ASSEMBLY PROCESS								May 05, 2025		
			Process Name/Title:		Validity Date:		n/a				
			Model code/Part number:	559D / 7N0242-7020B	Customer: TRJ	Car Model: TOYOTA HI-AC	Document No.:		WI-ENG-PDE-12	50B	
			Purpose:	☐ PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	1	Page No.:	1 of 6	
PART	S:	1. A: 2. C	ssy parts amp 82711-1E360 (W)	1	JIG:	n/a	n/a				
	NO.	PROCESS NAME WORK PROCEDURE/ ILLUSTRATION			ATION	TOOLS/PPE	- (QUALITY POIN	TERS		
				Clamp 82711- 1E360 (W) Tray	TABLE LAY-OUT	Safety Instruction Be sure to wear required personal protective equipme during operation (gloves, finger cots etc.) Housekeeping 1. Maintain and alway practice 5's.	ent S,				
	1	P.	? Table lay-out	Assy parts		L=534±2mm	Personal things of the workplace is prohibited. Keep it if your locker. Alert level For any trouble, inform the Assembly Assists Supervisor or Line Leader for immediate corrective action.	1. No missi 2. No exces	No missing parts/tools No excess parts/tools		
				Revision History	White tape/ T	rape holder	Prepared by	Checked by	Reviewed by	Approved by	
05/05/2		L=53	ge from pre-launch to masspro. Alig 4±2mm. Update Measurement work	A. Arañas A. Arañas A. Arañas	Show	South House					
04/16/2		Unitial issue. D. Castillo J. Loterte a A. Alaries D. Castillo J.							C. Villanueva	A. Arañes	
Eff. Da	te Rev. N	No		Details of Change		Revised Checked Reviewed	Approved Est. Date:	April 16, 2025			



			WORK INS TAPIN	Effectivity Date:	May 05, 2025						
		Process Name/Title:		Validity Date:	n/a						
		Model code/Part number:	559D / 7N0242-7020B	Customer: TF	RJ Car Model:	TOYOTA HI-ACE	Document No.:	WI-ENG-PDE-1250B			
		Purpose:	☐ PROTOTYPE	PRE-LAUNCH	■ MASSPE	RO	Revision No.:	1	Page No.:	2 of 6	
PARTS:	1. Clam 2. Assy	p 82711-1E360 (W) parts					JIG:	n/a			
NO.	PROCESS NAME WORK PROCEDURE/ ILLUSTRATION						TOOLS/PPE	QUALITY POINTERS			
2	P2	Clip attachment (Clip type clamp)	1. Hold the Connector using left hand, using right hand. Note: Follow the illustration. Sound			R R	n/a	2. No dama 3. No missi	g used of clamp aged clamp aged clamp aged clamp aged clamp. CLIP CLAMP ILLUST 82711-16	E360 (W)	

NBC (Philippines)


MASTER COPY



NBC (Philippines)
MASTER COPY

			WORK I	Effectivity Date:	May 05, 2025					
		Process Name/Title:		Validity Date: n/a						
		Model code/Part number:	559D / 7N0242-7020E	TOYOTA HI-ACE	Document No.:	WI-ENG-PDE-1250B				
		Purpose:	☐ PROTOTYPE	☐ PRE-LAUNCH	MASSPI	RO	Revision No.:	1	Page No.:	4 of 6
PARTS:	1. Assy 2. Whit			JIG:	n/a					
NO.		PROCESS NAME	TOOLS/PPE	(QUALITY POINT	TERS				
4	P2	Taping 2 Black corrugated tube to Black SV tube (Vinyl)	4~6mm	3. Hold measure 25±3mr hands.	2. Get the White tal then start taping prohands. the assy part using leef rom end of tape up. Then continue taping.	eft hand and to to end of COT ing using both	MEASURING TAPE	Impor 1. Ple meas meas. Docui 1. Ref taping 1. No flip- 2.No peel- 3. No loos 4. No wror 5. No wror 6. No miss	rtant reminders and ase use calibrated uring tape when gurement. ment reference/s: Fer to WI-PRO-AS's procedure. Dut tape off tape e tape and dimension and use of tape sing tape Vire alignment toler.	nd Note/s: d/verified letting the

MASTER COPY






	C	WORK INSTRUCTION						Effectivity Date:	May 05, 2025		
		Process Name/Title:	TAPING ASSEMBLY PROCESS					Validity Date:	n/a		
		Model code/Part number:	559D / 7N0242-7020B	Customer:	TRJ	Car Model:	TOYOTA HI-ACE	Document No.:		WI-ENG-PDE-12	50B
		Purpose:	☐ PROTOTYPE	☐ PRE-LAUNCH		MASSPE	RO	Revision No.:	1	Page No.:	6 of 6
PARTS:	1. Assy	parts						JIG:	n/a		

VISUAL INSPECTION/ QUALITY CHECKPOINTS

TAPING - P2

7N0242-7020B



- 1 No Missing Clip Clamp
- 2 No Missing tape

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines)
MASTER COPY