

Process Name/ Title:	
PACKING INSTRUCTION	V

7R0101

WORK INSTRUCTION
Product Code/Name: Cu

Customer Code:

TRMX

Rev. No.:

Document No:

Effective Date:

WI-QAD-QAC-155

Page No.:

July 2, 2024

Page 1 of 1

	7110	7101	IIVIV							
No.		Work Procedure/ Illustration					Records/Remarks/ Quality Pointers			
							Qty/box	600pcs.	50pcs* 12bdls	
	2				Mat'l name	Dim.	Qty.			
1	Put Vinyl Sheet (1250 x 1250)				TRMX box	544*370* 228mm	1			
	inside TRMX box.			Vinyl sheet	1250*1250	1				
							Partition board	343*510	1	
				A			Plastic Vinyl bag	420*280	12	
2	Put 6bdls of products. (50pcs/bdl)						of DC box.	SW use Oricon number 5 is app spection.		
3	Put partition board									
4	Put another 6bdls of products. (50pcs/bdl)									
(5)	Fold the vinyl sheet. Put NBP Identification tag at the top and tape the flaps (two side and top portion). Then Warehouse Identification tag at lower right side of the box.									
			The second secon		e : If need to attach Put 4M tag at the le	ft side	Prepared	Checked	Approved	
07/02/2024 08/16/2021	Change dimension of	t size from 1520 x1500mm to 1250 the box from 610*381*178mm to 54		S. Malabuyoc C.Dimailig	R. Pascua M.Lumbres	O . Merin E Mendoza	Cmaldern	I M-/	(les	
02/15/2021 Eff./Rev. Date	Rev. No.	Initial Issue Details of change		C. Dimailig Revise	M.Lumbres Check	E. Mendoza Approve	S. Malabuyoe Est. date:	R. Pascua February 15, 2021	O Merin	