

Process Name/ Title	:
---------------------	---

## PACKING INSTRUCTION WORK INSTRUCTION

Document No:

WI-QAD-QAC-194

April 19, 2022

Product Code/Name: 7H0389W7020A

Customer Code: NBS

Effective Date:

1

Page No.:

Page 1 of 1

	T	/HU389W/U2UA					D.	ecords/Remarl	rel	
No.		Work Procedure/ Illustration			(	Quality Pointers				
1	Put Vinyl Sheet (1520 x 1500) inside the box.						Qty/ Box Mat'l name	80 pcs	10pcs* 8bdls	
						Master	Dim. 535*360*	Qty 1		
							box Vinyl	150 mm 1520*1500	1	
							Sheet Partition	343*510	1	
							Board Plastic Vinyl Bag	300*200mm	8	
2		dls of products. (10pcs/bdl) n opposite direction.					Note: 1. For CSW use Oricon box instead of DC box. 2. Step number 5 is applicable only in QC FG Inspection.			
3		Put partition board		K						
4		dls of products. (10 pcs/bdl) n opposite direction.		Mail 7H038	INNER TA	ıG	Make sure that the inner tag indicates the correct terminal expiration date.			
(5)		Fold the vinyl sheet.								
6		o NBP Identification tag S Tag at the left side of the box								
	Attach N	NBS Identification tag at the	7H0389W7020A	Note:			Outgoing Inspectors are the person-in- charge in the attachment of NBP tag (warehouse tag) and NBS tag (outer tag) to its proper location.			
7	left s	side of the box and NBP se tag in the right side of the box.	80 Margarith 2022 E 202	If need to a			to its proper le	ocation.	g (outer tag)	
7	left s	se tag in the right side of the	80 Avenue 80 Ave	If need to a						
04/19/2022	left s	se tag in the right side of the box.	le to left side to consider warehouse special tags location	If need to a Put 4M tag		side	to its proper le	Check	g (outer tag)	

CONFIDENTIAL: ©2017 NBC; all rights reserved. Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines)

MASTER COPY