

			WORK INSTRUCTION								ctivity Date:		September 12, 2024		
			Process Name/Title: TAPING ASSEMBLY PROCESS								lity Date:		n/a		
			Model code/Part number: 320B / 7L0053-7025A Customer: TRQSS Car Model: TOYOTA-RAV						TA-RAV4	Docu	ment No.:		WI-ENG-PDE-1035C		
			Purpose:	PROTOTYPE	PRE-LAUNCH	1	MASSF	rRO		Revi	sion No.:	1	Page No.:	1 of 5	
PARTS:			y parts; Black tape; Yellow tape							JIG:	n/a				
NC).	PROCESS NAME WORK PROCEDURE/ ILLUSTRA					ATION		TOOLS/PPE				QUALITY POIN	TERS	
		Р3	Table Lay-out	Assv	TABLE LA	Y-OUT		9		bi t	afety Instruction Be sure to wear orescribed person to tective equipment during operation gloves, finger contect.)	al ent			
1									2	Housekeeping 1. Maintain and always practice 5's. 2. Personal things on the workplace is prohibited. Keep it in your locker.		No missing parts/tools No excess parts/tools			
				2711 571 1/3 171 15 171 1/3 171 17 19 19 17 17 17 17 17 17 17 17 17 17 17 17 17	- 1	r -	Yellow tape/ Tape Holder		1012245	the	Alert level or any trouble, infe e Assembly Assis Supervisor or Lin eader for immedia corrective action	ant e ate			
	Revision History							Prepared by	Reviewed by	Approved by	Noted by				
										1					
09/12/24	1 Change from Pre-launch to Masspro.				D. Castillo	C. Villanueva	A. Arañes	n/a		1/	Alax				
09/11/24	Villanueva					A. Arañes	n/a	n/a gentulo D. Castillo C.		Villanueva A. Arañes					
Eff. Date Rev. No Details of Change Revised Reviewed Approved Noted Est. Date: September 1							September 11, 202	4							



			WORK INST	Effectivity Date:	September 12, 2024			
		Process Name/Title:	TAPING		Validity Date:	n/a		
		Model code/Part number:	320B / 7L0053-7025A	Customer: TRQ	SS Car Model: TO	YOTA-RAV4	Document No.:	WI-ENG-PDE-1035C
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO		Revision No.:	1 Page No.: 3 of 5
PARTS:	Assy parts Yellow tape				JIG:	n/a		
NO.	F	PROCESS NAME	WORK PI	ROCEDURE/ ILLUS	TOOLS/PPE	QUALITY POINTERS		
2		Y-taping (Continuation)	6. conduct proper pressing of end tape using left hand (top part)	7. conduct proper using left hand (r pressing of end tape fliddle part)		oper pressing of end tape d (bottom part)	20±3mm 20±3mm 9. Check the Measurment and condition of tape.
3	P3	Taping 3 Black Corrugated tube to VM tube (Sunprene)	1. Hold the COT using left hand and f sunprene tube using right hand. Note: Must be no gap between tube 20±3mm 20±3rm	ix the ess 2. Gr pr	Hold the assy parts using the Yellow tape and access using both hands. After taping, check the disping condition.	ing left hand. start taping s.		1. No flip-out tape 2. No peel-off tape 3. No loose tape 4. No missing tape 5. No wrong dimension 6. No wrong use of tape Important reminder/Note/s: 1. Please use calibrated/verified measuring tape when getting the measurement. Document references: 1. Please refer to WI-PRO-ASY-001 for taping procedure.




		WORK INSTRUCTION						Effectivity Date:	September 12, 2024			
		Process Name/Title:	TAPIN	Validity Date:	n/a							
		Model code/Part number:	320B / 7L0053-7025A	Customer:	TRQSS	Car Model:	TOYOTA-RAV4	Document No.:		WI-ENG-PDE-10	35C	
		Purpose:	PROTOTYPE	PRE-LAUNC	Н	MASSPRO		Revision No.:	1	Page No.:	5 of 5	
PARTS:	1. Assy	. Assy parts						JIG:	n/a			

VISUAL INSPECTION/ QUALITY CHECKPOINTS

TAPING - P3

7L0053-7025A



- No Missing Tape
 No wrong use of
 tape (Black tape)
- No Missing Tape
 No wrong use
 tape (Yellow)

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.