

No.

| Process Name/ Title: | | |
|----------------------|------|----------|
| Sunprene | Tube | Checking |

Document No:

WI-PRO-COM-002

WORK INSTRUCTION

Effective Date:

February 01, 2019

Product Code/Name: ALL Customer Code:

Work Procedure/ Illustration

Rev. No.:

0

Page No.:


Page 1 of 1


Records/Remarks/

Quality Pointers

Foreign Material checking inside Sunprene Tube

Start in between corrugated and sunprene tube






carefully press and rub sunprene tube to feel if there is any inserted FM inside

Legend Sunprene tube


Corrugated tube



You will notice if there is any Foreign Material inserted inside the sunprene tube by pressing and gently rubbing it manually.

Once FM was detected during inspection immediately report it to the assigned leader.

Sample NG



Foreign Material - Spring, Stator, Slider, Slider Magnet

| | | | | | | Prepare | Check | Approve |
|----------------|----------|-------------------|--------|-------|---------|------------|------------|---------|
| | | | | | 9.99 | / | AI | < |
| | | | | | | GALD | Jennik | 169 |
| | | | | | | L. Alarzar | M. Demiden | Merin |
| Eff./Rev. Date | Rev. No. | Details of change | Revise | Check | Approve | Est. date: | 08/01/2017 | |