Process Name/ Title: WI-QAD-QAC-219 Document No: PACKING INSTRUCTION WORK INSTRUCTION Effective Date: September 23, 2023 Product Code/Name: Customer Code/ Customer: Rev. No.: 2 Page No.: 1 of 1 7N0120 TRJ Records/Remarks/ Work Procedure/ Illustration No. **Quality Pointers** Spread Vinyl sheet inside 9 pcs. x Qty/box 72 folding box. 8 bdls Mat'l name Dim. Qty. (1) 386*55*2 Oricon box 1 43 1520* Vinyl sheet 1 1500 Put the products inside the **Partition** 343* Plastic vinyl bag of CSW assy 9pcs × 2bdls 3 board 510 (9pcs* 2 bundles) 300* 2 Vinyl bag 8 200 NOTE: Step 6 is applicable only to QC FG inspection. Layout partition board Put the products (9pcs* 2 bundles) on the 2nd layer (3) Layout partition board Put the products (9pcs* 2 bundles) on the 3rd layer (4) Layout partition board Put the products (9pcs* 2 bundles) on the 4th layer (5) Fold the vinyl sheet. (6) Put NBP Identification tag at the top.Then warehouse Identification tag at lower right side of the box. 7 NBC ↔ N1 NOTE: If need to attach 4M tag Put 4M tag at the left side of the box 09/23/2023 Change position of product in procedure No. 4 A. De Chavez R. Pascua O. Merin Include step 5; Change quantity from 54 pcs. to 72 pcs; Change control no. from WI-ENG-PDE 312 to WI-QAD-QAC-219 08/02/2023 A. De Chave D. Dadulla O. Merir 07/19/2021 0 Initial issuance J. Loterte C. Villanuev A. Shimamura A. Arañes

CONFIDENTIAL: ©2017 NBC; all rights reserved. Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited. NBC (Philippines)

MASTER COPY