

No. Work Procedure/ Illustration Qty/ Mat'l in the "after inspection area" TRJ Rev. No.: 2 Particular to Parti	/box name ition ard	Dim. 343* 510	
Prepare empty oricon box in the	/box name ition ard	400 Dim. 343* 510	100pcs ³ 4 bdls Qty.
Get the vinyl (plastic) bag then put the 100 pcs harness. Insert products in same direction. Put the ID tag inside then fold the plastic bag.			
Put products on standing position and partition board vertically & alternately with the products. (100pcs* 4 Bundles with I.D tag inside)			
Put NBP Identification tag at the top. Then warehouse Identification tag at lower right side of the box. Note: If need to attach 4M tag Put 4M tag at the left side of the box			
/28/2024 2 Remove Vinyl Sheet M. Garcia D.Dadulla R.Pascua Fig. 2023 - Change document control number from WI-ENG-PDE-380 to WI-QAD-QAC-214 - Change document control number from WI-ENG-PDE-380 to WI-QAD-QAC-214	pared	Checked	Approved

CONFIDENTIAL: ©2017 NBC; all rights reserved. Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

12/14/21

NBC (Philippines)
MASTER COPY

Initial Issuance

Details of change

M. Ariola/ J.Loterte

Prepared

C.Villanueva

A. Arañes