

PACKING	INSTRUCTION

Work Procedure/ Illustration

Document No:

WI-QAD-QAC-242

July 5, 2024

Records/Remarks/

WORK INSTRUCTION Product Code/Name:

7L0106

Customer Code: **TRQSS**

Effective Date:

Rev. No.:

Page No.:

Page 1 of 1

No. 1 Put Vinyl (1)Sheet (1250 x 1250)



	Quality Pointers						
	Qty/box	240	60pcs *4bdls				
1	Mat'l name	Dim.	Qty.				
	DC carton	1131*781	1				
	Vinyl sheet	1250*1250	1				
	Vinyl bag	420*280	4				

Put 2 bundles of (2) products in opposite direction. (60pcs/bundle)

inside carton box.



Note: $\sqrt{1}$ Step number 5 is applicable only in QC FG Inspection.

Put another 2 bundles (3) of products in opposite direction. (60pcs/bundle)

Total of 4 bundles/box



Fold the vinyl sheet.





Close the flaps and put (5) ID tag (Inner tag at the top of the plastic and Outer tag at the right side of the front of the box).





Note: If need to attach 4M tag Put 4M tag at the left side

						Prepare	Check	Approve
07/05/2024	1	Change document control no. from WI-ENG-PDE-230 to WI-QAD-QAC-242; Change Vinyl Sheet Size from 1520x1500 to 1250x1250; Change picture of no. 1; Modify no. 4 and Addition of no. 5; Modify note.	J. De La Cruz	D.Dadulla	R.Pascua	A May		/ L, /
02/01/2021	0	Initial issue.	R. Peñaloza	A. Shimamura	A. Arañes	J. De La Cruz	D.Dadulla	R.Pascua
Eff./Rev. Date	Rev. no.	Details of change	Prepared	Checked	Approved	Established. date	ablished. date: February 1, 2021	

CONFIDENTIAL: ©2017 NBC; all rights reserved. Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines) **MASTER COPY**