

Process Name/ Title:

PACKING INSTRUCTION

Document No:

WI-ENG-PDE-485

April 20, 2022

WORK INSTRUCTION
Product Code/Name: Cus
7H0335W7020D

Customer Code: NBS Effective Date: Rev. No.:

Page No.:

0

Page 1 of 1

		7H0335W7020D	NBS				. ago . to	. ~9	
No.			Work Procedure/ Illustration		Records/Remarks/ Quality Pointers				
						Qty/ Box	160 pcs	10pcs* 16bdls	
1)		Put Vinyl Sheet (1520 x 1500) inside the box.		A			Mat'l name Master	Dim. 535*360*	Qty
							box Vinyl	150 mm	_
						Sheet	1520*1500	1	
				1			Partition Board	343*510	1
				- 27			Plastic Vinyl Bag	300*200mm	16
2	Put 8 bc	dls of products. (10pcs/bdl) n opposite direction.					Note: 1. For CSW use Oricon box instead of DC box. 2. Step number 7 is applicable only in QC FG Inspection.		
3		Put partition board							
4		lls of products. (10 pcs/bdl) n opposite direction.	(10 pcs/bdl)				Make sure that the inner tag indicates the correct terminal expiration date.		
(5)	Fold the vinyl sheet.								
6		NBP Identification tag S Tag at the left side of the box							
Ī	left s	NBS Identification tag at the ide of the box and NBP se tag in the right side of the box.	160 Magas 15 Note:			Outgoing Inspectors are the person-in- charge in the attachment of NBP tag (warehouse tag) and NBS tag (outer tag) to its proper location.			
							Prepare	Check	Approve
04/20/2022	0		Initial Issue	J. Loterte	C, Villanueva	A. Arañes	J. Loterte	C. Villanueva	A. Aranes
Eff./Rev. Date	Rev. No.		Details of change	Revise	Check	Approve	Est. date	April 20	

CONFIDENTIAL: ©2017 NBC; all rights reserved. Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines)
MASTER COPY