					STRUCTION			Effectivity Date:		September 10, 20)24		
			Process Name/Title:		IG ASSEMBLY PROC			Validity Date:		n/a			
		7	Model code/Part number:	920B / 7R0118-7025	Customer: TRMX	Car Model: TC	OYOTA TACOMA	Document No.:		WI-ENG-PDE-996	6B		
			Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO		Revision No.:	1	Page No.:	1 of 6		
PARTS:	1	1. Ass	/ parts; Black tape [1pc.]; G	reen tape [1pc.]		1. Insertion Jig JIG: 2. Measuring Jig 3. Locking Jig							
N	0.	ı	PROCESS NAME WORK PROCEDURE/ ILLUSTRATION						(QUALITY POINTERS			
NO.		P2	Tat:	Table Lay-out Insertion jig Black tape/ Tape				Safety Instruction Be sure to wear prescribed personal protective equipment during operation (gloves, finger cots, etc.) Housekeeping 1. Maintain and alway practice 5's. 2. Personal things on the workplace is prohibited. Keep it in your locker. Alert level For any trouble, inform	s 1. No miss 2. No exce	1. No missing parts/tools 2. No excess parts/tools			
			1 1 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2	Green tape/ Tape holder 7R018-7020B Locking jig Measuring jig			the Assembly Assistar Supervisor or Line Leader for immediate corrective action.	nt					
			-	Revision History		1 1		Prepared by	Reviewed by	Approved by	Noted by		
09/10/24	1 0	Change Initial iss		date Visual inspection/Quality checkpoints.		N/A N/A D. Castillo	South There	Agrados	N/A				
Eff. Date	Rev. No			Details of Change		Revised Revi	iewed Approved N		ugust 12, 2024	7 7. Walles	19/7		
-		•				•							

			WORK IN:	Effectivity Date:	September 10, 2024				
		Process Name/Title:	Validity Date:	n/a					
		Model code/Part number:	920B / 7R0118-7025	Customer: TRMX	Car Model: TOYOTA TACOMA	Document No.:		WI-ENG-PDE-9	96B
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	1	Page No.:	2 of 6
PARTS:	1. Assy	/ parts				JIG:	1. Insertior	า Jig	
NO.	F	PROCESS NAME	WORK	PROCEDURE/ ILLUSTR	RATION	TOOLS/PPE	(QUALITY POIN	TERS
2	P2	Connector setting to Insertion jig 6189-1142 (W)		Conrorient Control of the Assyright hand.	1. Press the lower wire guide using right thumb to make sure connector with inserted wires will be inserted. Release Release Release R After insertion, release the neertion jig lock using left thumb.	n/a	2. No wron 3. No wron 4. No dam		ENTATION ON

			WORK INS	Effectivity Date:	September 10, 2024					
		Process Name/Title: TAPING ASSEMBLY PROCESS				Validity Date:		n/a		
		Model code/Part number:	920B / 7R0118-7025	Customer: TRMX	Car Model: TOYOTA TACOMA	Document No.:		WI-ENG-PDE-99	96B	
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	1	Page No.:	3 of 6	
PARTS: 1. As		parts				JIG:	Insertion jig Locking jig			
NO.	F	PROCESS NAME	WORK I	PROCEDURE/ ILLUSTR	RATION	TOOLS/PPE		QUALITY POINTERS		
3	P2	Wire insertion to Connector (Assy parts)	1. Hold the insertion jig using left hand B/W wire then insert to terminal slot 1 right hand. 2 G wire R 3. Get the G- wire then insert to terminal slot 2 using right hand.	2. Press t Green wi	Wire facing the button using right thumb. Slot for lire will be opened. 4. After insertion, push the lock using left thumb and then hold the wires and gently pull out the connector from jig using right hand.	n/a	Note: During insertion, hold the wire rubber seal to prevent sagging. 1. No loose insertion 2. No wrong insertion 3. One by one insertion 4. No deformed terminal 5. No wrong wire facing Important reminders/Note/s: 1. Please hold the wire near terminal. 2. Make sure wires are properly insert Conduct Pull-Push-Pull-Push after insertion. Do not exert extra force. Document references: 1. Refer to GL-PRO-ASY-029 for Pull-procedure.		lote/s: t terminal. perly inserted. sh after	
4		Connector lock	Put the conne locking jig usin hand then pre Check the con if properly lock	ng right ess 2x. ennector lock	RESSING AFTER PRESSING	LOCKING JIG	Important reminders/Note/s: 1. MANUAL LOCKING MAY CAUSE DAMAGED CONNECTOR. 1. Use the provided locking jig per model 2. No unlock/half-lock connector 3. No damged connector			

			WORK IN	Effectivity Date:	024				
		Process Name/Title:	Validity Date:	n/a					
		Model code/Part number:	920B / 7R0118-7025	Customer: TRM	X Car Model: TOYOTA TACOMA	Document No.:		WI-ENG-PDE-99	96B
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	1	Page No.:	4 of 6
PARTS:	1. Assy 2. Gree	JIG:	1. Measuring jig						
NO.	F	PROCESS NAME	WORK	TRATION	TOOLS/PPE		QUALITY POIN	TERS	
5	P2	Taping 1 Black VM tube (Sunprene) to wire near PCB	1. Get the assy parts and set to m set the holmeted wire (No Gap) us set the VM tube (Sunprene)	easuring jig. First, ing right hand. Last,	Get the Green tape using right and then start taping process using both hands. 3. After taping, check the measurement and taping condition.	6789 112345,6789	1. Use GR 2. Please tape when 1. No flip- 2. No peel 3. No loos 4. No miss 5. No wror 6. No wror	off tape e tape ing tape ing tape ing use of tape ig use of tape ig dimension	fied measuring irement.



	_		WORK INS	Effectivity Date:	September 10, 2024				
		Process Name/Title:	TAPIN	Validity Date:		n/a			
				Car Model: TOYOTA TACOMA	Document No.:	WI-ENG-PDE-996B			
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	1	Page No.:	5 of 6
PARTS:	1. Assy 2. Blac					JIG:	n/a		
NO.	F	ROCESS NAME	WORK F	PROCEDURE/ ILLUSTRA	ATION	TOOLS/PPE	QUALITY POINTERS		
6	P2	Taping 2 COT to VM tube (Sunprene) near PCB	Start of taping 176±3mm 176±3mm 176±3mm 20±3mm 20±3mm	R	hand then start pre-		6. No wror Importa 1. Please measurin measure Docume	-off tape e tape ing tape ig use of tape ig dimension ant reminders/N use calibrated/ver g tape when getting ment. ent reference/s. o WI-PRO-ASY-00	ified g the




		WORK INSTRUCTION					Effectivity Date:		September 10, 2024		
		Process Name/Title:	TAPING ASSEMBLY PROCESS				Validity Date:	n/a			
		Model code/Part number:	920B / 7R0118-7025	Customer:	TRMX	Car Model: TOYOTA TACOMA	Document No.:		WI-ENG-PDE-99	06B	
		Purpose:	PROTOTYPE	PRE-LAUNC	Н	MASSPRO	Revision No.:	1	Page No.:	6 of 6	
PARTS:	1. Assy	parts					JIG:	n/a			

VISUAL INSPECTION/ QUALITY CHECKPOINTS

TAPING - P2

7R0118-7025



- 1 No WRONG INSERT
- 2 No TERMINAL BACKING
 OUT
- 3 No UNLOCKED/ HALF-LOCKED CONNECTOR
- 4 No MISSING TAPE/ NO WRONG USE OF TAPE (GREEN TAPE)
- No MISSING TAPE/ No WRONG USE OF TAPE

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.