

Process Name/ Title:

PACKING INSTRUCTION

Document No:

WI-ENG-PDE-1277

WORK INSTRUCTION

Effective Date:

Product Code/Name:

Customer Code:

0 Page No.: Page 1 of 1 Rev. No.: TRQSS 7L0167 Records/Remarks/ Work Procedure/ Illustration No. **Quality Pointers** 32pcs \*2bdls Qty/box Put Vinyl (1) Sheet (1250 x 1250) Mat'l name Dim. Qty. inside carton box. DC carton 1131\*781 1 Vinyl sheet 1250\*1250 1 420\*280 Vinyl bag 2 Step number 4 is applicable only in **QC FG Inspection.** Put first bundle of (2) products. (32pcs/bundle) 32pcs\*2bundles Put second bundles of (3) products in opposite direction. (32pcs/bundle) Plastic Vinyl bag (4)Fold the vinyl sheet then close the flaps and put ID tag (Inner tag at the top of the plastic and Outer tag at the right side of the front of the box). Note: If need to attach 4M tag Put 4M tag at the left side

|                |          |                   |             |               |           |       | Prepared                  | Reviewed | Approved    | Noted |
|----------------|----------|-------------------|-------------|---------------|-----------|-------|---------------------------|----------|-------------|-------|
|                |          |                   |             |               |           |       |                           | 1/1 :11  |             |       |
| 05/15/25       | 0        | Initial issue     | A.Hernandez | C. Villanueva | A. Arañes | n/a   | Okuwewedez<br>A.Hernandez |          | / (° ))     | n/a   |
| Eff./Rev. Date | Rev. no. | Details of change | Prepared    | Reviewed      | Approved  | Noted | Established. da           | ite:     | May 15, 202 | 5     |

CONFIDENTIAL: ©2017 NBC; all rights reserved. Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.

NBC (Philippines)
MASTER COPY