Process Name/ Title: WI-ENG-PDE-1179 Document No: **PACKING INSTRUCTION** WORK INSTRUCTION Effective Date: December 6, 2024 Product Code/Name: Customer Code/ Customer 0 Rev. No.: Page No.: Page 1 of 1 **75**\$834 **TRMX** Records/Remarks/ No. Work Procedure/ Illustration **Quality Pointers** 1 Qty/bo 100pcs\* 400 4bdls X Mat'l Dim. Qty. Put Vinyl Sheet name (1250 x 1250) **TRMX** inside TRMX box. 544\*370\* 1 228mm box Vinyl 1250\* 1 1250 sheet 2 **Partition** 343\* 3 board 510 Vinyl 545\* 4 450 bag Get the vinyl (plastic) bag then put the 100 pcs harness. Insert products in same PBVP connectors must direction. Put the ID be on top position. tag inside then fold the plastic bag. (3) Put products on standing position and **PBVP** connectors must be on top position. partition board vertically & alternately with the products. (100pcs\* 4 Bundles with I.D tag inside) (4) Fold the vinyl sheet. Put NBP Identification tag at the top and tape the flaps (two side and top portion). Then Warehouse Identification tag at right side of the box. Note: If need to attach 4M tag Put 4M tag at the left side of the box D.Castillo C.Villanueva A. Arañes 12/06/24 Initial issue Rev. No. Details Eff. Date Prepared Checked Approved Establish Date: December 6, 2024