					K INSTRUCTION			Effectivity Date:		September 12,	2024
			Process Name/Title:		LAMP ASSEMBLY PROC			Validity Date:		n/a	
			Model code/Part number:	920B / 7R0116-702	Customer: TRMX	Car Model: TOYC	TA-TACOMA	Document No.:		WI-ENG-PDE-1	030
			Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO		Revision No.:	1	Page No.:	1 of 8
PARTS	1. Assy parts: Clamp 82711-3A640 (B) ; Black tape 20mm; Label 7V3200-0020								JIG: 1. Clamp assembly jig		
N	0.	F	PROCESS NAME	WC		TOOLS/PPE	(	QUALITY POINTERS			
	1	Clamp Assy	Table Lay-out	Label Dispenser QR CODE 7V3200-0020	Tape holder/Black Tape	Tray/CI 82711-3A	640 (B)	Safety Instruction Be sure to wear prescribed person protective equipment during operation (gloves, finger cotect.)  Housekeeping 1. Maintain and alwe practice 5's. 2. Personal things the workplace is prohibited. Keep it your locker.  Alert level For any trouble, inforthe Assembly Assist Supervisor or Linue Leader for immedia corrective action	al ent s,	ing parts/tools ss parts/tools ent reference/so WI-ENG-PDE-6 ssemmbly process	<b>50A-B</b> for
				Revision Hi	istory			Prepared by	Reviewed by	Approved by	Noted by
							+ +				
09/12/24		-	rom Pre-launch to Masspro.		A. C. Hernandez Villanueva	a	n/a Oxform Con Ao. /	Month House			
09/09/24		Initial iss	ue.			Hernandez Villanueva	a	n/a Okum Chr. du A. Hernandez	C.Villanueva	A.Araños	n/a
Eff. Date	Rev. No			Details of Change		Revised Reviewed	d Approved N	oted Est. Date:	September 12, 2024		
				1							

			WORK IN	STRUCTION		Effectivity Date:	September 12, 20	)24		
		Process Name/Title:		MP ASSEMBLY PRO	CESS	Validity Date:	n/a			
		Model code/Part number:	920B / 7R0116-7022	Customer: TRMX	Car Model: TOYOTA-TACOMA	Document No.:	WI-ENG-PDE-1030			
		Purpose:	□ PROTOTYPE □ PRE-LAUNCH ■ MASSPRO		MASSPRO	Revision No.:	1 Page No.:	2 of 8		
		ı								
PARTS:	2. Blac	np 82711-3A640 (B) k tape 20mm				JIG:	1. Clamp assembly jig			
NO.	F	PROCESS NAME	WORK	PROCEDURE/ ILLUSTF	RATION	TOOLS/PPE	QUALITY POINT	ERS		
2	Clamp		1. Get 1pc. of clamp 82711-3A640 hands then set to clamp location 1	82711-3.	A640 (B)	The second secon	Important reminders 1. Please check the Clabefore start of assembly wrong use of clamp 1. No wrong use of clamp 2. No damaged clamp 3. No missing clamp 4. No wrong use of tape 5. No missing tape	CLAMP  der  //Note/s: mp first		




WORK INSTRUCTION Effectivity Date:									2024
		Process Name/Title:	CLAM	IP ASSEMBLY PROC	CESS	Validity Date:		n/a	
		Model code/Part number:	920B / 7R0116-7022	Customer: TRMX	Car Model: TOYOTA-TACOMA	Document No.:		WI-ENG-PDE-1	030
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	1	Page No.:	3 of 8
PARTS:	1. Assy	parts				JIG:	1. Clamp A	Assembly jig	
NO.	F	PROCESS NAME	WORK F	PROCEDURE/ ILLUSTR	RATION	TOOLS/PPE	(	QUALITY POIN	TERS
3	Clamp Assy	Connector lock	1. Put the connector into locking hand then press 2x to lock using Check the lock if properly locked.  Before lock	g jig using right g both hands.	Coupler Cross Sectional NG NG Double Double Half Lock Condition  LOCKING	GOOD  Double  Full Lock Condition	1. MANU DAMAGE	ant reminders JAL LOCKING I ED CONNECTO  provided locking ji ck/half-locked coni	MAY CAUSE DR g per model

WORK INSTRUCTION Effectivity Date: Sept										
		Process Name/Title:	CLAN	MP ASSEMBLY PROC	CESS	Validity Date:		n/a		
		Model code/Part number:	920B / 7R0116-7022	Customer: TRMX	Car Model: TOYOTA-TACOMA	Document No.:		WI-ENG-PDE-103	30	
		Purpose:	□PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	1	Page No.:	4 of 8	
PARTS:	1. Assy 2. Blac	parts k tape 20mm				JIG:	1. Clamp a	ssembly jig		
NO.	F	PROCESS NAME	WORK	PROCEDURE/ ILLUSTR	RATION	TOOLS/PPE	(	QUALITY POINT	ERS	
4	Clamp Assy	Clamp assembly	CONNECTOR SETTING  RECEIVER BASE 1  1. Get the assy parts and set into jig. ( correct setting of harness). First, set (W) to Receiver base 1 then lock. Cor jig. Color sensor light will beep/buzz tape. Color sensor light will beep/buzz tape. Last, set the terminal end togethe press by Toggle clamp.	COLOR SENSOR BROWN TAPE  See above picture for the connector 6188-0407 intinue to set the harness in if sensor detects Brown zz if sensor detects White	2. Check if all LED light for Power On encountered abnormality, STOP and attention of the leader. WAIT for further continue the process.  3. Hold the tape on clamp location 1. In then cut the tape using both hands. Proceed to attachment of label.	immediately CALL the er instruction then  Make 3 windings of tape ess the SW button after	1. No wron 2. No wron 3. No dama	nt reminders/No sure no gap in sininals  g use of parts g use of tape aged clamp g clamp position		

					TRUCTION		Effectivity Date:	September 12, 2024					
		Process Name/Title:			CLAMI	P ASSEMBLY PRO	CESS		Validity Date:		n/a		
		Model code/Part number:		920B / 7R011	6-7022	Customer: TRMX	Car Model:	TOYOTA-TACOMA	Document No.:		WI-ENG-PDE-1	030	
		Purpose:		PROTOTYPE		PRE-LAUNCH	MASSP	RO	Revision No.:	1	Page No.:	5 of 8	
PARTS:		el 7V3200-0020	JIG:								Clamp assembly jig		
NO.	F	PROCESS NAME			WORK P	ROCEDURE/ ILLUST	RATION		TOOLS/PPE	QUALITY POINTERS			
				MODEL CODE	ITEM NO.	ITEM NAME		16 Model code					
				7R0116-7022	73230-AK010	PASSENGER MNL/PWR							
				7R0117-7025	73240-AK010	DRIVER MANUAL		1. Get the label.	del code, item no. & name				
				7R0118-7025	73240-AK020	DRIVER PWR/ISO D		Note: Check the mo	der code, item no. & name				
				7R0119-7021	73230-AK050	PASSENGER ISO D	73230-AK010 PASSENGER MNL/PWB  Tal 32 20 44 1			1. No bubbles			
				7R0120-7022	73230-AK030	PASSENGER FOLD-FLAT	PASSENGER MN			No damage     No peel off			
5	Clamp Assy	Label Attachment	6. 8	Press the label upsid	jig.		h end part of labe	3. Fold the center	ago Owen	4. No wron 5. No miss 6. No loos	ng use of label		


WORK INSTRUCTION Effectivity Date:									2024
		Process Name/Title:		IP ASSEMBLY PROC		Validity Date:		n/a	
		Model code/Part number:	920B / 7R0116-7022	Customer: TRMX	Car Model: TOYOTA-TACOMA	Document No.:		WI-ENG-PDE-1	030
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	1	Page No.:	6 of 8
PARTS:	1. Assy	parts 17V3200-0020				JIG:	1. Clamp a	ssembly jig	
			MORK	DD OCEDUDE/ II LUCTE	ATION	TOOLS/PPE	QUALITY POINTERS		
NO.	ı	PROCESS NAME	WORK	PROCEDURE/ ILLUSTF	KATION	TOOLS/PPE	,	QUALITY POIN	IEKS
6	Clamp	Clamp assembly	Label Dispenser  7. After taping, cond	QR Code SENSOR	e removing the harness from the jig.	HASSEAMULY THE COUNTY OF THE C	2. No wron 3. No dama 4. No wron	g clamp position	lote/s:



			WORK INS	Effectivity Date:		September 12, 2024						
		Process Name/Title:	CLAM	Validity Date: n/a								
		Model code/Part number:	920B / 7R0116-7022	Customer: TRMX	Car Model: TOYOTA-TACOMA	Document No.:		WI-ENG-PDE-1	1030			
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	1	Page No.:	8 of 8			
PARTS:	/ parts	JIG:	n/a									
	VISUAL INSPECTION/ QUALITY CHECKPOINTS											

## **CLAMP ASSY**

## 7R0116-7022



1 No Unlocked/Half-Locked Connector

- 3 No Wrong facing of clamp
- 2 No Wrong Facing/Used of QR Code label

CONFIDENTIAL: Any misuse or misappropriation, including unauthorized copying, reproduction in any form, disclosure or publishing of this document or any information herein is strictly prohibited.