				WORK INS		Effectivity Date:		June 3, 2024			
			Process Name/Title:	CLAMP ASSEMBLY PROCESS				Validity Date:		n/a	
			Model code/Part number:	700B / 7N0038-7020B	Customer: TRJ	Car Model: TOYOTA LAN	ID-CRUISER	Document No.:		WI-ENG-PDE-88	37
			Purpose:	□PROTOTYPE	□PRE-LAUNCH	MASSPRO		Revision No.:	1	Page No.:	1 of 5
PARTS:	S: 2.Clamp 82711-52090 (W) 5. Black tape			<ol> <li>Clamp 82711-3A540 (W)</li> <li>Black tape [4pcs]</li> <li>Violet tape [1pc]</li> </ol>			JIG:	Clamp Assembly jig			
NC	).	F	ROCESS NAME	WORK P	ROCEDURE/ ILLUSTRA	TION		TOOLS/PPE	QUALITY POINTERS		TERS
1		n/a	Table Lay-out	Clamp 82711-48070 (GR)/Clamp Tray  Assy Parts	TABLE LAY-OUT  Clamp 82711-52090 (W Clamp Tray  Black tape/Tape holder	Clamp 82711-3A Clamp Tr.	ray	Safety Instruction Be sure to wear required personal protective equipment during operation (gloves, finger cots, etc.)  Housekeeping 1. Maintain and always practice 5's.	1. No missi	ng parts/tools ss parts/tools	
				Revision History				Prepared by Re	viewed by	Approved by	Noted by
06/03/24	1 0	Change p	ore-launch to mass pro.				Arañes n.		onf ) for-	A Maries	n/a
Eff. Date	Rev. No			Details of Change		Revised Reviewed Ap	proved No	9		. , . ,	.,, .



			WORK INST	Effectivity Date:	June 3, 2024				
		Process Name/Title:	CLAM	Validity Date:		n/a			
		Model code/Part number:	700B / 7N0038-7020B	Customer: TRJ	Car Model: TOYOTA LAND-CRUISER	Document No.:		WI-ENG-PDE-8	387
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO	Revision No.:	1	Page No.:	2 of 5
PARTS:	1.Clamp 82711-48070 (GR) [3pcs 2.Clamp 82711-52090 (W) 3.Clamp 82711-3A540 (W)			4. Violet Tape 5. Black tape [4 pcs.]			1. Clamp As		
NO.	F	PROCESS NAME	WORK P	ROCEDURE/ ILLUSTI	RATION	TOOLS/PPE	QUALITY POINTERS		
2	n/a	Clamp setting	1. Get 3pcs. of clamp 82711-48070 (G hand and set to clamp location 1, 4 an hands.  2. Get 2pcs. of clamp 82711-52090 (W and set to clamp location 2 using both location 3 using both location 4 using both location 3 using both location 4 using both location 5 using both location 6 using both location 8 using both location 6 using both location 8 using 8	(a) using right d 5 using both  (b) using right hand hands.	2711-3A540 (W)  82711-52090 (W  3 2  4. Initially attach Violet tape to clamp to hands.  5. Initially attach Black tape to clamp to using both hands.	1 1 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2	2. No wron 3. No dama 4. No wron 1. Pleas before wrong C	g use of parts g use of tape aged clamp g clamp position  retant reminders/N se check the Clar start of assembly use of clamp.  One side tape under  CLAMP ILLUSTRATION  NG  10090(W)  8271	mp first y to avoid

			WORK IN	Effectivity Date:	June 3, 2024					
		Process Name/Title:	Validity Date:	n/a						
		Model code/Part number:	700B / 7N0038-7020B	Customer: TRJ	Car Model: TC	YOTA LAND-CRUISER	Document No.:	WI-ENG-PDE-887		
		Purpose:	PROTOTYPE	PRE-LAUNCH	MASSPRO		Revision No.:	1	Page No.:	3 of 5
PARTS:	1. Assy	<i>ı</i> parts					JIG:	1. Clamp As	sembly jig	
NO.	IO. PROCESS NAME		WORK	PROCEDURE/ ILLU	STRATION		(	QUALITY POINT	ERS	
3	n/a	Clamp Assembly	1. Put the assy into jig. (See above pine the connector 6098-3802 (W) to Recein jig. Last, set G-B-V wires together w  2. Check if all LED Light for POWER abnormallity, STOP and immediately further instruction and continue the profunction of	on, CLAMP ON was Of CALL the attention of the occas.  make 3 windings of tape och button after taping. Commake 3 windings of tape och button after taping. Commake 3 windings of tape och button after taping. Commake 3 windings of tape och button after taping. Commake 3 windings of tape	set the harness by toggle clamp.  N. If encountered be leader, WAIT for the cut the ontinue to clamp be then cut the ontinue to clamp be then cut the ontinue to clamp	windings of tape thei hands. Press the Swit Continue to clamp loc  7. Hold the tape on clampings of tape their	RECEIVER BASE  CONNECTOR SETTING  amp location 4, make 3 in cut the tape using both ch button after taping. The cut the tape using both ch button after taping.  The cut the tape using both the button after taping.  HECKING before	1. Pleas before: wrong i Import 1. Make stopper 2. Make taping. 1. No loose 2. No dama 3. No missi	ne wind for under to	np first to avoid Note/s: veen clamp

			WORK INS		Effectivity Date:	June 3, 2024				
		Process Name/Title:	CLAMP ASSEMBLY PROCESS			Validity Date:		n/a		
		Model code/Part number:	700B / 7N0038-7020B	Customer: TRJ	Car Model: TOYOTA LAND-CRUISER	Document No.:		WI-ENG-PDE-88	.7	
		Purpose:	☐ PROTOTYPE	☐ PRE-LAUNCH	MASSPRO	Revision No.:	1	Page No.:	4 of 5	
PARTS:	1. Assy	parts				JIG:	n/a			
NO.	P	ROCESS NAME	WORK	PROCEDURE/ ILLUSTR	ATION	TOOLS/PPE	QUALITY POINTERS			
NO.	n/a		(a) 75±5 (a) 39±4 (b) 0 <sup>2</sup> 0  NOTE: (a) - Taping (B) (b) - Taping(V) (c) - Clamp (GR) (d) - Clamp (W)	© 154±5  COT(B) Ø5  WIRE TYPE TABLE  No. Color W.  1 V A' 2 B A'	(§ 75±5 (B) (61±5 (B) (C) (Vinyl tube(B) Ø5 (9) 116±5	MEASURING TAPE  6 7 8 9 1 2 3 4 5 6 7 8 9 1 12 3 4 5 6 7 8 9 1 12 3 4 5 6 7 8 9 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	1. No wrong Importat  1. Please measuri measure 2. For Ha  Docume 1. Refer assemb	g dimension  nt reminders/Note e use calibrated/ving tape when gett	erified ting the varimono.	

		WORK INS	Effectivity Date: June 3, 2024					
	Process Name/Title:	CLAM	Validity Date:	n/a				
	Model code/Part number:			Car Model: TOYOTA LAND-CRUISER	Document No.:	WI-ENG-PDE-887		
	Purpose:	PROTOTYPE	Customer: <b>TRJ</b>	MASSPRO	Revision No.:	1 Page No.:	5 of 5	
						<u> </u>		
PARTS: n/a					JIG:	n/a		
·		VIS	UAL INSPECTION/QUA	ALITY CHECKPOINTS				
CLAI	MP		7N(	0038-7020	В			
	1	2	2	2	2	Bak believek believe bet bet bet bet bet bet bet bet bet be		
1	No Wrong use	of tape (Clamp	taping) (3	Check the Clam	p appearand	ce		
2	No Missing Cla	amp	4	Check the Aligr	nment of Cla	mp		