6 List of Warning Codes

Table 6–1 No. 3 resettable warning list

Fault code	Fault subcode	Alarm Name	Fault Level	Resettable
E108	E108.0	Parameter write error	No. 3	Yes
	E108.1	Parameter read error	No. 3	Yes
	E108.2	Invalid check on data written in EEPROM	No. 3	Yes
	E108.3	Invalid check on data read in EEPROM	No. 3	Yes
	E108.4	Single data is stored too many times	No. 3	Yes
E110	E110.0	Frequency-division pulse output setting error	No. 3	Yes
E121	E121.0	Invalid S-ON command	No. 3	Yes
E122	E122.0	Multi-turn absolute encoder setting error	No. 3	Yes
E510	E510.0	Frequency division pulse output overspeed	No. 3	Yes
E600	E600.0	Inertia auto-tuning failure	No. 3	Yes
E601	E601.0	Homing warning	No. 3	Yes
	E601.1	Homing switch error	No. 3	Yes
	E601.2	Homing mode setting error	No. 3	Yes
E730	E730.0	Encoder battery warning	No. 3	Yes
E731	E731.0	Encoder battery failure	No. 3	Yes
E831	E831.1	AI1 zero offset too large	No. 3	Yes
E834	E834.1	AI1 overvoltage	No. 3	Yes
E900	E900.0	DI emergency braking	No. 3	Yes
E902	E902.0	DI setting invalid	No. 3	Yes
	E902.1	DO setting invalid	No. 3	Yes
	E902.2	Torque reach setting invalid	No. 3	Yes
E908	E908.0	Model identification failure	No. 3	Yes
E909	E909.0	Motor overload	No. 3	Yes
E910	E910.0	Control circuit overvoltage	No. 3	Yes
E920	E920.0	The regenerative resistor is overloaded.	No. 3	Yes
E922	E922.0	Resistance of the external regenerative resistor too small	No. 3	Yes
E924	E924.0	Regenerative transistor over-temperature	No. 3	Yes
E941	E941.0	Modified parameters activated at next power-on	No. 3	Yes
E942	E942.0	Parameters saved frequently	No. 3	Yes
E950	E950.0	Forward overtravel warning	No. 3	Yes
E952	E952.0	Reverse overtravel warning	No. 3	Yes

Fault code	Fault subcode	Alarm Name	Fault Level	Resettable
E980	E980.0	Encoder algorithm error	No. 3	Yes
E990	E990.1	Pulse input overspeed warning	No. 3	Yes
EA41	EA41.0	Torque fluctuation compensation failure	No. 3	Yes

7 Fault Code Table

No. 1 non-resettable faults:

Table 7–1 List of No. 1 non-resettable faults

Fault code	Fault subcode	Name	Fault Level	Resettable
E101	E101.0	Abnormal parameters in groups H02 and above	No. 1	No
	E101.1	Parameter error in group H00/H01	No. 1	No
	E101.2	Address error in read/write operation after the number of parameters changes	No. 1	No
	E101.9	Parameter attribute initialization check error.	No. 1	No
E102	E102.0	FPGA communication establishment error	No. 1	No
	E102.1	FPGA initialization start error	No. 1	No
	E102.8	FPGA and MCU version mismatch	No. 1	No
E104	E104.1	MCU running timeout (MCU break down)	No. 1	No
	E104.2	FPGA running timeout (FPGA break down).	No. 1	No
	E104.4	MCU command update timeout	No. 1	No
E120	E120.0	Unknown encoder model	No. 1	No
	E120.1	Unknown motor model	No. 1	No
	E120.2	Unknown drive model	No. 1	No
	E120.5	Motor and drive current mismatch	No. 1	No
	E120.6	FPGA and motor model mismatch	No. 1	No
	E120.7	Model check error	No. 1	No
	E120.8	Junction temperature parameter check error	No. 1	No
E136	E136.0	Encoder ROM motor parameter check error	No. 1	No
	E136.1	Encoder ROM motor parameter read error	No. 1	No
E201	E201.0	Phase-P overcurrent	No. 1	No
	E201.1	Phase-U overcurrent	No. 1	No
	E201.2	Phase-V overcurrent	No. 1	No
	E201.4	Phase-N overcurrent	No. 1	No
E210	E210.0	Output short circuited to ground	No. 1	No
E234	E234.0	Runaway	No. 1	No
E740	E740.0	Encoder communication timeout	No. 1	No
	E740.2	Absolute encoder error	No. 1	No
	E740.3	Absolute encoder single-turn calculation error	No. 1	No
	E740.6	Encoder write error	No. 1	No

Fault code	Fault subcode	Name	Fault Level	Resettable
E765	E765.0	Nikon encoder over-temperature or overspeed	No. 1	No
EA33	EA33.0	Encoder read/write check error	No. 1	No

No. 1 resettable faults

Table 7–2 List of No. 1 resettable faults

Fault code	Fault subcode	Name	Fault Level	Resettable
E150	E150.0	STO safety state applied	No. 1	Yes
	E150.1	STO input state abnormal	No. 1	Yes
	E150.2	Abnormal measured buffer 5 V voltage	No. 1	Yes
	E150.3	STO input circuit hardware diagnosis failure	No. 1	Yes
	E150.4	PWM Buffer hardware diagnosis failure	No. 1	Yes
E208	E208.2	Encoder communication timeout	No. 1	Yes
	E208.4	FPGA current loop operation timeout	No. 1	Yes
E320	E320.0	The regenerative resistor is overloaded.	No. 1	Yes
E400	E400.0	Main circuit overvoltage	No. 1	Yes
E410	E410.0	Main circuit undervoltage	No. 1	Yes
	E410.1	Main circuit de-energized	No. 1	Yes
E500	E500.0	Motor overspeed	No. 1	Yes
	E500.1	Speed feedback overflow	No. 1	Yes
	E500.2	FPGA position feedback pulse overspeed	No. 1	Yes
E602	E602.0	Angle auto-tuning failure	No. 1	Yes
	E602.2	U/V/W phase sequence reversed	No. 1	Yes
E605	E605.0	Speed too fast upon S-ON	No. 1	Yes
E620	E620.0	Motor overload	No. 1	Yes
E625	E625.0	Brake abnormality enabled	No. 1	Yes
E626	E626.0	Brake abnormality disabled	No. 1	Yes
E630	E630.0	Motor stall overtemperature protection	No. 1	Yes
E640	E640.0	IGBT junction overtemperature	No. 1	Yes
	E640.1	Flywheel diode overtemperature	No. 1	Yes
E650	E650.0	Heatsink overtemperature	No. 1	Yes
E660	E660.0	The motor temperature is too high	No. 1	Yes
E939	E939.0	Motor power cables disconnected	No. 1	Yes

No. 2 resettable faults

Table 7–3 List of No. 2 resettable faults

Fault code	Fault subcode	Name	Fault Level	Resettable
E122	E122.1	Different DIs assigned with the same function	No. 2	Yes
	E122.2	Different DOs assigned with the same function	No. 2	Yes
	E122.3	Upper limit in the rotation mode too high	No. 2	Yes
	E122.4	Different VDIs assigned with the same function	No. 2	Yes
	E122.5	DI and VDI assigned with the same function	No. 2	Yes
E420	E420.0	Main circuit phase loss	No. 2	Yes
E661	E661.0	STune failure	No. 2	Yes
E662	E662.0	ETune failure	No. 2	Yes
E663	E663.0	ITune failure	No. 2	Yes
E664	E664.0	Resonance too strong	No. 2	Yes
E731	E731.0	Encoder battery failure	No. 2	Yes
E733	E733.0	An encoder multi-turn counting error occurs.	No. 2	Yes
E735	E735.0	Encoder multi-turn counting overflow	No. 2	Yes
E760	E760.0	Encoder over-temperature	No. 2	Yes
E994	E994.0	Station number conflict	No. 2	Yes
EB00	EB00.0	Position deviation too large	No. 2	Yes
	EB00.1	Position deviation overflow	No. 2	Yes
EB01	EB01.0	The position reference increment is too large.	No. 2	Yes
	EB01.1	Individual position reference increment too large	No. 2	Yes
	EB01.3	Reference overflow	No. 2	Yes
EB03	EB03.0	Electronic gear ratio beyond the limit - H05.02	No. 2	Yes
	EB03.1	Electronic gear ratio beyond the limit - Electronic gear ratio 1	No. 2	Yes
	EB03.2	Electronic gear ratio beyond the limit -Electronic gear ratio 2	No. 2	Yes
ED02	ED02.0	Modbus communication timeout	No. 2	Yes
ED03	ED03.0	CANLink communication failure	No. 2	Yes
ED04	ED04.0	CANopen communication timeout	No. 2	Yes
ED05	ED05.0	CANopen communication initialized	No. 2	Yes
ED08	ED08.0	CANopen bus PDO transmission length error	No. 2	Yes
ED11	ED11.0	CANopen sync period error too large	No. 2	Yes

19011907B00

Copyright © Shenzhen Inovance Technology Co., Ltd.

Shenzhen Inovance Technology Co., Ltd.

www.inovance.com

Add.: Inovance Headquarters Tower, High-tech Industrial Park, Guanlan Street, Longhua New District, Shenzhen
Tel: (0755) 2979 9595 Fax: (0755) 2961 9897

Suzhou Inovance Technology Co., Ltd.

www.inovance.com

Add.: No. 16 Youxiang Road, Yuexi Town, Wuzhong District, Suzhou 215104, P.R. China
Tel: (0512) 6637 6666 Fax: (0512) 6285 6720