Wave Calculations

1. $F_{wave} = f_{cpu}/preScaler * steps in timer* steps in wave$

SawTooth

High Frequency 16 million/ 64*1*255 = 980.39 Low Frequency 16million/ 64*255*255 = 3.845

Sine Wave

High Frequency 16 million/ 64*1*255 = 980.39 Low Frequency 16million/ 64*255*255 = 3.845

Triangle Wave

High Frequency 16 million/ 64*1*510 = 490.196 Low Frequency 16million/ 64*255*510 = 1.9922