#### Power Loss in Flight

Airspeed	70MPH
Alternate Air	OPEN
Fuel Pump	ON
Fuel Valve	CHECK ON
Ignition	CHECK BOTH ON
Transponder	SQUAWK 7700
Radio	CALL MAYDAY

#### EMERGENCY LANDING

Throttle	CLOSE
Mixture	CUT OFF
Fuel Valve	OFF
Ignition	BOTH OFF
All Electrical	OFF
Door / Window	EJECT
Belts / Harnesses	SECURE

# INITIAL

Fuel Quantity	CHECK
Oil Quantity	CHECK
Call for Fuel / Oil	AS REQUIRED
Paperwork	CHECK
Ignition	BOTH OFF
All Electrical	OFF
Master	ON
Lights	CHECK
Master	OFF
Fuel Valve	ON
Breakers	CHECK
Fuse Supply	CHECK
ELT	CHECK ARMED
Seat Belts	CHECK SECURE
Controls	RELEASE
Ties / Chains	REMOVE

### Preflight

### BEFORE STARTING

Fuel Sumps	ALL DRAINED
Fuel Quantity	VERIFY
Ties / Chains	CHECK REMOVED
Chocks	CHECK REMOVED
Prop	CHECK CLEAR
Fuel Caps	CHECK SECURE
Cowl Access	CHECK SECURE
Rear Belts	CHECK SECURE
WX / NOTAMs / TFRs	CHECK
Weight & Balance	CHECK
Headset	MONO / STEREO
Sunglasses	AS REQUIRED
ATIS / AWOS	LISTEN
Altimter	$\mathbf{SET}$
Departure Clearance	AS REQUIRED

# Start

Door	CLOSED
Seats	ADJUST
Avionics	OFF
Alternate Air	CLOSED
Prop	FULL FORWARD
Mixture	RICH
Master	ON
Beacon	ON
Fuel Pump	PRIME ENGINE
Mixture	FULL LEAN
Brakes	HOLD
Stick	FULL AFT
Ignition	BOTH ON
Starter	ENGAGE
Mixture	RICH ON START
Oil Pressure	25PSI IN 30SEC
Timer / Tracker	START
Mixture	LEAN

# Taxi

Seat Belts	SECURE
Avionics	ON
Transponder	$\mathbf{ALT}$
ADS-B	ON
Taxi Clearance	AS REQUIRED
Brakes	TEST
Mixture	CHECK LEAN

## Takeoff

Mixture	BEST POWER
Alternate Air	CLOSED
Transponder	$\operatorname{ALT}$
Doors / Windows	CHECK
Landing Light	ON
ABOVE A SA	AFE HEIGHT
Throttle	25" MP
Prop Control	$2500 \mathrm{\ RPM}$

### Run-Up

Flight Controls	FREE / CORRECT
- C	•
Instruments	CHECK
Mixture	BEST POWER
Trim	SET TAKEOFF
Stick	FULL AFT
Throttle	$1800 \mathrm{RPM}$
Magnetos	$175\mathrm{RPM} \ / \ 50\mathrm{RPM}$
Prop Control	CYCLE THREE TIMES
Alternate Air	TEST
Ammeter	CHECK
Oil Pressure	60 - 100 PSI
Oil Temperature	100F - 245F
Throttle	IDLE CHECK
Throttle	$1000 \mathrm{RPM}$

SEAT BELTS
G METER
DOORS/WINDOWS

#### LANDING

Alternate Air	CLOSED
Fuel Quantity	CHECK
Brakes	CHECK FIRM
Mixture	BEST POWER
Prop	FULL FORWARD
Belts / Harnesses	SECURE

#### AFTER LANDING

Mixture	LEAN
Trim	SET TAKEOFF
Transponder	$\operatorname{ALT}\ 1200$

#### WHAT ARE YOU FORGETTING?

Aresti Cards, Cameras, Phone, Headset, Jacket, Sunglasses, Tach Book, Radios

# Shutdown

Avionics	OFF
Mixture	CUT OFF
Ignition	BOTH OFF
Lights	ALL OFF
Master	OFF
Timer / Tracker	STOP

#### FINAL

Ties / Chains	SECURE
Flight Controls	SECURE
Hobbs Time	RECORD
Ignition	BOTH OFF
All Electrical	OFF
Windows / Vents	CLOSED
Cabin Door	LOCKED
Parachute	STOWED