DIAGRAMA DE PINES BALAM-PIC 1.0 Pin Entrada/Salida Salida de 5V USB **GND** Alimentación Externa (JACK) Salida PWM **Pin UART** JEB GND PC6 VEX1 *5V* GND PIC LED GREEN GND PWM2 18F4550 PWM: GND PC₀ LED BLUE BALAM-PIC RX *5V* GND 1.0 8 A 8 (%) RESET USER