Quick Reference SV9100

- Answer Call Lift Handset or Press SPEAKER (Make sure MIC light is on)
 Note When receiving a 2nd call the "Answer" Key will flash. To answer Press "Answer"... That will put your first party on hold and answer the 2nd call.
- Placing Calls (Internal) Press one touch button or dial extension
- Placing Calls (External) Lift handset Dial 9 + Number
- **Headset To answer a ringing call** Press "Headset" Button then "Headset" to end the call
- **Headset To place a call** Press "Headset" and receive dial tone Dial internal ext or 9+number Press "Headset" to end the call.
- Hold Press HOLD button
- Transfer With call in progress Press TRANSFER Dial EXTENSION Wait for answer or hang up
- **Trunk to Trunk Transfer** With outside call in progress Press "Transfer" dial 9 + phone number and wait for answer Press "Transfer" again.
- **Quick Transfer to VM** With call in progress Press TRANSFER Dial EXTENSION PRESS 8 Hang up (Call will be transferred directly to VM)
- Page (Button) Press PAGE button (Will page external horns/speaker)
- Page (Internal Code) 7011 (Zone 1)
- Page (External Code) 7031 (Zone 1)
- Page (Soft Keys-Internal) Lift Handset Press INPG Press 1 for group 1
- Page (Soft Keys-External) Lift Handset Press EXPG Press 1 for group 1
- Park a call (Code) With call in progress Press TRANSFER Dial # 6 * Check display for park location (ex. 01) Hang up Retrieve Parked call (Code) Lift Handset Dial * 6 Dial park location (ex. 01)
- DND TO SET Press "DND" key Will take approx. 5 secs to set (Will be lit RED when set)
 DND TO CANCEL Press "DND" key
- DND To Set using Code Lift Handset dial 747 (Wait approx. 5 sec display will show DND set)
 DND To cancel using Code Lift Handset dial 747 (Wait approx. 5 sec display will show cancel)
- **CONFERENCE** With call in progress Press CONF (soft key) Dial number(Internal or 9+ for external) When party answers, let them know they are joining a conference Press ADD. To add additional parties... repeat steps. When ready to join all parties together PRESS BEGIN
- Adjust ring volume Press SPEAKER Dial 729 Use up/down buttons to adjust Press SPEAKER
- Change Ring Tones Press SPEAKER Dial 720 Select "1" for Internal or "2" for External
- Last Number REDIAL Press REDIAL (repeat to scroll) Lift handset to place call
- **To dial System Speed Dials** Press Redial Dial 000-099
- Caller ID Press LIST Press CID Use arrows to scroll
- Call pick up (Direct) Lift handset PRESS * * Then dial specific extension
- Call Pick up (Your Group) Lift Handset PRESS *#
- Call Pick up (Specific Group) Lift Handset DIAL 768 Dial "Group" Number
- Call forward all Press SPEAKER DIAL 741 PRESS 1 DIAL destination (Internal extension or 9+outside number Press SPEAKER
 - Call forward all cancel Press SPEAKER DIAL 741 PRESS o Press SPEAKER
- Call forward busy no answer Press SPEAKER DIAL 744 PRESS 1 DIAL destination (VM Pilot 100) Press SPEAKER Call forward busy no answer cancel Press SPEAKER DIAL 744 PRESS 0 Press SPEAKER
- Change Display name Press SPEAKER Dial 700 Enter Extension number Use dial pad to enter name Press HOLD Press SPEAKER
- Message light cancel Press SPEAKER Dial 773 Press SPEAKER
- Voice/Tone Press SPEAKER Dial 723 (Signaling/Ring) or SPEAKER 721 (Voice) Press Speaker
- Set Time Press SPEAKER Dial 728 Enter 2 digits for hour (24 hr clock) Enter 2 digits for minutes Press SPEAKER
- **Programming ONE TOUCH/DSS Buttons** Press SPEAKER Dial 751 Press BLANK Button Dial "o1" Dial Extension to program on button (ex.1100) or 9 + Telephone Number Press HOLD Press SPEAKER