Outer Iteration (maximum iterations defined by it_max_bga)
 The outer iterations iterate until convergence of both
 PHI and Structural Parameters (optional)
 ■ Inner Iteration (maximum iterations defined by it max phi)

end Structural Parameter Optimization

The inner iteration progresses until convergence of PHI conditional on the current values of Structural Parameters

end Inner Iteration

If linesearch == 1

Linesearch (maximum iterations defined by it_max_linesearch)

The linesearch is an optional correction that can get optimization for PHI back on track if it strays

end linesearch

If struct_par_opt ==1

Structural Parameter Optimization

(maximum iterations defined by it_max_structural)

If, optionally, Structural Parameter Optimization is invoked, iterations progress until convergence conditional on current process parameter values

end Outer Iteration

If posterior_cov_flag == 1
 Calculate posterior covariance
 posterior covariance is only calculated for the final parameter values