

INSTRUCCIONES DE INSTALACIÓN – SOFFIT DE ALUMINIO

Según NOA No. 23-1208.15 – Miami-Dade County

1. Instalación de J-channel:

1. Instalar J-channels en todo el perímetro e Instalar furring strips si es necesario.
2. Deben estar nivelados y alineados.
3. Fijación cada 12 pulgadas como máximo.

2. Corte de Paneles:

1. Medir distancia entre J-channels opuestos.
2. Cortar paneles dejando tolerancia de 1/8" a 1/4" para expansión.

3. Instalacion de soffit:

1. Insertar un extremo del panel dentro del J-channel.
2. Fijar mecánicamente cada 12 pulgadas
3. Mantener alineación correcta y holgura para expansión

4. INSPECCIÓN FINAL:

1. Verificar correcta fijación y alineacion de todos los paneles
2. Confirmar que no existan tornillos flojos
3. Confirmar cumplimiento total con el NOA

NOTA:

Documento técnico preparado conforme a los requisitos del NOA 23-1208.15

INSTALLATION INSTRUCTIONS – ALUMINUM SOFFIT

According to NOA No. 23-1208.15 – Miami-Dade County.

1. J-channel installation:

1. Install J-channel around the perimeter and Install furring strips if necessary.
2. They must be level and aligned
3. Fixation every 12 inches maximum.

2. Panel Cutting:

1. Measure distance between opposite channels.
2. Cut panels leaving 1/8" to 1/4" tolerance for expansion.

3. Installation of Soffit panels

1. Insert one end of the panel into the J-channel.
2. Mechanically fasten every 12 inches
3. Maintain correct alignment and clearance for expansion

4. FINAL INSPECTION:

1. Verify the correct attachment and alignment of all panels.
2. Confirm that there are no loose screws
3. Confirm full compliance with the NOA

NOTA:

Technical document prepared in accordance with the requirements of standard NOA 23-1208.15