9 **Battery Pack Replacement**

9

Each of the three battery packs are located in the positions shown in fig. 9-1 "Locations of the Battery and Multi-port Connector" with the multiport connector connectors.

When the battery alarm message is shown on the programming pendant, replace the battery pack in accordance with the following two methods. Perform the replacement by referring to chapter 2 "Notes for Maintenance".

Cover mounting bolt M4 (length:14 mm)(4 bolts) Tightening torque: 1.4 N·m

Fig. 9-1: Locations of the Battery and Multi-port Connector

