
START-UP GUIDE


Bobcat E20 compact excavator

Excavator 017 · EXCAVATOR-017 · Northridge Rentals (demo)

Review draft
Not yet approved for use



1 Call before you dig
Call 811 before you dig. Watch for holes, drop-offs and soft ground.




2 Walk around first
Walk around before you start: leaks, broken or damaged parts. Report anything.

Not drawn yet
Waiting on the manufacturer's manual.


3 Belt on, controls neutral
Belt on. Levers and controls in neutral. Start only from the seat.

Not drawn yet
Waiting on the manufacturer's manual.

4 Levers away: toward the blade
Levers pushed away = travel toward the blade. Check where the blade is before you move.



5 Slope limits
Across or up: 15 degrees or less. Down or backing up: 25 degrees or less. No swinging loads on a slope.



6 Keep people clear
Keep people out of the swing area. Never lift over anyone. No riders.

Not drawn yet
Frame 4 needs OMM 7255004; frames 1-3 are sourced.

7 Leaving the machine
1 Bucket on the ground. 2 Shut down. 3 Key out. 4 Console up.

Not drawn yet
Waiting on the manufacturer's manual.

8 Loading for transport
Heavy end uphill. Slew lock on. Chain it down at the tie-down points.

NEVER

- Never carry riders.
- Never operate the controls from the ground.
- Keep hands and feet inside the operator's area while the machine is on.
- Never smoke while fueling.

Full manual: Bobcat Company, E20 Compact Excavator Operation & Maintenance Manual (https://shop.bobcat.com/ca/e20-excavator-operation-and-maintenance-digital-manual-7255004enuspdf), sold by the manufacturer.

This guide shows key steps from the manufacturer's documents (Rent It Safely: Safety Rules for Bobcat Compact Excavators (B-1699); Service Schedule: E19, E20 Compact Excavator (SS EXC E19 E20-0315)). It does not replace them. Original artwork by Mulemark. Questions: use Request Support on the equipment page.