

CAUTION / INFORMATION Make sure no obstacles are in the desk's movement path and your cords are the appropriate length to accommodate the change in height. Keep children away from the desk's electronical components (i.e. control switch, power cord, etc.). There is a risk of injury and electric shock. Keep all electrical components away from liquids. Do NOT sit or stand on the desk frame or go under the desk frame when in motion. Do NOT place any objects taller than 25" underneath the desk. Do NOT open or take apart any of the components: leg, control, motor, etc. There is a risk of injury and electric shock. Do NOT reset the motor without proper instruction. This product is designed with a duty cycle of 4 min on, 15 min off. USE/ LIABILITY

This automatic height adjustable desk has an electric motor and is designed for use in dry work areas only.

The desk height is adjustable which allows you to set your ideal ergonomial height in the office or at home,

Page 1

IMPORTANT NOTE

assembled (Exception: leg & foot)

Do NOT fully tighten screws until the product is fully











