docs.qmk.fm /

Keycodes Overview



When defining a keymap each key needs a valid key definition. This page documents the symbols that correspond to keycodes that are available to you in QMK.

This is a reference only. Each group of keys links to the page documenting their functionality in more detail.

Basic Keycodes

See also: Basic Keycodes

| Key | Aliases | Description | Windo | ws macO | S Linux ¹ |
|----------------|----------|---|----------|----------|----------------------|
| KC_NO | XXXXXXX | Ignore this key (NOOP) | N/A | N/A | N/A |
| KC_TRANSPARENT | KC_TRNS, | Use the next lowest non- transparent key | N/A | N/A | N/A |
| KC_A | | a and A | ✓ | ✓ | ✓ |
| KC_B | | ь and в | ✓ | ✓ | ✓ |
| KC_C | | c and c | ✓ | ✓ | ✓ |
| KC_D | | d and D | ✓ | ✓ | ✓ |
| KC_E | | e and E | ✓ | ✓ | ✓ |
| KC_F | | f and F | ✓ | ✓ | ✓ |
| KC_G | | g and G | ✓ | ✓ | ✓ |
| KC_H | | h and н | ✓ | ✓ | ✓ |
| KC_I | | i and I | ✓ | ✓ | ✓ |
| KC_J | | j and J | ✓ | ✓ | ✓ |
| KC_K | | к and к | ✓ | ✓ | ✓ |
| KC_L | | ı and ı | ✓ | ✓ | ✓ |
| KC_M | | \mathtt{m} and \mathtt{M} | ✓ | ✓ | ✓ |
| KC_N | | n and \mathtt{N} | ✓ | ✓ | ✓ |
| KC_O | | ∘ and ∘ | ✓ | ~ | ✓ |
| KC_P | | p and P | ✓ | ~ | ✓ |

| Key | Aliases | Description | Windo | ows mac(| OS Linux ¹ |
|------------------|---------|-------------------------------------|----------|----------|-----------------------|
| KC_Q | | q and Q | ✓ | ~ | ✓ |
| KC_R | | r and R | ✓ | ✓ | ✓ |
| KC_S | | s and s | ✓ | ✓ | ✓ |
| KC_T | | t and T | ✓ | ✓ | ✓ |
| KC_U | | ս and Մ | ✓ | ✓ | ✓ |
| KC_V | | $_{	ext{v}}$ and $_{	ext{v}}$ | ✓ | ✓ | ✓ |
| KC_W | | $_{\mathtt{W}}$ and $_{\mathtt{W}}$ | ✓ | ✓ | ✓ |
| KC_X | | x and x | ✓ | ✓ | ✓ |
| KC_Y | | $_{ m Y}$ and $_{ m Y}$ | ✓ | ✓ | ✓ |
| KC_Z | | z and z | ✓ | ✓ | ✓ |
| KC_1 | | 1 and ! | ✓ | ✓ | ✓ |
| KC_2 | | 2 and @ | ✓ | ✓ | ✓ |
| KC_3 | | 3 and # | ✓ | ✓ | ✓ |
| KC_4 | | 4 and \$ | ✓ | ✓ | ✓ |
| KC_5 | | 5 and % | ✓ | ✓ | ✓ |
| KC_6 | | 6 and ^ | ✓ | ✓ | ✓ |
| KC_7 | | 7 and & | ✓ | ✓ | ✓ |
| KC_8 | | 8 and * | ✓ | ✓ | ✓ |
| KC_9 | | 9 and (| ✓ | ✓ | ✓ |
| KC_0 | | o and) | ✓ | ✓ | ✓ |
| KC_ENTER | KC_ENT | Return (Enter) | ✓ | ✓ | ✓ |
| KC_ESCAPE | KC_ESC | Escape | ✓ | ✓ | ✓ |
| KC_BACKSPACE | KC_BSPC | Delete (Backspace) | ✓ | ✓ | ✓ |
| KC_TAB | | Tab | ✓ | ✓ | ✓ |
| KC_SPACE | KC_SPC | Spacebar | ✓ | ✓ | ✓ |
| KC_MINUS | KC_MINS | - and _ | ✓ | ✓ | ✓ |
| KC_EQUAL | KC_EQL | = and + | ✓ | ✓ | ✓ |
| KC_LEFT_BRACKET | KC_LBRC | [and { | ✓ | ✓ | ✓ |
| KC_RIGHT_BRACKET | KC_RBRC |] and } | ✓ | ✓ | ✓ |
| KC_BACKSLASH | KC_BSLS | ∖ and ∣ | ✓ | ✓ | ✓ |
| KC_NONUS_HASH | KC_NUHS | Non-US # and ~ | ✓ | ✓ | ✓ |
| KC_SEMICOLON | KC_SCLN | ; and : | ✓ | ✓ | ✓ |
| KC_QUOTE | KC_QUOT | ¹ and " | ✓ | ✓ | ✓ |
| KC_GRAVE | KC_GRV | ` and ~ | ✓ | ✓ | ✓ |
| KC_COMMA | KC_COMM | , and < | ✓ | ✓ | ✓ |
| KC_DOT | | . and > | ✓ | ✓ | ✓ |
| KC_SLASH | KC_SLSH | / and ? | ✓ | ~ | ✓ |
| KC_CAPS_LOCK | KC_CAPS | Caps Lock | ✓ | ~ | ✓ |
| KC_F1 | | F1 | ✓ | ~ | ✓ |
| KC_F2 | | F2 | ✓ | ~ | ✓ |
| KC_F3 | | F3 | ✓ | ✓ | ✓ |

| Key | Aliases | Description | Windows | macOS | Linux ¹ |
|-----------------|-----------------------------|--------------------------------------|----------|-----------------------|--------------------|
| KC_F4 | | F4 | ✓ | / | ✓ |
| KC_F5 | | F5 | ✓ | / | ✓ |
| KC_F6 | | F6 | ✓ | ✓ | ✓ |
| KC_F7 | | F7 | ✓ | ✓ | ✓ |
| KC_F8 | | F8 | ✓ | ✓ | ✓ |
| KC_F9 | | F9 | ✓ | ✓ | ✓ |
| KC_F10 | | F10 | ✓ | ✓ | ✓ |
| KC_F11 | | F11 | ✓ | ✓ | ✓ |
| KC_F12 | | F12 | ✓ | ✓ | ✓ |
| KC_PRINT_SCREEN | KC_PSCR | Print Screen | ✓ | ~ ² | ✓ |
| KC_SCROLL_LOCK | KC_SCRL, KC_BRMD | Scroll Lock, Brightness Down (macOS) | • | ~ ² | • |
| KC_PAUSE | KC_PAUS, KC_BRK, KC_BRMU | Pause, Brightness Up (macOS) | ✓ | ~ ² | • |
| KC_INSERT | KC_INS | Insert | ✓ | | ✓ |
| KC_HOME | | Home | ✓ | ✓ | ✓ |
| KC_PAGE_UP | KC_PGUP | Page Up | ✓ | ✓ | ✓ |
| KC_DELETE | KC_DEL | Forward Delete | ✓ | ✓ | ✓ |
| KC_END | | End | ✓ | ✓ | ✓ |
| KC_PAGE_DOWN | KC_PGDN | Page Down | ✓ | ✓ | ✓ |
| KC_RIGHT | KC_RGHT | Right Arrow | ✓ | ✓ | ✓ |
| KC_LEFT | | Left Arrow | ✓ | ✓ | ✓ |
| KC_DOWN | | Down Arrow | ✓ | ✓ | ✓ |
| KC_UP | | Up Arrow | ✓ | ✓ | ✓ |
| KC_NUM_LOCK | KC_NUM | Keypad Num Lock and Clear | ✓ | ✓ | ✓ |
| KC_KP_SLASH | KC_PSLS | Keypad / | ✓ | ✓ | ✓ |
| KC_KP_ASTERISK | KC_PAST | Keypad ∗ | ✓ | ✓ | ✓ |
| KC_KP_MINUS | KC_PMNS | Keypad - | ✓ | ✓ | ✓ |
| KC_KP_PLUS | KC_PPLS | Keypad + | ✓ | ✓ | ✓ |
| KC_KP_ENTER | KC_PENT | Keypad Enter | ✓ | ✓ | ✓ |
| KC_KP_1 | KC_P1 | Keypad 1 and End | ✓ | ✓ | ✓ |
| KC_KP_2 | KC_P2 | Keypad 2 and Down Arrow | ✓ | ✓ | ✓ |
| KC_KP_3 | KC_P3 | Keypad 3 and Page Down | ✓ | ✓ | ✓ |
| KC_KP_4 | KC_P4 | Keypad 4 and Left Arrow | ✓ | ✓ | ✓ |
| KC_KP_5 | KC_P5 | Keypad 5 | ✓ | ~ | ✓ |
| KC_KP_6 | KC_P6 | Keypad 6 and Right Arrow | ✓ | ~ | ✓ |
| KC_KP_7 | KC_P7 | Keypad 7 and Home | ✓ | • | ✓ |
| KC_KP_8 | KC_P8 | Keypad ଃ and Up Arrow | ✓ | ✓ | ✓ |
| KC_KP_9 | KC_P9 | Keypad 9 and Page Up | ✓ | ✓ | ✓ |
| KC_KP_0 | KC_P0 | Keypad o and Insert | ✓ | ✓ | ✓ |
| KC_KP_DOT | KC_PDOT | Keypad . and Delete | • | ✓ | ✓ |

| Key | Aliases | Description | Window | s macOS | 3 Linux ¹ |
|------------------------|-----------|--|----------|------------|----------------------|
| KC_NONUS_BACKSLASH | KC_NUBS | Non-US ∖ and ⊦ | / | / | ✓ |
| KC_APPLICATION | KC_APP | Application (Windows Context Menu Key) | • | | • |
| KC_KB_POWER | | System Power | | √ 3 | ✓ |
| KC_KP_EQUAL | KC PEQL | Keypad = | / | / | ✓ |
| KC_F13 | | F13 | ✓ | ✓ | ✓ |
| KC_F14 | | F14 | ✓ | ✓ | ✓ |
| KC_F15 | | F15 | ✓ | ✓ | ✓ |
| KC_F16 | | F16 | ✓ | ✓ | ✓ |
| KC_F17 | | F17 | ✓ | ✓ | ✓ |
| KC_F18 | | F18 | ✓ | ✓ | ✓ |
| KC_F19 | | F19 | ✓ | ✓ | ✓ |
| KC_F20 | | F20 | ✓ | | ✓ |
| KC_F21 | | F21 | ✓ | | ✓ |
| KC_F22 | | F22 | ✓ | | ✓ |
| KC_F23 | | F23 | ✓ | | ✓ |
| KC_F24 | | F24 | ✓ | | ✓ |
| KC_EXECUTE | KC_EXEC | Execute | | | ✓ |
| KC_HELP | | Help | | | ✓ |
| KC_MENU | | Menu | | | ✓ |
| KC_SELECT | KC_SLCT | Select | | | ✓ |
| KC_STOP | | Stop | | | ✓ |
| KC_AGAIN | KC_AGIN | Again | | | ✓ |
| KC_UNDO | | Undo | | | ✓ |
| KC_CUT | | Cut | | | ✓ |
| KC_COPY | | Сору | | | ✓ |
| KC_PASTE | KC_PSTE | Paste | | | ✓ |
| KC_FIND | | Find | | | ✓ |
| KC_KB_MUTE | | Mute | | ✓ | ✓ |
| KC_KB_VOLUME_UP | | Volume Up | | ✓ | ✓ |
| KC_KB_VOLUME_DOWN | | Volume Down | | ✓ | ✓ |
| KC_LOCKING_CAPS_LOCK | KC_LCAP | Locking Caps Lock | ✓ | ✓ | |
| KC_LOCKING_NUM_LOCK | KC_LNUM | Locking Num Lock | ✓ | ✓ | |
| KC_LOCKING_SCROLL_LOCE | K KC_LSCR | Locking Scroll Lock | ✓ | ✓ | |
| KC_KP_COMMA | KC_PCMM | Keypad , | | | ✓ |
| KC_KP_EQUAL_AS400 | | Keypad = on AS/400 keyboards | 3 | | |
| KC_INTERNATIONAL_1 | KC_INT1 | International 1 | ✓ | | ✓ |
| KC_INTERNATIONAL_2 | KC_INT2 | International 2 | ✓ | | ✓ |
| KC_INTERNATIONAL_3 | KC_INT3 | International 3 | ✓ | | ✓ |
| KC_INTERNATIONAL_4 | KC_INT4 | International 4 | ✓ | | ✓ |
| KC_INTERNATIONAL_5 | KC_INT5 | International 5 | ✓ | | ✓ |

| Key | Aliases | Description | Windows | macOS | Linux ¹ |
|--------------------|---------------------------|--|----------|-----------------------|--------------------|
| KC_INTERNATIONAL_6 | KC_INT6 | International 6 | | | / |
| KC_INTERNATIONAL_7 | KC_INT7 | International 7 | | | |
| KC_INTERNATIONAL_8 | KC_INT8 | International 8 | | | |
| KC_INTERNATIONAL_9 | KC_INT9 | International 9 | | | |
| KC_LANGUAGE_1 | KC_LNG1 | Language 1 | | | ✓ |
| KC_LANGUAGE_2 | KC_LNG2 | Language 2 | | | ✓ |
| KC_LANGUAGE_3 | KC_LNG3 | Language 3 | | | ✓ |
| KC_LANGUAGE_4 | KC_LNG4 | Language 4 | | | ✓ |
| KC_LANGUAGE_5 | KC_LNG5 | Language 5 | | | ✓ |
| KC_LANGUAGE_6 | KC_LNG6 | Language 6 | | | |
| KC_LANGUAGE_7 | KC_LNG7 | Language 7 | | | |
| KC_LANGUAGE_8 | KC_LNG8 | Language 8 | | | |
| KC_LANGUAGE_9 | KC_LNG9 | Language 9 | | | |
| KC_ALTERNATE_ERASE | KC_ERAS | Alternate Erase | | | |
| KC_SYSTEM_REQUEST | KC_SYRQ | SysReq/Attention | | | |
| KC_CANCEL | KC_CNCL | Cancel | | | |
| KC_CLEAR | KC_CLR | Clear | | | ~ |
| KC_PRIOR | KC_PRIR | Prior | | | |
| KC_RETURN | KC_RETN | Return | | | |
| KC_SEPARATOR | KC_SEPR | Separator | | | |
| KC_OUT | | Out | | | |
| KC_OPER | | Oper | | | |
| KC_CLEAR_AGAIN | KC_CLAG | Clear/Again | | | |
| KC_CRSEL | KC_CRSL | CrSel/Props | | | |
| KC_EXSEL | KC_EXSL | ExSel | | | |
| KC_LEFT_CTRL | KC_LCTL | Left Control | ✓ | ✓ | ✓ |
| KC_LEFT_SHIFT | KC_LSFT | Left Shift | ✓ | ✓ | ✓ |
| KC_LEFT_ALT | KC_LALT, KC_LOPT | Left Alt (Option) | ✓ | ✓ | ✓ |
| KC_LEFT_GUI | KC_LGUI, KC_LCMD, KC_LWIN | Left GUI (Windows/Command/Meta key) | • | • | • |
| KC_RIGHT_CTRL | KC_RCTL | Right Control | ✓ | V | ~ |
| KC_RIGHT_SHIFT | KC_RSFT | Right Shift | • | ✓ | ✓ |
| KC_RIGHT_ALT | KC_RALT, KC_ROPT, KC_ALGR | Right Alt (Option/AltGr) | ✓ | • | • |
| KC_RIGHT_GUI | KC_RGUI, KC_RCMD, KC_RWIN | Right GUI (Windows/Command/Meta key) | • | • | • |
| KC_SYSTEM_POWER | KC_PWR | System Power Down | • | √ 3 | ✓ |
| KC_SYSTEM_SLEEP | KC_SLEP | System Sleep | • | ✓ 3 | ✓ |
| KC_SYSTEM_WAKE | KC_WAKE | System Wake | | √ 3 | ✓ |
| KC_AUDIO_MUTE | KC_MUTE | Mute | ✓ | ✓ | ✓ |
| KC_AUDIO_VOL_UP | KC_VOLU | Volume Up | • | ~ ⁴ | • |

| Key | Aliases | Description | Windo | ws macC | S Linux ¹ |
|-----------------------|---------|-----------------------------------|------------|-----------------------|----------------------|
| KC_AUDIO_VOL_DOWN | KC_VOLD | Volume Down | ✓ | ~ ⁴ | ✓ |
| KC_MEDIA_NEXT_TRACK | KC_MNXT | Next Track | ✓ | √ ⁵ | ✓ |
| KC_MEDIA_PREV_TRACK | KC_MPRV | Previous Track | ✓ | √ ⁵ | ~ |
| KC_MEDIA_STOP | KC_MSTP | Stop Track | ✓ | | ✓ |
| KC_MEDIA_PLAY_PAUSE | KC_MPLY | Play/Pause Track | ✓ | ~ | ✓ |
| KC_MEDIA_SELECT | KC_MSEL | Launch Media Player | ✓ | | ✓ |
| KC_MEDIA_EJECT | KC_EJCT | Eject | | ~ | ✓ |
| KC_MAIL | | Launch Mail | ✓ | | ✓ |
| KC_CALCULATOR | KC_CALC | Launch Calculator | ✓ | | ✓ |
| KC_MY_COMPUTER | KC_MYCM | Launch My Computer | ✓ | | ✓ |
| KC_WWW_SEARCH | KC_WSCH | Browser Search | ✓ | | ✓ |
| KC_WWW_HOME | KC_WHOM | Browser Home | ✓ | | ✓ |
| KC_WWW_BACK | KC_WBAK | Browser Back | ✓ | | ✓ |
| KC_WWW_FORWARD | KC_WFWD | Browser Forward | ✓ | | ✓ |
| KC_WWW_STOP | KC_WSTP | Browser Stop | ✓ | | ✓ |
| KC_WWW_REFRESH | KC_WREF | Browser Refresh | ✓ | | ✓ |
| KC_WWW_FAVORITES | KC_WFAV | Browser Favorites | ✓ | | ✓ |
| KC_MEDIA_FAST_FORWARD | KC_MFFD | Next Track | ✓ | √ ⁵ | ✓ |
| KC_MEDIA_REWIND | KC_MRWD | Previous Track | √ 6 | √ ⁵ | ~ |
| KC_BRIGHTNESS_UP | KC_BRIU | Brightness Up | ✓ | ~ | ✓ |
| KC_BRIGHTNESS_DOWN | KC_BRID | Brightness Down | ✓ | ✓ | ✓ |
| KC_CONTROL_PANEL | KC_CPNL | Open Control Panel | ✓ | | |
| KC_ASSISTANT | KC_ASST | Launch Context-Aware Assistant | ✓ | | |
| KC_MISSION_CONTROL | KC_MCTL | Open Mission Control | | ~ | |
| KC_LAUNCHPAD | KC_LPAD | Open Launchpad | | • | |

- 1. The Linux kernel HID driver recognizes nearly all keycodes, but the default bindings depend on the DE/WM.
- 2. Treated as F13-F15.
- 3. Must be held for about three seconds, and will display a prompt instead.
- 4. Holding Shift+Option allows for finer control of volume level.
- 5. Skips the entire track in iTunes when tapped, seeks within the current track when held.
- 6. WMP does not recognize the Rewind key, but both alter playback speed in VLC.

Quantum Keycodes

See also: Quantum Keycodes

| Key | Aliases | Description |
|-----------------|----------------|--|
| QK_BOOTLOADER | QK_BOOT | Put the keyboard into bootloader mode for flashing |
| QK_DEBUG_TOGGLE | DB_TOGG | Toggle debug mode |

| Key | Aliases | Description |
|-----------------|----------|--|
| QK_CLEAR_EEPRON | M EE_CLR | Reinitializes the keyboard's EEPROM (persistent memory) |
| QK_MAKE | | Sends qmk compile $-kb$ (keyboard) $-km$ (keymap), or qmk flash if shift is held. Puts keyboard into bootloader mode if shift & control are held |
| QK_REBOOT | QK_RBT | Resets the keyboard. Does not load the bootloader |

Audio Keys

See also: Audio

| Key | Aliases | Description |
|-------------------------|---------|--|
| QK_AUDIO_ON | AU_ON | Turns on Audio Feature |
| QK_AUDIO_OFF | AU_OFF | Turns off Audio Feature |
| QK_AUDIO_TOGGLE | AU_TOGG | Toggles Audio state |
| QK_AUDIO_CLICKY_TOGGLE | CK_TOGG | Toggles Audio clicky mode |
| QK_AUDIO_CLICKY_ON | CK_ON | Turns on Audio clicky mode |
| QK_AUDIO_CLICKY_OFF | CK_OFF | Turns on Audio clicky mode |
| QK_AUDIO_CLICKY_UP | CK_UP | Increases frequency of the clicks |
| QK_AUDIO_CLICKY_DOWN | CK_DOWN | Decreases frequency of the clicks |
| QK_AUDIO_CLICKY_RESET | CK_RST | Resets frequency to default |
| QK_MUSIC_ON | MU_ON | Turns on Music Mode |
| QK_MUSIC_OFF | MU_OFF | Turns off Music Mode |
| QK_MUSIC_TOGGLE | MU_TOGG | Toggles Music Mode |
| QK_MUSIC_MODE_NEXT | MU_NEXT | Cycles through the music modes |
| QK_AUDIO_VOICE_NEXT | AU_NEXT | Cycles through the audio voices |
| QK_AUDIO_VOICE_PREVIOUS | AU_PREV | Cycles through the audio voices in reverse |

Auto Shift

See also: Auto Shift

| Key | Aliases | Description |
|----------------------|---------|--|
| QK_AUTO_SHIFT_DOWN | AS_DOWN | Lower the Auto Shift timeout variable (down) |
| QK_AUTO_SHIFT_UP | AS_UP | Raise the Auto Shift timeout variable (up) |
| QK_AUTO_SHIFT_REPORT | AS_RPT | Report your current Auto Shift timeout value |
| QK_AUTO_SHIFT_ON | AS_ON | Turns on the Auto Shift Function |
| QK_AUTO_SHIFT_OFF | AS_OFF | Turns off the Auto Shift Function |
| QK_AUTO_SHIFT_TOGGLE | AS_TOGG | Toggles the state of the Auto Shift feature |

Autocorrect

See also: Autocorrect

| Key | Aliases | Description |
|-----|---------|-------------|
| | | |

| Key | Aliases | Description |
|-----------------------|---------|--|
| QK_AUTOCORRECT_ON | AC_ON | Turns on the Autocorrect feature. |
| QK_AUTOCORRECT_OFF | AC_OFF | Turns off the Autocorrect feature. |
| QK_AUTOCORRECT_TOGGLE | AC_TOGG | Toggles the status of the Autocorrect feature. |

Backlighting

See also: Backlighting

| Key | Aliases | Description |
|-------------------------------|---------|-------------------------------------|
| QK_BACKLIGHT_TOGGLE | BL_TOGG | Turn the backlight on or off |
| QK_BACKLIGHT_STEP | BL_STEP | Cycle through backlight levels |
| QK_BACKLIGHT_ON | BL_ON | Set the backlight to max brightness |
| QK_BACKLIGHT_OFF | BL_OFF | Turn the backlight off |
| QK_BACKLIGHT_UP | BL_UP | Increase the backlight level |
| QK_BACKLIGHT_DOWN | BL_DOWN | Decrease the backlight level |
| QK_BACKLIGHT_TOGGLE_BREATHING | BL_BRTG | Toggle backlight breathing |

Bluetooth

See also: Bluetooth

| Key | Aliases | Description |
|---------------------|---------|--|
| QK_OUTPUT_AUTO | OU_AUTO | Automatically switch between USB and Bluetooth |
| QK_OUTPUT_USB | OU_USB | USB only |
| QK_OUTPUT_BLUETOOTH | OU_BT | Bluetooth only |

Caps Word

See also: Caps Word

| | Key | | Ali | ases | Des | criptio | n |
|----------|--------|--------|-----|------|---------|---------|------|
| QK_CAPS_ | _WORD_ | TOGGLE | CW_ | TOGG | Toggles | Caps V | Vord |

Dynamic Macros

See also: Dynamic Macros

| Key | Aliases | Description |
|---------------------------------|---------|--|
| QK_DYNAMIC_MACRO_RECORD_START_1 | DM_REC1 | Start recording Macro 1 |
| QK_DYNAMIC_MACRO_RECORD_START_2 | DM_REC2 | Start recording Macro 2 |
| QK_DYNAMIC_MACRO_PLAY_1 | DM_PLY1 | Replay Macro 1 |
| QK_DYNAMIC_MACRO_PLAY_2 | DM_PLY2 | Replay Macro 2 |
| QK_DYNAMIC_MACRO_RECORD_STOP | DM_RSTP | Finish the macro that is currently being recorded. |

Grave Escape

See also: Grave Escape

Key Aliases Description

 ${\tt QK_GRAVE_ESCAPE\ QK_GESC\ Escape\ when\ pressed,\ `\ when\ Shift\ or\ GUI\ are\ held}$

Joystick

See also: Joystick

| Key | Aliases | Description |
|-----------------------|---------|-------------|
| QK_JOYSTICK_BUTTON_0 | JS_0 | Button 0 |
| QK_JOYSTICK_BUTTON_1 | JS_1 | Button 1 |
| QK_JOYSTICK_BUTTON_2 | JS_2 | Button 2 |
| QK_JOYSTICK_BUTTON_3 | JS_3 | Button 3 |
| QK_JOYSTICK_BUTTON_4 | JS_4 | Button 4 |
| QK_JOYSTICK_BUTTON_5 | JS_5 | Button 5 |
| QK_JOYSTICK_BUTTON_6 | JS_6 | Button 6 |
| QK_JOYSTICK_BUTTON_7 | JS_7 | Button 7 |
| QK_JOYSTICK_BUTTON_8 | JS_8 | Button 8 |
| QK_JOYSTICK_BUTTON_9 | JS_9 | Button 9 |
| QK_JOYSTICK_BUTTON_10 | JS_10 | Button 10 |
| QK_JOYSTICK_BUTTON_11 | JS_11 | Button 11 |
| QK_JOYSTICK_BUTTON_12 | JS_12 | Button 12 |
| QK_JOYSTICK_BUTTON_13 | JS_13 | Button 13 |
| QK_JOYSTICK_BUTTON_14 | JS_14 | Button 14 |
| QK_JOYSTICK_BUTTON_15 | JS_15 | Button 15 |
| QK_JOYSTICK_BUTTON_16 | JS_16 | Button 16 |
| QK_JOYSTICK_BUTTON_17 | JS_17 | Button 17 |
| QK_JOYSTICK_BUTTON_18 | JS_18 | Button 18 |
| QK_JOYSTICK_BUTTON_19 | JS_19 | Button 19 |
| QK_JOYSTICK_BUTTON_20 | JS_20 | Button 20 |
| QK_JOYSTICK_BUTTON_21 | JS_21 | Button 21 |
| QK_JOYSTICK_BUTTON_22 | JS_22 | Button 22 |
| QK_JOYSTICK_BUTTON_23 | JS_23 | Button 23 |
| QK_JOYSTICK_BUTTON_24 | JS_24 | Button 24 |
| QK_JOYSTICK_BUTTON_25 | JS_25 | Button 25 |
| QK_JOYSTICK_BUTTON_26 | JS_26 | Button 26 |
| QK_JOYSTICK_BUTTON_27 | JS_27 | Button 27 |
| QK_JOYSTICK_BUTTON_28 | JS_28 | Button 28 |
| QK_JOYSTICK_BUTTON_29 | JS_29 | Button 29 |
| QK_JOYSTICK_BUTTON_30 | JS_30 | Button 30 |

Key Aliases Description

QK JOYSTICK BUTTON 31 JS 31 Button 31

Key Lock

See also: Key Lock

Key Description

QK_LOCK Hold down the next key pressed, until the key is pressed again

Layer Switching

See also: Layer Switching

| Key | Description |
|------------------|--|
| DF(layer) | Set the base (default) layer |
| MO(layer) | Momentarily turn on layer when pressed (requires KC_TRNS on destination layer) |
| OSL(layer) | Momentarily activates layer until a key is pressed. See One Shot Keys for details. |
| LM(layer, mod) | Momentarily turn on layer (like MO) with mod active as well. Where mod is a mods_bit. Mods can be viewed here. Example Implementation: LM(LAYER_1, MOD_LALT) |
| LT(layer, kc) | Turn on layer when held, ke when tapped |
| TG(layer) | Toggle layer on or off |
| TO(layer) | Turns on layer and turns off all other layers, except the default layer |
| TT(layer) | Normally acts like MO unless it's tapped multiple times, which toggles layer on |

Leader Key

See also: Leader Key

Key Description

QK_LEAD Begins a leader sequence

Magic Keycodes

See also: Magic Keycodes

| Key | Aliases | Description |
|-----------------------------------|-----------------------|------------------------------|
| QK_MAGIC_SWAP_CONTROL_CAPS_LOCK | CL_SWAP Swap Caps | Lock and Left Control |
| QK_MAGIC_UNSWAP_CONTROL_CAPS_LOCK | CL_NORM Unswap Ca | ps Lock and Left Control |
| QK_MAGIC_TOGGLE_CONTROL_CAPS_LOCK | CL_TOGG Toggle Caps | s Lock and Left Control swap |
| QK_MAGIC_CAPS_LOCK_AS_CONTROL_ON | CL_CTRL Treat Caps | Lock as Control |
| QK_MAGIC_CAPS_LOCK_AS_CONTROL_OFF | CL_CAPS Stop treating | g Caps Lock as Control |
| QK_MAGIC_SWAP_ESCAPE_CAPS_LOCK | EC_SWAP Swap Caps | Lock and Escape |

| Key | Aliases | Description |
|-------------------------------------|---------|---|
| QK_MAGIC_UNSWAP_ESCAPE_CAPS_LOCK | EC_NORM | Unswap Caps Lock and Escape |
| QK_MAGIC_TOGGLE_ESCAPE_CAPS_LOCK | EC_TOGG | Toggle Caps Lock and Escape swap |
| QK_MAGIC_SWAP_LCTL_LGUI | CG_LSWP | Swap Left Control and GUI |
| QK_MAGIC_UNSWAP_LCTL_LGUI | CG_LNRM | Unswap Left Control and GUI |
| QK_MAGIC_SWAP_RCTL_RGUI | CG_RSWP | Swap Right Control and GUI |
| QK_MAGIC_UNSWAP_RCTL_RGUI | CG_RNRM | Unswap Right Control and GUI |
| QK_MAGIC_SWAP_CTL_GUI | CG_SWAP | Swap Control and GUI on both sides |
| QK_MAGIC_UNSWAP_CTL_GUI | CG_NORM | Unswap Control and GUI on both sides |
| QK_MAGIC_TOGGLE_CTL_GUI | CG_TOGG | Toggle Control and GUI swap on both sides |
| QK_MAGIC_SWAP_LALT_LGUI | AG_LSWP | Swap Left Alt and GUI |
| QK_MAGIC_UNSWAP_LALT_LGUI | AG_LNRM | Unswap Left Alt and GUI |
| QK_MAGIC_SWAP_RALT_RGUI | AG_RSWP | Swap Right Alt and GUI |
| QK_MAGIC_UNSWAP_RALT_RGUI | AG_RNRM | Unswap Right Alt and GUI |
| QK_MAGIC_SWAP_ALT_GUI | AG_SWAP | Swap Alt and GUI on both sides |
| QK_MAGIC_UNSWAP_ALT_GUI | AG_NORM | Unswap Alt and GUI on both sides |
| QK_MAGIC_TOGGLE_ALT_GUI | AG_TOGG | Toggle Alt and GUI swap on both sides |
| QK_MAGIC_GUI_OFF | GU_OFF | Disable the GUI keys |
| QK_MAGIC_GUI_ON | GU_ON | Enable the GUI keys |
| QK_MAGIC_TOGGLE_GUI | GU_TOGG | Toggles the status of the GUI keys |
| QK_MAGIC_SWAP_GRAVE_ESC | GE_SWAP | Swap ` and Escape |
| QK_MAGIC_UNSWAP_GRAVE_ESC | GE_NORM | Unswap ` and Escape |
| QK_MAGIC_SWAP_BACKSLASH_BACKSPACE | BS_SWAP | Swap \ and Backspace |
| QK_MAGIC_UNSWAP_BACKSLASH_BACKSPACE | BS_NORM | Unswap \ and Backspace |
| QK_MAGIC_TOGGLE_BACKSLASH_BACKSPACE | BS_TOGG | Toggle ∖ and Backspace swap state |
| QK_MAGIC_NKRO_ON | NK_ON | Enable N-key rollover |
| QK_MAGIC_NKRO_OFF | NK_OFF | Disable N-key rollover |
| QK_MAGIC_TOGGLE_NKRO | NK_TOGG | Toggle N-key rollover |
| QK_MAGIC_EE_HANDS_LEFT | EH_LEFT | Set the master half of a split keyboard as the left hand (for EE_HANDS) |
| QK_MAGIC_EE_HANDS_RIGHT | EH_RGHT | Set the master half of a split keyboard as the right hand (for $\texttt{EE_HANDS}$) |

MIDI

See also: MIDI

| Key | Aliases | Description |
|------------------------|--------------|---------------------|
| QK_MIDI_ON | MI_ON | Turn MIDI on |
| QK_MIDI_OFF | MI_OFF | Turn MIDI off |
| QK_MIDI_TOGGLE | MI_TOGG | Toggle MIDI enabled |
| QK_MIDI_NOTE_C_0 | MI_C | C octave 0 |
| QK MIDI NOTE C SHARP 0 | MI Cs, MI Db | C#/Db octave 0 |

| Key | Aliases | Description |
|------------------------|----------------|-------------------|
| QK_MIDI_NOTE_D_0 | MI_D | D octave 0 |
| QK_MIDI_NOTE_D_SHARP_0 | MI_Ds, MI_Eb | D#/Eb octave 0 |
| QK_MIDI_NOTE_E_0 | MI_E | E octave 0 |
| QK_MIDI_NOTE_F_0 | MI_F | F octave 0 |
| QK_MIDI_NOTE_F_SHARP_0 | MI_Fs, MI_Gb | F#/Gb octave 0 |
| QK_MIDI_NOTE_G_0 | MI_G | G octave 0 |
| QK_MIDI_NOTE_G_SHARP_0 | MI_Gs, MI_Ab | G # /A b octave 0 |
| QK_MIDI_NOTE_A_0 | MI_A | A octave 0 |
| QK_MIDI_NOTE_A_SHARP_0 | MI_As, MI_Bb | A # /B b octave 0 |
| QK_MIDI_NOTE_B_0 | MI_B | B octave 0 |
| QK_MIDI_NOTE_C_1 | MI_C1 | C octave 1 |
| QK_MIDI_NOTE_C_SHARP_1 | MI_Cs1, MI_Db1 | . C♯/D♭ octave 1 |
| QK_MIDI_NOTE_D_1 | MI_D1 | D octave 1 |
| QK_MIDI_NOTE_D_SHARP_1 | MI_Ds1, MI_Eb1 | . D♯/E♭ octave 1 |
| QK_MIDI_NOTE_E_1 | MI_E1 | E octave 1 |
| QK_MIDI_NOTE_F_1 | MI_F1 | F octave 1 |
| QK_MIDI_NOTE_F_SHARP_1 | MI_Fs1, MI_Gb1 | F♯/G♭ octave 1 |
| QK_MIDI_NOTE_G_1 | MI_G1 | G octave 1 |
| QK_MIDI_NOTE_G_SHARP_1 | MI_Gs1, MI_Ab1 | G # /A b octave 1 |
| QK_MIDI_NOTE_A_1 | MI_A1 | A octave 1 |
| QK_MIDI_NOTE_A_SHARP_1 | MI_As1, MI_Bb1 | . A♯/B♭ octave 1 |
| QK_MIDI_NOTE_B_1 | MI_B1 | B octave 1 |
| QK_MIDI_NOTE_C_2 | MI_C2 | C octave 2 |
| QK_MIDI_NOTE_C_SHARP_2 | MI_Cs2, MI_Db2 | C#/Db octave 2 |
| QK_MIDI_NOTE_D_2 | MI_D2 | D octave 2 |
| QK_MIDI_NOTE_D_SHARP_2 | MI_Ds2, MI_Eb2 | D#/Eb octave 2 |
| QK_MIDI_NOTE_E_2 | MI_E2 | E octave 2 |
| QK_MIDI_NOTE_F_2 | MI_F2 | F octave 2 |
| QK_MIDI_NOTE_F_SHARP_2 | MI_Fs2, MI_Gb2 | F # /G b octave 2 |
| QK_MIDI_NOTE_G_2 | MI_G2 | G octave 2 |
| QK_MIDI_NOTE_G_SHARP_2 | MI_Gs2, MI_Ab2 | G # /A b octave 2 |
| QK_MIDI_NOTE_A_2 | MI_A2 | A octave 2 |
| QK_MIDI_NOTE_A_SHARP_2 | MI_As2, MI_Bb2 | A # /B b octave 2 |
| QK_MIDI_NOTE_B_2 | MI_B2 | B octave 2 |
| QK_MIDI_NOTE_C_3 | MI_C3 | C octave 3 |
| QK_MIDI_NOTE_C_SHARP_3 | MI_Cs3, MI_Db3 | C#/Db octave 3 |
| QK_MIDI_NOTE_D_3 | MI_D3 | D octave 3 |
| QK_MIDI_NOTE_D_SHARP_3 | MI_Ds3, MI_Eb3 | D#/Eb octave 3 |
| QK_MIDI_NOTE_E_3 | MI_E3 | E octave 3 |

| Key | Aliases | Description |
|------------------------|----------------|---------------------------------|
| QK_MIDI_NOTE_F_3 | MI_F3 | F octave 3 |
| QK_MIDI_NOTE_F_SHARP_3 | MI_Fs3, MI_Gb3 | F # /G b octave 3 |
| QK_MIDI_NOTE_G_3 | MI_G3 | G octave 3 |
| QK_MIDI_NOTE_G_SHARP_3 | MI_Gs3, MI_Ab3 | G # /A b octave 3 |
| QK_MIDI_NOTE_A_3 | MI_A3 | A octave 3 |
| QK_MIDI_NOTE_A_SHARP_3 | MI_As3, MI_Bb3 | A # /B b octave 3 |
| QK_MIDI_NOTE_B_3 | MI_B3 | B octave 3 |
| QK_MIDI_NOTE_C_4 | MI_C4 | C octave 4 |
| QK_MIDI_NOTE_C_SHARP_4 | MI_Cs4, MI_Db4 | C#/Db octave 4 |
| QK_MIDI_NOTE_D_4 | MI_D4 | D octave 4 |
| QK_MIDI_NOTE_D_SHARP_4 | MI_Ds4, MI_Eb4 | D#/Eb octave 4 |
| QK_MIDI_NOTE_E_4 | MI_E4 | E octave 4 |
| QK_MIDI_NOTE_F_4 | MI_F4 | F octave 4 |
| QK_MIDI_NOTE_F_SHARP_4 | MI_Fs4, MI_Gb4 | F#/Gb octave 4 |
| QK_MIDI_NOTE_G_4 | MI_G4 | G octave 4 |
| QK_MIDI_NOTE_G_SHARP_4 | MI_Gs4, MI_Ab4 | G # /A b octave 4 |
| QK_MIDI_NOTE_A_4 | MI_A4 | A octave 4 |
| QK_MIDI_NOTE_A_SHARP_4 | MI_As4, MI_Bb4 | A # /B b octave 4 |
| QK_MIDI_NOTE_B_4 | MI_B4 | B octave 4 |
| QK_MIDI_NOTE_C_5 | MI_C5 | C octave 5 |
| QK_MIDI_NOTE_C_SHARP_5 | MI_Cs5, MI_Db5 | C#/Db octave 5 |
| QK_MIDI_NOTE_D_5 | MI_D5 | D octave 5 |
| QK_MIDI_NOTE_D_SHARP_5 | MI_Ds5, MI_Eb5 | D#/Eb octave 5 |
| QK_MIDI_NOTE_E_5 | MI_E5 | E octave 5 |
| QK_MIDI_NOTE_F_5 | MI_F5 | F octave 5 |
| QK_MIDI_NOTE_F_SHARP_5 | MI_Fs5, MI_Gb5 | F#/Gb octave 5 |
| QK_MIDI_NOTE_G_5 | MI_G5 | G octave 5 |
| QK_MIDI_NOTE_G_SHARP_5 | MI_Gs5, MI_Ab5 | G#/Ab octave 5 |
| QK_MIDI_NOTE_A_5 | MI_A5 | A octave 5 |
| QK_MIDI_NOTE_A_SHARP_5 | MI_As5, MI_Bb5 | A # /B b octave 5 |
| QK_MIDI_NOTE_B_5 | MI_B5 | B octave 5 |
| QK_MIDI_OCTAVE_N2 | MI_OCN2 | Set octave to -2 |
| QK_MIDI_OCTAVE_N1 | MI_OCN1 | |
| QK_MIDI_OCTAVE_0 | MI_OCO | Set octave to 0 |
| QK_MIDI_OCTAVE_1 | MI_OC1 | Set octave to 1 |
| QK_MIDI_OCTAVE_2 | MI_OC2 | |
| QK_MIDI_OCTAVE_3 | MI_OC3 | |
| QK_MIDI_OCTAVE_4 | MI_OC4 | |
| QK_MIDI_OCTAVE_5 | MI_OC5 | Set octave to 5 Set octave to 6 |
| QK_MIDI_OCTAVE_6 | MI_OC6 | Jei Uciave IU U |

| Key | Aliases | Description |
|------------------------|---------|-----------------------------------|
| QK_MIDI_OCTAVE_7 | MI_OC7 | Set octave to 7 |
| QK_MIDI_OCTAVE_DOWN | MI_OCTD | Move down an octave |
| QK_MIDI_OCTAVE_UP | MI_OCTU | Move up an octave |
| QK_MIDI_TRANSPOSE_N6 | MI_TRN6 | Set transposition to -6 semitones |
| QK_MIDI_TRANSPOSE_N5 | MI_TRN5 | Set transposition to -5 semitones |
| QK_MIDI_TRANSPOSE_N4 | MI_TRN4 | Set transposition to -4 semitones |
| QK_MIDI_TRANSPOSE_N3 | MI_TRN3 | Set transposition to -3 semitones |
| QK_MIDI_TRANSPOSE_N2 | MI_TRN2 | Set transposition to -2 semitones |
| QK_MIDI_TRANSPOSE_N1 | MI_TRN1 | Set transposition to -1 semitone |
| QK_MIDI_TRANSPOSE_0 | MI_TRO | No transposition |
| QK_MIDI_TRANSPOSE_1 | MI_TR1 | Set transposition to +1 semitone |
| QK_MIDI_TRANSPOSE_2 | MI_TR2 | Set transposition to +2 semitones |
| QK_MIDI_TRANSPOSE_3 | MI_TR3 | Set transposition to +3 semitones |
| QK_MIDI_TRANSPOSE_4 | MI_TR4 | Set transposition to +4 semitones |
| QK_MIDI_TRANSPOSE_5 | MI_TR5 | Set transposition to +5 semitones |
| QK_MIDI_TRANSPOSE_6 | MI_TR6 | Set transposition to +6 semitones |
| QK_MIDI_TRANSPOSE_DOWN | MI_TRSD | Decrease transposition |
| QK_MIDI_TRANSPOSE_UP | MI_TRSU | Increase transposition |
| QK_MIDI_VELOCITY_0 | MI_VLO | Set velocity to 0 |
| QK_MIDI_VELOCITY_1 | MI_VL1 | Set velocity to 12 |
| QK_MIDI_VELOCITY_2 | MI_VL2 | Set velocity to 25 |
| QK_MIDI_VELOCITY_3 | MI_VL3 | Set velocity to 38 |
| QK_MIDI_VELOCITY_4 | MI_VL4 | Set velocity to 51 |
| QK_MIDI_VELOCITY_5 | MI_VL5 | Set velocity to 64 |
| QK_MIDI_VELOCITY_6 | MI_VL6 | Set velocity to 76 |
| QK_MIDI_VELOCITY_7 | MI_VL7 | Set velocity to 89 |
| QK_MIDI_VELOCITY_8 | MI_VL8 | Set velocity to 102 |
| QK_MIDI_VELOCITY_9 | MI_VL9 | Set velocity to 114 |
| QK_MIDI_VELOCITY_10 | MI_VL10 | Set velocity to 127 |
| QK_MIDI_VELOCITY_DOWN | MI_VELD | Decrease velocity |
| QK_MIDI_VELOCITY_UP | MI_VELU | Increase velocity |
| QK_MIDI_CHANNEL_1 | MI_CH1 | Set channel to 1 |
| QK_MIDI_CHANNEL_2 | MI_CH2 | Set channel to 2 |
| QK_MIDI_CHANNEL_3 | MI_CH3 | Set channel to 3 |
| QK_MIDI_CHANNEL_4 | MI_CH4 | Set channel to 4 |
| QK_MIDI_CHANNEL_5 | MI_CH5 | Set channel to 5 |
| QK_MIDI_CHANNEL_6 | MI_CH6 | Set channel to 6 |
| QK_MIDI_CHANNEL_7 | MI_CH7 | Set channel to 7 |
| QK_MIDI_CHANNEL_8 | MI_CH8 | Set channel to 8 |
| QK_MIDI_CHANNEL_9 | MI_CH9 | Set channel to 9 |
| QK_MIDI_CHANNEL_10 | MI_CH10 | Set channel to 10 |

| Aliases | Description |
|---------|---|
| MI_CH11 | Set channel to 11 |
| MI_CH12 | Set channel to 12 |
| MI_CH13 | Set channel to 13 |
| MI_CH14 | Set channel to 14 |
| MI_CH15 | Set channel to 15 |
| MI_CH16 | Set channel to 16 |
| MI_CHND | Decrease channel |
| MI_CHNU | Increase channel |
| MI_AOFF | Stop all notes |
| MI_SUST | Sustain |
| MI_PORT | Portmento |
| MI_SOST | Sostenuto |
| MI_SOFT | Soft Pedal |
| MI_LEG | Legato |
| MI_MOD | Modulation |
| MI_MODD | Decrease modulation speed |
| MI_MODU | Increase modulation speed |
| MI_BNDD | Bend pitch down |
| MI_BNDU | Bend pitch up |
| | MI_CH11 MI_CH12 MI_CH13 MI_CH14 MI_CH15 MI_CH16 MI_CHND MI_CHNU MI_AOFF MI_SUST MI_PORT MI_SOST MI_SOFT MI_SOFT MI_LEG MI_MOD MI_MODD MI_MODD MI_MODU MI_BNDD |

Mouse Keys

See also: Mouse Keys

| Key | Aliases | Description |
|----------------|----------------|-----------------------------|
| KC_MS_UP | KC_MS_U | Mouse Cursor Up |
| KC_MS_DOWN | KC_MS_D | Mouse Cursor Down |
| KC_MS_LEFT | KC_MS_L | Mouse Cursor Left |
| KC_MS_RIGHT | KC_MS_R | Mouse Cursor Right |
| KC_MS_BTN1 | KC_BTN1 | Mouse Button 1 |
| KC_MS_BTN2 | KC_BTN2 | Mouse Button 2 |
| KC_MS_BTN3 | KC_BTN3 | Mouse Button 3 |
| KC_MS_BTN4 | KC_BTN4 | Mouse Button 4 |
| KC_MS_BTN5 | KC_BTN5 | Mouse Button 5 |
| KC_MS_WH_UP | KC_WH_U | Mouse Wheel Up |
| KC_MS_WH_DOWN | KC_WH_D | Mouse Wheel Down |
| KC_MS_WH_LEFT | KC_WH_L | Mouse Wheel Left |
| KC_MS_WH_RIGHT | KC_WH_R | Mouse Wheel Right |
| KC_MS_ACCEL0 | KC_ACL0 | Set mouse acceleration to 0 |
| KC_MS_ACCEL1 | KC_ACL1 | Set mouse acceleration to 1 |
| KC_MS_ACCEL2 | KC_ACL2 | Set mouse acceleration to 2 |

Modifiers

See also: Modifier Keys

| Key | Aliases | Description |
|----------|------------------------------|---|
| LCTL(kc) | C(kc) | Hold Left Control and press kc |
| LSFT(kc) | S(kc) | Hold Left Shift and press kc |
| LALT(kc) | A(kc), LOPT(kc) | Hold Left Alt and press kc |
| LGUI(kc) | G(kc), LCMD(kc), LWIN(kc) | Hold Left GUI and press kc |
| RCTL(kc) | | Hold Right Control and press kc |
| RSFT(kc) | | Hold Right Shift and press kc |
| RALT(kc) | ROPT(kc), ALGR(kc) | Hold Right Alt (AltGr) and press kc |
| RGUI(kc) | RCMD(kc), RWIN(kc) | Hold Right GUI and press kc |
| LSG(kc) | SGUI(kc), SCMD(kc), SWIN(kc) | Hold Left Shift and Left GUI and press kc |
| LAG(kc) | | Hold Left Alt and Left GUI and press kc |
| RSG(kc) | | Hold Right Shift and Right GUI and press kc |
| RAG(kc) | | Hold Right Alt and Right GUI and press kc |
| LCA(kc) | | Hold Left Control and Alt and press kc |
| LSA(kc) | | Hold Left Shift and Left Alt and press kc |
| RSA(kc) | SAGR(kc) | Hold Right Shift and Right Alt (AltGr) and press ${\tt kc}$ |
| RCS(kc) | | Hold Right Control and Right Shift and press kc |
| LCAG(kc) | | Hold Left Control, Alt and GUI and press kc |
| MEH(kc) | | Hold Left Control, Shift and Alt and press kc |
| HYPR(kc) | | Hold Left Control, Shift, Alt and GUI and press ${\tt kc}$ |
| KC_MEH | | Left Control, Shift and Alt |
| KC_HYPR | | Left Control, Shift, Alt and GUI |

Mod-Tap Keys

See also: Mod-Tap

| Key | Aliases | Description |
|----------------|--|--|
| MT(mod, kc) | | mod when held, ke when tapped |
| LCTL_T(kc) | CTL_T(kc) | Left Control when held, kc when tapped |
| LSFT_T(kc) | SFT_T(kc) | Left Shift when held, kc when tapped |
| | LOPT_T(kc), ALT_T(kc), OPT_T(kc) | Left Alt when held, kc when tapped |
| LGUI_T(kc) | <pre>LCMD_T(kc), LWIN_T(kc), GUI_T(kc), CMD_T(kc), WIN_T(kc)</pre> | Left GUI when held, ke when tapped |
| RCTL_T(kc) | | Right Control when held, kc when tapped |
| RSFT_T(kc) | | Right Shift when held, kc when tapped |
| RALT_T(kc) | ROPT_T(kc), ALGR_T(kc) | Right Alt (AltGr) when held, kc when tapped |
| RGUI_T(kc) | RCMD_T(kc), RWIN_T(kc) | Right GUI when held, kc when tapped |
| LSG_T(kc) | SGUI_T(kc), SCMD_T(kc), SWIN_T(kc) | Left Shift and GUI when held, kc when tapped |

| Key | Aliases | Description |
|----------------------|---------|---|
| LAG_T(kc) | | Left Alt and GUI when held, kc when tapped |
| RSG_T(kc) | | Right Shift and GUI when held, kc when tapped |
| RAG_T(kc) | | Right Alt and GUI when held, kc when tapped |
| LCA_T(kc) | | Left Control and Alt when held, kc when tapped |
| LSA_T(kc) | | Left Shift and Left Alt when held, kc when tapped |
| RSA_T(kc) SAGR_T(kc) |) | Right Shift and Right Alt (AltGr) when held, kc when tapped |
| RCS_T(kc) | | Right Control and Right Shift when held, ke when tapped |
| LCAG_T(kc) | | Left Control, Alt and GUI when held, kc when tapped |
| RCAG_T(kc) | | Right Control, Alt and GUI when held, ke when tapped |
| C_S_T(kc) | | Left Control and Shift when held, kc when tapped |
| MEH_T(kc) | | Left Control, Shift and Alt when held, kc when tapped |
| HYPR_T(kc) ALL_T(kc) | | Left Control, Shift, Alt and GUI when held, kc when tapped - more info here |

Tapping Term Keys

See also: Dynamic Tapping Term

| Key | Aliases | Description |
|-------------------------------|----------------|---|
| QK_DYNAMIC_TAPPING_TERM_PRINT | DT_PRNT | Types the current tapping term, in milliseconds |
| QK_DYNAMIC_TAPPING_TERM_UP | DT_UP | Increases the current tapping term by DYNAMIC_TAPPING_TERM_INCREMENTMS (5ms by default) |
| QK_DYNAMIC_TAPPING_TERM_DOWN | | Decreases the current tapping term by DYNAMIC TAPPING TERM INCREMENTMS (5ms by default) |

RGB Lighting

See also: RGB Lighting

| Key | Aliases | Description |
|------------------|----------|--|
| RGB_TOG | | Toggle RGB lighting on or off |
| RGB_MODE_FORWARD | RGB_MOD | Cycle through modes, reverse direction when Shift is held |
| RGB_MODE_REVERSE | RGB_RMOD | Cycle through modes in reverse, forward direction when Shift is held |
| RGB_HUI | | Increase hue, decrease hue when Shift is held |
| RGB_HUD | | Decrease hue, increase hue when Shift is held |
| RGB_SAI | | Increase saturation, decrease saturation when Shift is held |
| RGB_SAD | | Decrease saturation, increase saturation when Shift is held |
| RGB_VAI | | Increase value (brightness), decrease value when Shift is held |

| Key | Aliases | Description |
|-------------------|----------|--|
| RGB_VAD | | Decrease value (brightness), increase value when Shift is held |
| RGB_MODE_PLAIN | RGB_M_P | Static (no animation) mode |
| RGB_MODE_BREATHE | RGB_M_B | Breathing animation mode |
| RGB_MODE_RAINBOW | RGB_M_R | Rainbow animation mode |
| RGB_MODE_SWIRL | RGB_M_SW | Swirl animation mode |
| RGB_MODE_SNAKE | RGB_M_SN | Snake animation mode |
| RGB_MODE_KNIGHT | RGB_M_K | "Knight Rider" animation mode |
| RGB_MODE_XMAS | RGB_M_X | Christmas animation mode |
| RGB_MODE_GRADIENT | RGB_M_G | Static gradient animation mode |
| RGB_MODE_RGBTEST | RGB_M_T | Red, Green, Blue test animation mode |

RGB Matrix Lighting

See also: RGB Matrix Lighting

| Key | Aliases | Description |
|-----------------|------------|--|
| RGB_TOG | | Toggle RGB lighting on or off |
| RGB_MODE_FORWAR | D RGB_MOD | Cycle through modes, reverse direction when Shift is held |
| RGB_MODE_REVERS | E RGB_RMOD | Cycle through modes in reverse, forward direction when Shift is held |
| RGB_HUI | | Increase hue, decrease hue when Shift is held |
| RGB_HUD | | Decrease hue, increase hue when Shift is held |
| RGB_SAI | | Increase saturation, decrease saturation when Shift is held |
| RGB_SAD | | Decrease saturation, increase saturation when Shift is held |
| RGB_VAI | | Increase value (brightness), decrease value when Shift is held |
| RGB_VAD | | Decrease value (brightness), increase value when Shift is held |
| RGB_SPI | | Increase effect speed (does not support eeprom yet), decrease speed when Shift is held |
| RGB_SPD | | Decrease effect speed (does not support eeprom yet), increase speed when Shift is held |

US ANSI Shifted Symbols

See also: US ANSI Shifted Symbols

| Key | Aliases | Description |
|---------------|---------|-------------|
| KC_TILDE | KC_TILD | ~ |
| KC_EXCLAIM | KC_EXLM | ! |
| KC_AT | | @ |
| KC_HASH | | # |
| KC_DOLLAR | KC_DLR | \$ |
| KC_PERCENT | KC_PERC | 용 |
| KC_CIRCUMFLEX | KC_CIRC | ^ |
| KC_AMPERSAND | KC_AMPR | & |
| KC_ASTERISK | KC_ASTR | * |

| Key | Aliases | Description |
|------------------------|-----------------|-------------|
| KC_LEFT_PAREN | KC_LPRN | (|
| KC_RIGHT_PAREN | KC_RPRN |) |
| KC_UNDERSCORE | KC_UNDS | _ |
| KC_PLUS | | + |
| KC_LEFT_CURLY_BRACE | KC_LCBR | { |
| KC_RIGHT_CURLY_BRACE | KC_RCBR | } |
| KC_PIPE | | |
| KC_COLON | KC_COLN | : |
| KC_DOUBLE_QUOTE | KC_DQUO, KC_DQT | " |
| KC_LEFT_ANGLE_BRACKET | KC_LABK, KC_LT | < |
| KC_RIGHT_ANGLE_BRACKET | KC_RABK, KC_GT | > |
| KC_QUESTION | KC_QUES | ? |

One Shot Keys

See also: One Shot Keys

| Key | Aliases | Description |
|--------------------|---------|----------------------------------|
| OSM(mod) | | Hold mod for one keypress |
| OSL(layer) | | Switch to layer for one keypress |
| QK_ONE_SHOT_TOGGLE | OS_TOGG | Toggles One Shot keys status |
| QK_ONE_SHOT_ON | OS_ON | Turns One Shot keys on |
| QK_ONE_SHOT_OFF | OS_OFF | Turns One Shot keys off |

Programmable Button Support

See also: Programmable Button

| Key | Aliases | Description |
|---------------------------|----------------|------------------------|
| QK_PROGRAMMABLE_BUTTON_1 | PB_1 | Programmable button 1 |
| QK_PROGRAMMABLE_BUTTON_2 | PB_2 | Programmable button 2 |
| QK_PROGRAMMABLE_BUTTON_3 | PB_3 | Programmable button 3 |
| QK_PROGRAMMABLE_BUTTON_4 | PB_4 | Programmable button 4 |
| QK_PROGRAMMABLE_BUTTON_5 | PB_5 | Programmable button 5 |
| QK_PROGRAMMABLE_BUTTON_6 | PB_6 | Programmable button 6 |
| QK_PROGRAMMABLE_BUTTON_7 | PB_7 | Programmable button 7 |
| QK_PROGRAMMABLE_BUTTON_8 | PB_8 | Programmable button 8 |
| QK_PROGRAMMABLE_BUTTON_9 | PB_9 | Programmable button 9 |
| QK_PROGRAMMABLE_BUTTON_10 | PB_10 | Programmable button 10 |
| QK_PROGRAMMABLE_BUTTON_11 | PB_11 | Programmable button 11 |
| QK_PROGRAMMABLE_BUTTON_12 | PB_12 | Programmable button 12 |
| QK_PROGRAMMABLE_BUTTON_13 | PB_13 | Programmable button 13 |
| QK_PROGRAMMABLE_BUTTON_14 | PB_14 | Programmable button 14 |

| Description | Aliases | Key | I |
|--------------------|---------|------------------|-------------|
| Programmable butto | PB_15 | MMABLE_BUTTON_15 | QK_PROGRAMM |
| Programmable butto | PB_16 | MMABLE_BUTTON_16 | QK_PROGRAMM |
| Programmable butto | PB_17 | MMABLE_BUTTON_17 | QK_PROGRAMM |
| Programmable butto | PB_18 | MMABLE_BUTTON_18 | QK_PROGRAMM |
| Programmable butto | PB_19 | MMABLE_BUTTON_19 | QK_PROGRAMM |
| Programmable butto | PB_20 | MMABLE_BUTTON_20 | QK_PROGRAMM |
| Programmable butto | PB_21 | MMABLE_BUTTON_21 | QK_PROGRAMM |
| Programmable butto | PB_22 | MMABLE_BUTTON_22 | QK_PROGRAMM |
| Programmable butto | PB_23 | MMABLE_BUTTON_23 | QK_PROGRAMM |
| Programmable butto | PB_24 | MMABLE_BUTTON_24 | QK_PROGRAMM |
| Programmable butto | PB_25 | MMABLE_BUTTON_25 | QK_PROGRAMM |
| Programmable butto | PB_26 | MMABLE_BUTTON_26 | QK_PROGRAMM |
| Programmable butto | PB_27 | MMABLE_BUTTON_27 | QK_PROGRAMM |
| Programmable butto | PB_28 | MMABLE_BUTTON_28 | QK_PROGRAMM |
| Programmable butto | PB_29 | MMABLE_BUTTON_29 | QK_PROGRAMM |
| Programmable butto | PB_30 | MMABLE_BUTTON_30 | QK_PROGRAMM |
| Programmable butto | PB_31 | MMABLE_BUTTON_31 | QK_PROGRAMM |
| Programmable butto | PB 32 | MMABLE BUTTON 32 | QK PROGRAMM |

Repeat Key

See also: Repeat Key

| Description | Aliases | Keycode |
|---------------------------------|---------|-----------------|
| Repeat the last pressed key | QK_REP | QK_REPEAT_KEY |
| Perform alternate of the last k | QK_AREP | QK_ALT_REPEAT_K |

Space Cadet

See also: Space Cadet

| Key | Aliases | Description |
|--|---------|--|
| QK_SPACE_CADET_LEFT_CTRL_PARENTHESIS_OPEN | SC_LCPO | Left Control when held, (when tapped |
| QK_SPACE_CADET_RIGHT_CTRL_PARENTHESIS_CLOSE | SC_RCPC | Right Control when held,) when tapped |
| QK_SPACE_CADET_LEFT_SHIFT_PARENTHESIS_OPEN | SC_LSPO | Left Shift when held, (when tapped |
| QK_SPACE_CADET_RIGHT_SHIFT_PARENTHESIS_CLOSE | SC_RSPC | Right Shift when held,) when tapped |
| QK_SPACE_CADET_LEFT_ALT_PARENTHESIS_OPEN | SC_LAPO | Left Alt when held, (when tapped |
| QK_SPACE_CADET_RIGHT_ALT_PARENTHESIS_CLOSE | SC_RAPC | Right Alt when held,) when tapped |
| QK_SPACE_CADET_RIGHT_SHIFT_ENTER | SC_SENT | Right Shift when held, Enter when tapped |

Swap Hands

See also: Swap Hands

| Key | Aliases | Description |
|-----------------------------|---------|--|
| SH_T(kc) | | Momentary swap when held, kc when tapped |
| QK_SWAP_HANDS_ON | SH_ON | Turn on hand swap |
| QK_SWAP_HANDS_OFF | SH_OFF | Turn off hand swap |
| QK_SWAP_HANDS_MOMENTARY_ON | SH_MON | Turn on hand swap while held |
| QK_SWAP_HANDS_MOMENTARY_OFF | SH_MOFF | Turn off hand swap while held |
| QK_SWAP_HANDS_TOGGLE | SH_TOGG | Toggle hand swap |
| QK_SWAP_HANDS_TAP_TOGGLE | SH_TT | Momentary swap when held, toggle when tapped |
| QK_SWAP_HANDS_ONE_SHOT | SH_OS | Turn on hand swap while held or until next key press |

Unicode Support

See also: Unicode Support

| Key | Aliases | Description |
|----------------------------|---------|--|
| UC(c) | | Send Unicode code point c, up to 0x7FFF |
| UM(i) | | Send Unicode code point at index i in unicode_map |
| UP(i, j) | | Send Unicode code point at index i, or j if Shift/Caps is on |
| QK_UNICODE_MODE_NEXT | UC_NEXT | Cycle through selected input modes |
| QK_UNICODE_MODE_PREVIOUS | UC_PREV | Cycle through selected input modes in reverse |
| QK_UNICODE_MODE_MACOS | UC_MAC | Switch to macOS input |
| QK_UNICODE_MODE_LINUX | UC_LINX | Switch to Linux input |
| QK_UNICODE_MODE_WINDOWS | UC_WIN | Switch to Windows input |
| QK_UNICODE_MODE_BSD | UC_BSD | Switch to BSD input (not implemented) |
| QK_UNICODE_MODE_WINCOMPOSE | UC_WINC | Switch to Windows input using WinCompose |
| QK_UNICODE_MODE_EMACS | UC_EMAC | Switch to emacs (C-x-8 RET) |

