Custom Keycodes

- 1. Porting guide
- 2. Custom Keycode


Custom keycodes in QMK

QMK provides a way for user to redefine behavior for existing key or create new keycode.

For example, here 3 custom keycodes are defined within keymap.c. An enum block is used to assign each keycode a unique integer code, and then the behavior of each keycode is defined inside process record user(). The keycodes are then assigned inside the keymap as usual.

```
enum blender keycode {
    B VPAN = SAFE RANGE,
    B DOLLY,
    B UNDO,
}
bool process record user(uint16 t keycode, keyrecord t *record) {
        switch (keycode) {
                case B VPAN:
            if (record->event.pressed) { ... }
            return 0;
        case B DOLLY:
            if (record->event.pressed) { ... }
            return 0;
        case B UNDO:
            if (record->event.pressed) { ... }
            return 0;
        }
```

When you load a board with custom keycodes, they will appear as unique hexcode. You can use the "any key" button and type in values starting with 0x7E40 to assign them but this isn't very user friendly.



Custom keycodes in Vial

Vial provides a way to alias custom keycodes so that they appear as a named keycode you can assign in the GUI.

In vial.json you can create a new list named customKeycodes with each of the keycodes having three properties:

- shortName: the name that will appear on the key in the GUI; it needs to be short otherwise the text will overflow.
- title: a short description that will appear when you hover over the keycode
- name: appears before title

For those three keycodes you'd have something like this in your vial.json. Watch out for any syntax errors. The last item in the list should not have a comma.

In the keymap.c file, replace SAFE RANGE with QK KB 0:

```
enum blender_keycode {
    B_VPAN = QK_KB_0,
    B_DOLLY,
    B_UNDO,
}
```

Custom keycodes in the json file **must** match what's inside the enum block, both in order and number of keycodes.

If everything goes smoothly the hexcode will be replaced with name of the keycode. You can access all your custom keycode inside the User tab. Do note that the firmware size will increase slightly (this example is ~100bytes).



