

z Fuss) each through a VCA; output CURRENTS sum at U9A virtual ground (free mixing).
dry / R11 100k fb) are reproduced by the input attenuators + firmware CV law.
tied = OTA CURRENT summing (intentional; ERC output-output waiver).

U11A int1 (BP) -> U11B int2 (LP); HP at the sum node. Cutoff = SVF_F_CV -> both labc.
U12A VCA -> SVF_Q_CV sets resonance 0.25..8 continuously (synth-style).

Mode select: CD4051B on VA rail. ch0=Off(bypass) ch1=LP ch2=BP ch3=HP ch4=Notch. Address 3.3V->VA level-shifted (inverting).

Illicit Apothecary

Sheet: /
File: mix_svf.kicad_sch

Title: Glitchwave 567 – Mix & SVF Filter

Size: A3 Date:
KiCad E.D.A. kicad-cli 7.0.11+dfsg-1build4

Rev: 0.1
Id: 1/1