Potenza Backlit Remote Programing

Please read through the directions entirely prior to programming your remote as the process is time sensitive.

Program Remote to TV using Code Scan

1. Turn on your TV using the *original TV remote* or the power button on the TV.



2. Press the **TV** button at the top of the remote



- 3. Press and hold **SETUP** until the **TV** button flashes twice.
- 4. Using the keypad on the remote. Enter the number **991** on the remote. The **TV** button should again flash twice.



5. Press the **CH+** button once per second until the TV turns off. (Do not go too fast or you will skip by the code.)



6. Press the **SETUP** button until the **TV** button blinks twice to lock in the code.

If you did not go too fast, pressing the power button should turn the TV back on. If not, repeat steps 2 through 5.

Program the Master Power button

This will allow you to press only the power button to turn the TV and Set-Top-Box on and off. (Versus pressing the TV button, then the power button to turn the TV off)

- 1. Press the **TV** button once.
- 2. Press and hold **SETUP** until the **TV** button blinks twice.
- 3. Enter 995, the TV button should again blink twice.
- 4. Press the **POWER** button once.
- 5. Press the **STB** button once.
- 6. Press the **TV** button once.
- 7. Press and hold **SETUP** until the **TV** button blinks twice.
- 8. Press the STB button once.

Press Power button. If you followed the steps, the Set-Top-Box and TV should both turn off. Press power again to turn them both back on.