



Smartcard Laboratory Introduction to Side-Channel Analysis

Prof. Dr.-Ing. Georg Sigl

Institute for Security in Information Technology

Lecturer: M.Sc. Oscar M. Guillen

Summer Semester 2015





Tutor – Consultation hours

Lab Tutor

Thomas Zeschg

E-Mail

- thomas.zeschg@tum.de

Consultation hours

- Tuesday 10:45 am to 12:45 pm
- Wednesday 1:00 pm to 3:00 pm

Location

Laboratory Room N1003



Agenda

- Introduction
 - Attacks on crypto implementations
 - Classification of hardware attacks
 - Different kinds of side-channel attacks
- Side Channel Analysis
 - AES algorithm
 - Power consumption models
 - Steps of a DPA Attack
- SCA Countermeasures
 - Hiding
 - Masking



Section 1


INTRODUCTION



Black box assumptions

Symmetric cryptography:

- AES introduced 1999 is still cryptographically secure Asymmetric cryptography:
- RSA with 2048 Bit key will be secure for the next years
- Elliptic curves cryptography with smaller key size and equivalent security as an alternative






Black Box → Grey Box or White Box



For Implementations of cryptographic algorithms the black box assumptions are not longer valid



Which kinds of attacks on embedded systems exist?





Example: PIN check with 4 digits

```
function pin_verification( digit_entered[1:4] )
    if (digit_entered [1] != PIN_digit[1] )
        return(false);
    if (digit_entered [2] != PIN_digit[2] )
        return(false);
    if (digit_entered [3] != PIN_digit[3] )
        return(false);
    if (digit_entered [4] != PIN_digit[4] )
        return(false);
    return(true);
end function
```



Fault attack

```
function pin_verification( digit_entered[1:4])
    if (digit_entered [1] != PIN_digit[1])
        return(false);
    if (digit_entered [2] != PIN_digit[2])
        return(false);
    if (digit_entered [3] != PIN_digit[3])
        return(false);
    if (digit_entered [4] != PIN_digit[4])
        return(false);
    return(true);
end function
```




Side-channel attack

(Timing attack in this case)

```
function pin_verification( digit_entered[1:4] )
    if (digit_entered [1] != PIN_digit[1] )
        return(false);
    if (digit_entered [2] != PIN_digit[2] )
        return(false);
    if (digit_entered [3] != PIN_digit[3] )
        return(false);
    if (digit_entered [4] != PIN_digit[4] )
        return(false);
    return(true);
end function
```








Attack classification

	Active	Passive
Non-Invasive	Glitching, Temperature Change, Low Voltage,	Side-Channel Attacks (Timing Analysis, Power Analysis, Simple EM Attacks)
Semi-Invasive	Light Attacks, Radiation Attacks, 	Sophisticated EM Attacks, Optical inspection (ROM,)
Invasive	Forcing, Permanent circuit changes,	Probing Attacks,



Power Analysis Measurement






Simple Power Analysis

Idea

- Measure the power profile during a single crypto operation
- Power consumption is data dependent
- Extract information from a power trace
 e.g. square versus (square + multiply)

Pros

- Cheap equipment
- Low knowledge required



Cons

- Bad resolution: critical in case of low signal to noise ratio
- Modifications to the board are required
- Difficult in SoCs with a single power supply; no local information



Idea

- Measure the power profile during a crypto operation
- Repeat the measurements many times (10² 10⁶)
- Perform statistical correlation between the traces measured and a power model of the implementation

Pros


- Cheap equipment
- High resolution

Cons

- Modifications to the board are required
- Difficult in SoCs with a single power supply; no local information
- Expertise required



Power measurement setup





Electromagnetic Analysis

Idea:

- Measure electromagnetic emanation during crypto operations
- Repeat this many times (10² 10⁶)
- Perform statistical correlation between the traces measured and an emission model of the implementation

Pros


- High resolution
- No modifications to board are required
- Localized information

Cons


- Expertise required
- Chip de-capsulation (improves results drastically)



Electromagnetic Analysis (semi-invasive)










Section 2 – Side-channel Analysis

DIFFERENTIAL POWER ANALYSIS




Basic structure of the AES algorithm

- 10, 12, or 14 rounds for key sizes
 128, 192, 256 bits
- Last round is slightly different (no mixcolumns)






The AES algorithm operations are performed on a two-dimensional array of bytes called the **state**





AddRoundKey transformation


- The round key is added to the state
- Simple bitwise XOR operation





SubBytes transformation


- Non-linear byte substitution
- Operates on each byte using a substitution table





ShiftRows transformation


- Cyclical shift of rows
- Each row is cycled with a different offset





MixColumns transformation

- Operates on the state one column at a time
- The columns are considered as polynomials over GF(2⁸) and multiplied modulo x⁴+1 with a fixed polynomial
- It can be seen as a matrix multiplication






Basic structure of AES-128


AES-128

- Input size = 128 bit
- Output size = 128 bit
- Key size = 128 bit
- 10 Rounds





Power trace of an AES SW implementation





Power traces

What can be learned from power traces?


- Through visual inspection (as in SPA), we can get information about:
 - The parameters of the algorithm
 (e.g. # rounds in AES → key length)
 - A closer look may identify characteristics of single instructions
 - Length differences of instructions (e.g. MUL, DIV) may help make educated guesses about the parameters
 - Differences in the instruction flow (key dependent jumps) may allow extracting secret data
 - Memory accesses often show characteristic power profiles
 - Cache hit and miss behavior can be easily identified



CMOS Power consumption model

Hamming Distance

- Power consumption proportional to the number of transitions from 0 -> 1 and 1-> 0
- Assumptions
 - Transitions from 0->1 and 1->0 consume the same power
 - Transitions from 0->0 and 1->1 do not consume power



$$P = C^*V^2$$
 if $O(t-1)=0$ and $O(t)=1$

$$P = C^*V^2$$
 if $O(t-1)=0$ and $O(t)=1$
 $O = \overline{A}$
 $P = 0$ if $O(t-1) = 0$ (t) or $O(t-1) = 1$ and $O(t)=0$


Hamming Distance = |A(t) - A(t-1)|



Power consumption models

Hamming Weight

- Most commonly used
- Simpler than the Hamming Distance model
- Used when the attacker only knows one data value being transferred (i.e. no information about the previous value)
- Assumption
 - Power consumption is proportional to the number of bits that are set in the processed value





- DPA was published by Paul Kocher, Joshua Jaffe, Benjamin Jun in Proceedings of Crypto 1999
- Paul Kocher founded a company Cryptography Research Inc. CRI, which holds most of the patents for countermeasures against SCA (including DPA)
- On June 6, 2011 Cryptography Research was bought by Rambus in a deal worth \$342.5 million
- For further information and nice videos about DPA see: http://www.cryptography.com/



What is DPA?

- Power analysis attack which goal is to reveal the secret keys of a cryptographic device
- It assumes that the power consumption is a function of the secret data being processed
- The shape of the trace is not important (as in SPA)
- Uses a large number of power traces taken during the operation of the device
- Linear data relationships are determined by using statistical tools



Attack Strategy

- 1. Choosing an intermediate result of the executed algorithm
- 2. Measuring the power consumption
- 3. Calculating intermediate values
- 4. Mapping intermediate values to hypothetical power consumption values
- 5. Comparing the hypothetical power consumption values with the power consumption traces



Choosing an intermediate result

Choose an intermediate result of the algorithm which depends on data (known) and the key (unknown): *f* (d,k)

Most effective attacks on AES can be mounted at the


- S-box output of the first round (for encryption)
- S-box input of the last round (for decryption)

Why?

- Number of key hypothesis for the S-box is small (i.e. 28=256)
- The intermediate value depends on small part of the key k and known data d
- Non-linear elements of the S-box make the DPA more effective (i.e. a one bit difference at the input of an S-box leads to a difference of several bits at the output)



Choosing an intermediate result





Measuring the power consumption

- Choose a set of D data values which will be encrypted (or decrypted). Store this values as a vector: d = (d₁,...d_D)'
- Measure the power consumption for each encryption of a data value d_i and store it in a power trace t'_i = (t_{i,1}, ...t_{i,T})' with T samples
- Store all collected traces inside a matrix T of dimensions DxT.
- It is important to align the traces
 - All the values in a column of **T** have to belong to the same operation
 - Using a unique trigger for trace collection with the oscilloscope yields the best results

$$\mathbf{T} = \begin{bmatrix} t_{1,1} & \dots & t_{1,j} & \cdots & t_{1,T} \\ \vdots & \ddots & & & \vdots \\ t_{i,1} & & t_{i,j} & & t_{i,T} \\ \vdots & & \ddots & \vdots \\ t_{D,1} & \cdots & t_{D,j} & \cdots & t_{D,T} \end{bmatrix}$$



Trace compression

Concept

- Power traces contain many points with lots of redundancy
- In order to speed up analysis it is favorable to reduce the number of points
- Such techniques receive the name of trace compression

There are many methods to compress a trace, e.g.:

- Sum of absolute values over a time interval
- Sum of squared values over a time interval
- Maximum value in a time interval



Calculating intermediate values

- List all possible key values and store it in a vector of size K (e.g. for the S-box K = 256 possible values since each key part is 8-bit long) $\mathbf{k} = (k_1, \dots, k_K)'$ (e.g. $\mathbf{k} = (0, 1, 2, \dots, 255)'$ for an 8-bit value)
- Calculate a matrix **V** of possible intermediate results for all data and key hypothesis with elements $v_{i,i} = f(d_i, k_i)$ using the function which was chosen in the first step



Hypothetical power consumption values

- Calculate the power consumption for each element in the matrix **V** of possible intermediate results
- Make use of a power model to estimate the power consumption
 - Hamming weight
 - Hamming Distance
- This results in a matrix **H** of hypothetical power consumption:



Statistical Correlation

Pearson Correlation Coefficient

 The covariance is a measure of the statistical dependence of two random variables, i.e. power traces t=(t_i); q=(q_i) for i = 1,...,n

$$Cov(t,q) = E(t \cdot q) - E(t) \cdot E(q)$$

- If t and q are independent $E(t \cdot q) = E(t) \cdot E(q) \rightarrow Cov(t,q) = 0$
- The correlation coefficient ρ is a normalized measure for the dependence with -1
 ≤ ρ ≤ 1 and ρ=0 for Independent variables.

$$\rho = \frac{Cov(\mathbf{t}, \mathbf{q})}{\sqrt{Var(\mathbf{t}) \cdot Var(\mathbf{q})}} \approx r = \frac{\sum_{i=1}^{n} (t_i - t) \cdot (q_i - q)}{\sqrt{\sum_{i=1}^{n} (t_i - \bar{t})^2 \cdot \sum_{i=1}^{n} (q_i - \bar{q})^2}}$$



Statistical Correlation

In this step the correlation coefficient between the columns of the matrix of measured traces T and the columns of the matrix of hypothetical values H is calculated for all points in time.

The estimated correlation coefficient $r_{i,i}$ is calculated by taking column ifrom matrix **H** and column *j* from matrix **T**:

$$r_{i,j} = \frac{\sum_{d=1}^{D} \left[(t_{d,j} - \overline{t}_{j}) \cdot (h_{d,i} - \overline{h}_{i}) \right]}{\sqrt{\sum_{d=1}^{D} (t_{d,j} - \overline{t}_{j})^{2} \cdot \sum_{d=1}^{D} (h_{d,i} - \overline{h}_{i})^{2}}}$$

$$r_{i,j} = \frac{\sum\limits_{d=1}^{D} \left[(t_{d,j} - \bar{t}_j) \cdot (h_{d,i} - \bar{h}_i) \right]}{\sqrt{\sum\limits_{d=1}^{D} (t_{d,j} - \bar{t}_j)^2 \cdot \sum\limits_{d=1}^{D} (h_{d,i} - \bar{h}_i)^2} } \\ R = \begin{bmatrix} r_{1,1} & \dots & r_{1,j} & \dots & r_{1,T} \\ \vdots & \ddots & & \vdots \\ r_{i,1} & & r_{i,j} & & r_{i,T} \\ \vdots & & \ddots & \vdots \\ r_{K,1} & \dots & r_{K,j} & \dots & r_{K,T} \end{bmatrix}$$
 result is a KxT matrix of

The result is a KxT matrix of correlation coefficients R:



Finding the most probable result


The key byte and the time when it is used in the power trace can be obtained by finding $r_{ck,ct} = \max_{i,j} (abs(r_{i,j}));$ ck = i; ct = j ck is the index of the row with correct key ct is the index of the column with the correct time

$$\mathbf{R} = \begin{bmatrix} \mathbf{r}_{1,1} & \dots & \mathbf{r}_{1,j} & \cdots & \mathbf{r}_{1,T} \\ \vdots & \ddots & & & \vdots \\ \mathbf{r}_{i,1} & & \mathbf{r}_{i,j} & & \mathbf{r}_{i,T} \\ \vdots & & \ddots & \vdots \\ \mathbf{r}_{K,1} & \cdots & \mathbf{r}_{K,j} & \cdots & \mathbf{r}_{K,T} \end{bmatrix}$$
 key with maximum correlation

time of maximum correlation







vector **k** with K key hypothesis

intermediate values $v_{i,j}$ with all key hypothesis $\rightarrow V_{DxK}$

V _{1,1}	V _{1,2}		V _{1,K}				
V _{2,1}	V _{2,2}		V _{2,K}				
V _{D,1}	V _{D,2}		V _{D,K}				

Power model

hypothetical power values $h_{i,j} \rightarrow \mathbf{H}_{DxK}$

h _{1,1}	h _{1,2}	 h _{1,K}	t _{1,1}	t _{1,2}	 t _{1,T}
h _{2,1}	h _{2,2}	 h _{2,K}	t _{2,1}	t _{2,2}	 t _{2,T}
h _{D,1}	h _{D,2}	 h _{D,K}	t _{D,1}	t _{D,2}	 t _{D,T}

Statistical analysis

Power traces for T measuring points, D data values and alignment to same trigger → T_{DxT}


Matrix of correlation coefficients $\rightarrow \mathbf{R}_{KxT}$

r _{1,1}	r _{1,2}	 r _{1,T}
r _{2,1}	r _{2,2}	 r _{2,T}
r _{K,1}	r _{K,2}	 r _{K,T}



Section 2 – Differential Power Analysis

COUNTERMEASURES





Hiding the power consumption

Increasing noise

- Time domain
 - Insertion of random wait states
 - Shuffling instructions, memory accesses, etc...
- Amplitude domain
 - Perform dummy operations in parallel to crypto algorithm
 - Dedicated noise generators on smartcards

Attenuation of the side-channel signal

- Amplitude domain
 - Special circuit design styles to achieve logic value independent power consumption
 - Filtering the power supply



Hiding in SW

Randomization

- Random wait state insertion (nop's)
- Randomize instruction execution
- Randomize memory accesses

Generate noise

Make use of peripherals which generate noise in parallel to the cryptographic function



Masking internal values

Description

- Make the power consumption of the device independent of the intermediate values of the cryptographic algorithm through randomization
- Avoids having to modify the power consumption characteristics of the device
- Can be implemented at the algorithm level

Concept

- Each intermediate value *v* is concealed by a random value *m*
- The value *m* varies in each execution and cannot be predicted

$$V_m = V * m$$



Masking types

Types

- Boolean masking (with xor ⊕): v_m = v ⊕ m
 - Mostly applied in symmetric cryptography i.e. AES
- Arithmetic masking (with + or ·): $v_m = v + m$ or $v_m = v \cdot m$
 - Mostly applied in asymmetric cryptography

Masking of linear functions

• $f(v_m) = f(v) * f(m)$

Masking of nonlinear functions is difficult


- $f(v_m) \neq f(v) * f(m)$
 - For example the AES S-box is nonlinear:
 S(v ⊕ m) ≠ S(v) ⊕ S(m)



Masking Example

Masking is the most widely used countermeasure in software In hardware masking can be implemented on any design level What is the impact on masking with an **unknown mask m** on SCA?

Intermediate values are concealed





Masking in software for AES

Simple masking scheme for AES

- Data (or key) are XOR'ed with a random mask at the beginning
- During each round the transformations are applied to the masked data and the mask itself
 - AddRoundKey: apply the function only to the masked data
 - SubBytes: Need for a masked S-box table
 - Shift Rows: Shifting is applied to mask and data separately (unless all bytes in the state are masked with the same value, in that case it does not affect the masking)
 - MixColumns: Applied to mask and data separately
- After the last round, the mask is removed



AES software masking scheme

For the SW implementation 6 independent masks are used

- 2 masks *m* and *m*' for the S-box input and output
- 4 masks for each row of the state m_1, m_2, m_3, m_4 for the input of MixColumns

Pre-computation (done for every encryption)

- Generate the six masks at random
- Calculate the masked S-box, $S_m(x \oplus m) = S(x) \oplus m'$
- Execute MixColumns for the masks m_1, m_2, m_3, m_4 to create the output masks m'_1, m'_2, m'_3, m'_4

Execute the AES algorithm applying the masks on the state and round key

AES (software) masking scheme

Rounds execution

- Mask the plaintext with $[m'_1, m'_2, m'_3, m'_4]$
- Mask the round key with
 [m'₁ xor m, m'₂ xor m, m'₃ xor m,m'₄ xor m]
- Perform AddRoundKey masks will become [m, m, m, m]
- Perform SubBytes and ShiftRows masks will become [m', m', m', m']
- Do re-masking to end up with the input masks for MixedColumns [m₁,m₂,m₃,m₄], masks after MixedColumns [m'₁,m'₂,m'₃,m'₄]

In the final round skip re-masking and MixedColumns

Remove the masks from the ciphertext

State

m'1	m'1	m'1	m'1
m'2	m'2	m'2	m'2
m'3	m'3	m'3	m'3
m'4	m'4	m'4	m'4

Round Key							
m'1⊕	m'1 ⊕	m'1 ⊕	m'1 ⊕				
m	m	m	m				
m'2 ⊕	m'2 ⊕	m'2 ⊕	m'2 ⊕				
m	m	m	m				
m'3 ⊕	m'3 ⊕	m'3 ⊕	m'3 ⊕				
m	m	m	m				
m'4 ⊕	m'4 ⊕	m'4 ⊕	m'4 ⊕				
m	m	m	m				

AddRoundKey

m	m	m	m
m	m	m	m
m	m	m	m
m	m	m	m

SubBytes, ShiftRows

m'	m'	m'	m'
m'	m'	m'	m'
m'	m'	m'	m'
m'	m'	m'	m'

Remasking

m1	m1	m1	m1
m2	m2	m2	m2
m3	m3	m3	m3
m4	m4	m4	m4

Mixcolumns

m'1	m'1	m'1	m'1
m'2	m'2	m'2	m'2
m'3	m'3	m'3	m'3
m'4	m'4	m'4	m'4



Attacks on Masking

Masking protects against DPA if

- There is no joint power consumption of the masked value and mask
- The mask is uniformly distributed

Implementation pitfalls

- If masks are not changed frequently enough, DPA is still possible
- Masks may be biased due to insufficient statistical properties of the PRNG generating the masks
- Binning of the traces may be possible if (global) mask changes can be detected
- If masks are reused, operations with values (u, v), which are masked with the same mask m, may show the plain values

$$(u \oplus m) \oplus (v \oplus m) = u \oplus v$$

• Hamming Distance of a register may leak the value being protected $HD(v_m, m) = HW(v_m \oplus m) = HW(v)$



Further Information

The book from Stefan Mangard, Thomas Popp, Elisabeth Oswald provides all necessary know how and detailed mathematical background to perform power attacks. http://www.dpabook.org/

SICA lecture¹ at TUM every winter term, provides very good training in this topic. (taught in German) Stefan Mangard's material (2012) can be found under:



http://www.physical-security.org

Power analysis attacks are in the focus of the research community. Therefore new attack flavors are published every year.

www.chesworkshop.org
https://www.cosade.org/

http://www.sec.ei.tum.de/lehrveranstaltungen/sichere%20implementierung%20kryptographischer%20verfahren/



Questions?

THANK YOU FOR YOUR ATTENTION!