SECTION 26 0573 - OVERCURRENT PROTECTIVE DEVICE COORDINATION STUDY

PART 1 - GENERAL

1.1 RELATED DOCUMENTS

A. Drawings and general provisions of the Contract, including General and Supplementary Conditions and Division 01 Specification Sections, apply to this Section.

1.2 SUMMARY

- A. Section includes computer-based, overcurrent protective device coordination studies to determine overcurrent protective devices and to determine overcurrent protective device settings for selective tripping.
 - 1. Study results shall be used to determine coordination of series-rated devices.

1.3 DEFINITIONS

- A. Existing to Remain: Existing items of construction that are not to be removed and that are not otherwise indicated to be removed, removed and salvaged, or removed and reinstalled.
- B. One-Line Diagram: A diagram which shows, by means of single lines and graphic symbols, the course of an electric circuit or system of circuits and the component devices or parts used therein.
- C. Protective Device: A device that senses when an abnormal current flow exists and then removes the affected portion from the system.
- D. SCCR: Short-circuit current rating.
- E. Service: The conductors and equipment for delivering electric energy from the serving utility to the wiring system of the premises served.

1.4 ACTION SUBMITTALS

- A. Product Data: For computer software program to be used for studies.
- B. Other Action Submittals: Submit the following after the approval of system protective devices submittals. Submittals shall be in digital form.
 - 1. Coordination-study input data, including completed computer program input data sheets.
 - 2. Study and equipment evaluation reports.
 - 3. Overcurrent protective device coordination study report; signed, dated, and sealed by a qualified professional engineer.
 - Submit study report for action prior to receiving final approval of the distribution equipment submittals. If formal completion of studies will cause delay in equipment manufacturing, obtain approval from Architect for preliminary submittal of sufficient study data to ensure that the selection of devices and associated characteristics is satisfactory.

1.5 CLOSEOUT SUBMITTALS

- A. Operation and Maintenance Data: For the overcurrent protective devices to include in emergency, operation, and maintenance manuals.
 - 1. In addition to items specified in front end specifications:
 - a. The following parts from the Protective Device Coordination Study Report:
 - 1) One-line diagram.
 - 2) Protective device coordination study.
 - 3) Time-current coordination curves.
 - b. Power system data.

1.6 QUALITY ASSURANCE

- A. Studies shall use computer programs that are distributed nationally and are in wide use. Software algorithms shall comply with requirements of standards and guides specified in this Section. Manual calculations are unacceptable.
- B. Coordination Study Software Developer Qualifications: An entity that owns and markets computer software used for studies, having performed successful studies of similar magnitude on electrical distribution systems using similar devices.
 - 1. The computer program shall be developed under the charge of a licensed professional engineer who holds IEEE Computer Society's Certified Software Development Professional certification.
- C. Coordination Study Specialist Qualifications: Professional engineer in charge of performing the study and documenting recommendations, licensed in the state where Project is located. All elements of the study shall be performed under the direct supervision and control of this professional engineer.

PART 2 - PRODUCTS

2.1 COMPUTER SOFTWARE DEVELOPERS

- A. Comply with IEEE 242 and IEEE 399.
- B. Analytical features of device coordination study computer software program shall have the capability to calculate "mandatory," "very desirable," and "desirable" features as listed in IEEE 399.
- C. Computer software program shall be capable of plotting and diagramming time-current-characteristic curves as part of its output. Computer software program shall report device settings and ratings of all overcurrent protective devices and shall demonstrate selective coordination by computer-generated, timecurrent coordination plots.
 - 1. Optional Features:
 - a. Arcing faults.
 - b. Simultaneous faults.
 - c. Explicit negative sequence.
 - d. Mutual coupling in zero sequence.

2.2 PROTECTIVE DEVICE COORDINATION STUDY REPORT CONTENTS

- A. Executive summary.
- B. Study descriptions, purpose, basis and scope. Include case descriptions, definition of terms and guide for interpretation of the computer printout.
- C. One-line diagram, showing the following:
 - 1. Protective device designations and ampere ratings.
 - Cable size and lengths.
 - 3. Transformer kilovolt ampere (kVA) and voltage ratings.
 - 4. Motor and generator designations and kVA ratings.
 - Switchboard and panelboard designations.
- D. Study Input Data: As described in "Power System Data" Article.
- E. Short-Circuit Study Output: As specified in "Short-Circuit Study Output" Paragraph in "Short-Circuit Study Report Contents" Article in Section 16052 "Overcurrent Protective Device Short-Circuit Study."
- F. Protective Device Coordination Study:
 - Report recommended settings of protective devices, ready to be applied in the field. Use manufacturer's data sheets for recording the recommended setting of overcurrent protective devices when available.
 - a. Phase and Ground Relays:
 - Device tag.

- 2) Relay current transformer ratio and tap, time dial, and instantaneous pickup value.
- 3) Recommendations on improved relaying systems, if applicable.
- b. Circuit Breakers:
 - 1) Adjustable pickups and time delays (long time, short time, ground).
 - 2) Adjustable time-current characteristic.
 - 3) Adjustable instantaneous pickup.
 - 4) Recommendations on improved trip systems, if applicable.
- c. Fuses: Show current rating, voltage, and class.
- G. Time-Current Coordination Curves: Determine settings of overcurrent protective devices to achieve selective coordination. Graphically illustrate that adequate time separation exists between devices installed in series, including power utility company's upstream devices. Prepare separate sets of curves for the switching schemes and for emergency periods where the power source is local generation. Show the following information:
 - 1. Device tag and title, one-line diagram with legend identifying the portion of the system covered.
 - 2. Terminate device characteristic curves at a point reflecting maximum symmetrical or asymmetrical fault current to which the device is exposed.
 - 3. Identify the device associated with each curve by manufacturer type, function, and, if applicable, tap, time delay, and instantaneous settings recommended.
 - 4. Plot the following listed characteristic curves, as applicable:
 - Power utility's overcurrent protective device.
 - b. Medium-voltage equipment overcurrent relays.
 - Medium- and low-voltage fuses including manufacturer's minimum melt, total clearing, tolerance, and damage bands.
 - Low-voltage equipment circuit-breaker trip devices, including manufacturer's tolerance bands.
 - e. Transformer full-load current, magnetizing inrush current, and ANSI through-fault protection curves.
 - f. Cables and conductors damage curves.
 - g. Ground-fault protective devices.
 - h. Motor-starting characteristics and motor damage points.
 - i. Generator short-circuit decrement curve and generator damage point.
 - j. The largest feeder circuit breaker in each motor-control center and panelboard.
 - 5. Series rating on equipment allows the application of two series interrupting devices for a condition where the available fault current is greater than the interrupting rating of the downstream equipment. Both devices share in the interruption of the fault and selectivity is sacrificed at high fault levels. Maintain selectivity for tripping currents caused by overloads.
 - 6. Provide adequate time margins between device characteristics such that selective operation is achieved.
 - 7. Comments and recommendations for system improvements.
 - 8. No more than three time-current curves provided on any single graph for review.

PART 3 - EXECUTION

3.1 EXAMINATION

- A. Examine Project overcurrent protective device submittals for compliance with electrical distribution system coordination requirements and other conditions affecting performance. Devices to be coordinated are indicated on Drawings.
 - Proceed with coordination study only after relevant equipment submittals have been assembled.
 Overcurrent protective devices that have not been submitted and approved prior to coordination study may not be used in study.

3.2 PROTECTIVE DEVICE COORDINATION STUDY

- A. Comply with IEEE 242 for calculating short-circuit currents and determining coordination time intervals.
- B. Comply with IEEE 399 for general study procedures.
- C. The study shall be based on the device characteristics supplied by device manufacturer.

- D. Begin analysis at the service, extending down to the system overcurrent protective devices as follows:
 - 1. To life safety, critical, equipment, and normal systems low-voltage load buses where fault current is 10 kA or less down to 0.1 seconds.
- E. Study electrical distribution systems from normal and alternate power sources throughout electrical distribution system for Project. Study all cases of system-switching configurations and alternate operations that could result in maximum fault conditions.
- F. Motor Protection:
 - 1. Select protection for low-voltage motors according to IEEE 242 and NFPA 70.
 - 2. Select protection for motors served at voltages more than 600 V according to IEEE 620.
- G. Conductor Protection: Protect cables against damage from fault currents according to ICEA P-32-382, ICEA P-45-482, and protection recommendations in IEEE 242. Demonstrate that equipment withstands the maximum short-circuit current for a time equivalent to the tripping time of the primary relay protection or total clearing time of the fuse. To determine temperatures that damage insulation, use curves from cable manufacturers or from listed standards indicating conductor size and short-circuit current.
- H. Generator Protection: Select protection according to manufacturer's written recommendations and to IEEE 242.
- I. The calculations shall include the ac fault-current decay from induction motors, synchronous motors, and asynchronous generators and shall apply to low- and medium-voltage, three-phase ac systems. The calculations shall also account for the fault-current dc decrement, to address the asymmetrical requirements of the interrupting equipment.
 - 1. For grounded systems, provide a bolted line-to-ground fault-current study for areas as defined for the three-phase bolted fault short-circuit study.
 - Any application of series-rated devices shall be recertified, complying with requirements in NFPA 70.

3.3 POWER SYSTEM DATA

- A. Obtain all data necessary for the conduct of the overcurrent protective device study.
 - Verify completeness of data supplied in the one-line diagram on Drawings. Call discrepancies to the attention of Architect.
 - 2. For new equipment, use characteristics submitted under the provisions of action submittals and information submittals for this Project.
- B. Gather and tabulate the following input data to support coordination study. The list below is a guide. Comply with recommendations in IEEE 551 for the amount of detail required to be acquired in the field. Field data gathering shall be under the direct supervision and control of the engineer in charge of performing the study, and shall be by the engineer or its representative who holds NETA ETT Level III certification or NICET Electrical Power Testing Level III certification.
 - Product Data for overcurrent protective devices specified in other Sections and involved in overcurrent protective device coordination studies. Use equipment designation tags that are consistent with electrical distribution system diagrams, overcurrent protective device submittals, input and output data, and recommended device settings.
 - 2. Electrical power utility impedance at the service.
 - 3. Power sources and ties.
 - 4. Short-circuit current at each system bus, three phase and line-to-ground.
 - 5. Full-load current of all loads.
 - Voltage level at each bus.
 - 7. For transformers, include kVA, primary and secondary voltages, connection type, impedance, X/R ratio, taps measured in percent, and phase shift.
 - 8. For circuit breakers and fuses, provide manufacturer and model designation. List type of breaker, type of trip and available range of settings, SCCR, current rating, and breaker settings.
 - 9. Generator short-circuit current contribution data, including short-circuit reactance, rated kVA, rated voltage, and X/R ratio.
 - 10. For relays, provide manufacturer and model designation, current transformer ratios, potential transformer ratios, and relay settings.
 - 11. Motor horsepower and NEMA MG 1 code letter designation.

12. Low-voltage cable sizes, lengths, number, conductor material, and conduit material (magnetic or nonmagnetic).

3.4 FIELD ADJUSTING

- A. Adjust relay and protective device settings according to the recommended settings provided by the coordination study. Field adjustments shall be completed by the engineering service division of the equipment manufacturer under the Startup and Acceptance Testing contract portion.
- B. Make minor modifications to equipment as required to accomplish compliance with short-circuit and protective device coordination studies.
 - Perform each visual and mechanical inspection and electrical test stated in NETA Acceptance
 Testing Specification. Certify compliance with test parameters. Perform NETA tests and inspections
 for all adjustable overcurrent protective devices.

3.5 DEMONSTRATION

- A. Engage the Coordination Study Specialist to train Owner's maintenance personnel in the following:
 - Acquaint personnel in the fundamentals of operating the power system in normal and emergency modes.
 - 2. Hand-out and explain the objectives of the coordination study, study descriptions, purpose, basis, and scope. Include case descriptions, definition of terms, and guide for interpreting the time-current coordination curves.
 - 3. Adjust, operate, and maintain overcurrent protective device settings.

END OF SECTION