# Draft Proposed American National Standard

# X3T10 Project 1047D

Revision 6c 03-Sept-96

# Information technology - SCSI-3 Controller Commands (SCC)

This is a draft proposed American National Standard of Accredited Standards Committee X3. As such this is not a completed standard. The X3T10 Technical Committee may modify this document as a result of comments received during public review and its approval as a standard. Use of the information contained here in is at your own risk.

Permission is granted to members of X3, its technical committees, and their associated task groups to reproduce this document for the purposes of X3 standardization activities without further permission, provided this notice is included. All other rights are reserved. Any duplication of this document for commercial or for-profit use is strictly prohibited.

ASC X3T10 Technical Editor: George O. Penokie

IBM Dept. 2B7

3605 Highway 52 N. Rochester, MN 55901

**USA** 

Telephone: 507-253-5208 Facsimile: 507-253-2432

Email: gop@rchvmp3.vnet.ibm.com

Reference number ISO/IEC \*\*\*\*\*: 199x ANSI X3.276 - 199x

#### **POINTS OF CONTACT:**

X3T10 Chair
John B. Lohmeyer

X3T10 Vice-Chair
Lawrence J. Lamers

Symbios Logic Adaptec

 4420 Arrows West Drive
 691 South Milpitas Blvd

 Colo Spgs, CO 80907-3444
 Milpitus, CA 95035

 Tel: (719) 533-7560
 Tel: (408) 975-7817

 Fax: (719) 533-7036
 Fax: (408) 957-7193

#### X3 Secretariat

Lynn Barra

Administrator Standards Processing

X3 Secretariat Telephone: 202-626-5738
1250 Eye Street, NW Suite 200 Facsimile: 202-638-4922
Washington, DC 20005 Email: Ibarra@cbema.org

SCSI Reflector Internet address for subscription of the SCSI reflector: scsi-request@symbios.com

Internet address for distribution via SCSI reflector: scsi@symbios.com

SCSI Bulletin Board 719-574-0424

**Document Distribution** 

Global Engineering Telephone: 303-792-2181 or 15 Inverness Way East 800-854-7179 Englewood, CO 80112-5704 Facsimile: 303-792-2192

#### **ABSTRACT**

This standard defines commands for SCSI-3 storage array devices; commonly known as RAID devices. This standard is principally intended to be used in conjunction with, not as an alternate to, any of the SCSI-3 command standards and the SCSI-3 Architecture Model Standard. The resulting commands facilitate the control and configuration of SCSI-3 storage arrays and thus provide a common command specification for both system integrators and suppliers of SCSI-3 storage array devices.

#### PATENT STATEMENT

**CAUTION:** The developers of this standard have requested that holder's of patents that may be required for the implementation of the standard, disclose such patents to the publisher. However, neither the developers nor the publisher have undertaken a patent search in order to identify which, if any, patents may apply to this standard. As of the date of publication of this standard, following calls for the identification of patents that may be required for the implementation of the standard, notice of one or more claims has been received.

By publication of this standard, no position is taken with respect to the validity of this claim or of any rights in connection therewith. The known patent holder(s) has (have), however, filed a statement of willingness to grant a license under these rights on reasonable and nondiscriminatory terms and conditions to applicants desiring to obtain such a license. Details may be obtained from the publisher.

No further patent search is conducted by the developer or the publisher in respect to any standard it processes. No representation is made or implied that licenses are not required to avoid infringement in the use of this standard.

### Contents

	Page
Foreword	x
0 Introduction	xii
1 Scope	1
·	
2 Normative references	
2.1 Approved references	
2.2 References under development	2
3 Definitions, symbols, abbreviations, and conventions	2
3.1 Definitions	2
3.2 Symbols and abbreviations	
3.3 Conventions	
4 General	6
5 Models for systems containing arrays of devices	7
5.1 System layering model	
5.1.1 SACL functions	
5.1.2 Protocol conversion layer	8
5.1.3 Storage array conversion layer (SACL)	9
5.1.4 Examples of system layering variations	10
5.1.5 Branch of generic layers	11
5.1.6 Software SACL with a branch of SCSI disks	
5.1.7 Branch with HBA SACL	13
5.1.8 Branch with bridge controller SACL	14
5.1.9 Branch with SACLs in multiple layers	15
5.2 Model for SCSI-3 storage arrays	16
5.2.1 SCSI storage array addressing	
5.2.1.1 SCSI-3 storage array base address	
5.2.1.2 Eight byte LUN structure	
5.2.1.3 Component device address method	
5.2.1.4 Logical unit address method	
5.2.1.5 Peripheral device address method	
5.2.1.6 Redundancy group address method	
5.2.1.7 Spare address method	
5.2.1.8 Volume set address method	
5.2.2 SCSI-3 storage array objects	
5.2.2.1 Adding objects	
5.2.2.2 Association of objects	
5.2.2.3 Attachment of objects	
5.2.2.4 Covering of objects	
5.2.2.5 Exchanging objects	
5.2.2.6 Protected objects	
5.2.2.7 Removing objects	
5.2.2.8 Component device	
5.2.2.9 Peripheral device	
5.2.2.10 P_extent	
5.2.2.11 Ps_extent	
5.2.2.12 Redundancy group	
5.2.2.12.2 Copy redundancy method of check data mapping	
5.2.2.12.3 XOR or P+Q redundancy method of check data mapping	
5.2.2.12.4 Vendor specific redundancy method of check data mapping	
5.2.2.12.7 Volidor Specific redundancy method of check data mapping	∠1

5.2.2.13 Spares	27
5.2.2.14 Volume sets	
5.2.3 SCSI-3 storage array operations	34
5.2.3.1 Rebuild operation	34
5.2.3.2 Recalculate operation	
5.2.3.3 Regenerate operation	34
5.2.3.4 Verify operation	34
5.2.4 SCSI-3 storage array states	
5.2.5 SCSI-3 storage array exception conditions	34
6 Commands for SCSI-3 storage array devices	36
6.1 MAINTENANCE(IN) command	
6.1.1 MAINTENANCE(IN) command service actions	
6.1.1.1 REPORT ASSIGNED/UNASSIGNED P_EXTENT service action	
6.1.1.2 REPORT COMPONENT DEVICE service action	
6.1.1.3 REPORT COMPONENT DEVICE ATTACHMENTS service	
6.1.1.4 REPORT PERIPHERAL DEVICE service action	
6.1.1.5 REPORT PERIPHERAL DEVICE ASSOCIATIONS service action	
6.1.1.6 REPORT PERIPHERAL DEVICE/COMPONENT DEVICE IDENTIFIER service action	
6.1.1.7 REPORT STATES service action	
6.2 MAINTENANCE (OUT) commands	
6.2.1 MAINTENANCE (OUT) command service actions	
6.2.1.1 ADD PERIPHERAL DEVICE/COMPONENT DEVICE service action	
6.2.1.2 ATTACH TO COMPONENT DEVICE service action	
6.2.1.3 BREAK PERIPHERIAL DEVICE/COMPONENT DEVICE service action	
6.2.1.4 EXCHANGE P_EXTENT service action	
6.2.1.5 EXCHANGE PERIPHERAL DEVICE/COMPONENT DEVICE service action	
6.2.1.6 INSTRUCT COMPONENT DEVICE service action	
6.2.1.7 REMOVE PERIPHERAL DEVICE/COMPONENT DEVICE service action	
6.2.1.8 SET PERIPHERAL DEVICE/COMPONENT DEVICE IDENTIFIER service action	
6.3 REDUNDANCY GROUP (IN) command	
6.3.1 REDUNDANCY GROUP (IN) command service actions	
6.3.1.1 REPORT REDUNDANCY GROUPS service action	
6.3.1.2 REPORT UNASSIGNED REDUNDANCY GROUP SPACE service action	
6.4 REDUNDANCY GROUP (OUT) command	
6.4.1 REDUNDANCY GROUP (OUT) command service actions	
6.4.1.1 CONTROL GENERATION OF CHECK DATA service action	
6.4.1.2 CREATE/MODIFY REDUNDANCY GROUP service action	
6.4.1.3 DELETE REDUNDANCY GROUP service action	
6.4.1.4 REBUILD P_EXTENT service action	
6.4.1.5 REBUILD PERIPHERAL DEVICE service action	
6.4.1.6 RECALCULATE CHECK DATA service action	
6.4.1.7 VERIFY CHECK DATA service action	
6.5 VOLUME SET (IN) command	
6.5.1 VOLUME SET (IN) command service actions	
6.5.1.1 REPORT VOLUME SETS service action	
6.6 VOLUME SET (OUT) command	
6.6.1 VOLUME SET (OUT) command service actions	
6.6.1.1 CONTROL GENERATION OF CHECK DATA service action	
6.6.1.2 CONTROL WRITE OPERATIONS service action	
6.6.1.3 CREATE/MODIFY VOLUME SET service action	
6.6.1.4 DELETE VOLUME SET service action	
6.6.1.5 RECALCULATE VOLUME SET CHECK DATA service action	
6.6.1.6 VERIFY VOLUME SET CHECK DATA service action	
6.7 SPARE (IN) command	
6.7.1 SPARE (IN) command service actions	
6.7.1.1 REPORT P EXTENT SPARE service action	

	6.7.1.2 REPORT PERIPHERAL DEVICE/COMPONENT DEVICE SPARE service action	114
	6.8 SPARE (OUT) command	117
	6.8.1 SPARE (OUT) command service actions	117
	6.8.1.1 CREATE/MODIFY P_EXTENT SPARE service action	118
	6.8.1.2 CREATE/MODIFY PERIPHERAL DEVICE/COMPONENT DEVICE SPARE service action	121
	6.8.1.3 DELETE SPARE service action	122
	6.9 Parameters for direct-access devices	124
	6.9.1 Mode parameters	
	6.9.1.1 LUN mapping page	
ΔΛ	SCSI-3 storage array IDENTIFY message format	126
۸.۷	A.1 IDENTIFY message	126
R (	SCSI-3 storage array addressing examples	127
٥.ر	B.1 Addressing Examples for the 8-byte LUN structure	
	B.2 Addressing Examples for the 6-bit LUN structure	
C.0	Examples of check data and user data mappings	132
	C.1 Example XOR redundancy mapping	
	C.2 User data mapping examples	

## Tables

	Page
1 Addressing methods within a SCSI-3 storage array	16
2 Eight byte LUN structure adjustments	
3 Eight byte LUN structure	
4 FIRST LEVEL ADDRESSING field, SECOND LEVEL ADDRESSING field, THIRD LEVEL ADDRESSING field, ar	
LEVEL ADDRESSING field	
5 ADDRESS METHOD	
6 Logical unit addressing	
7 Peripheral device addressing	
8 Volume set addressing	20
9 Commands for SCSI storage array devices	
10 Service actions for MAINTENANCE(IN) command	
11 REPORT ASSIGNED/UNASSIGNED P_EXTENT service action	
12 REPORT ASSIGNED/UNASSIGNED P_EXTENT parameter list	
13 Data format of ASSIGNED/UNASSIGNED P_EXTENT DESCRIPTOR	
14 Data format of P_EXTENT DESCRIPTOR	
15 REPORT COMPONENT DEVICE service action	
16 REPORT COMPONENT DEVICE parameter list	
17 Data format of COMPONENT DEVICE DESCRIPTOR	
18 COMPONENT DEVICE TYPES	_
19 REPORT COMPONENT DEVICE ATTACHMENTS service action	
20 REPORT COMPONENT DEVICE ATTACHMENTS parameter list	
21 Format of COMPONENT DEVICE ATTACHMENT DESCRIPTOR	
22 Data format of LOGICAL UNIT DESCRIPTOR	
23 LOGICAL UNIT types	47
24 REPORT PERIPHERAL DEVICE service action	
25 SELECT REPORT	
26 REPORT PERIPHERAL DEVICE parameter List	
27 Format of PERIPHERAL DEVICE DESCRIPTOR	
28 REPORT PERIPHERAL DEVICE ASSOCIATIONS service action	
29 REPORT PERIPHERAL DEVICE ASSOCIATIONS parameter list	
30 Format of PERIPHERAL DEVICE ASSOCIATIONS DESCRIPTOR	
31 REPORT PERIPHERAL DEVICE/COMPONENT DEVICE IDENTIFIER service action	
32 REPORT PERIPHERAL DEVICE/COMPONENT DEVICE IDENTIFIER parameter list	
33 REPORT STATES service action	
34 REPORT STATES	
35 REPORT STATES parameter list	56
36 Format of LOGICAL UNIT STATES DESCRIPTORS	
37 Target base device (LUN 0) states	
38 Volume set states	
39 Redundancy group states	
40 Peripheral device and p_extent states	
41 Spare states	
42 Component device states	
43 Service actions for MAINTENANCE (OUT) command	
44 ADD PERIPHERAL DEVICE/COMPONENT DEVICE service action	
45 ATTACH COMPONENT DEVICE service actions	
46 ATTACH COMPONENT DEVICE parameter list	
47 BREAK PERIPHERAL DEVICE/COMPONENT DEVICE service action	
48 EXCHANGE P_EXTENT service action	
49 EXCHANGE P_EXTENT parameters list	
50 EXCHANGE PERIPHERAL DEVICE/COMPONENT DEVICE Service Action	
51 INSTRUCT COMPONENT DEVICE service action	
52 COMPONENT DEVICE INSTRUCTION field	
53 INSTRUCT COMPONENT DEVICE parameter list	
54 REMOVE PERIPHERAL DEVICE/COMPONENT DEVICE service action	70

55 SET PERIPHERAL DEVICE/COMPONENT DEVICE IDENTIFIER service action	71
56 SET PERIPHERAL DEVICE/COMPONENT DEVICE IDENTIFIER parameter list	
57 Service actions for REDUNDANCY GROUP (IN) command	
58 REPORT REDUNDANCY GROUPS service action	
59 REPORT REDUNDANCY GROUPS parameter list	
60 Format of REPORT REDUNDANCY GROUP DESCRIPTOR	
61 REDUNDANCY GROUP IDENTIFIERS	
62 GRANULARITY OF UNITS	
63 REDUNDANCY GROUP P EXTENT DESCRIPTOR	
64 REPORT UNASSIGNED REDUNDANCY GROUP SPACE service action	
65 REPORT UNASSIGNED REDUNDANCY GROUP SPACE parameter list	
66 Format of REPORT UNASSIGNED REDUNDANCY GROUP SPACE DESCRIPTOR	
67 Data format of PS_EXTENT DESCRIPTOR	
68 Service actions for REDUNDANCY GROUP (OUT) command	
69 CONTROL GENERATION OF CHECK DATA service action	
70 CREATE/MODIFY REDUNDANCY GROUP service action	
71 CREATE/MODIFY REDUNDANCY GROUP parameter list	
72 Data format of CREATE/MODIFY P_EXTENT DESCRIPTOR	
73 DELETE REDUNDANCY GROUP service action	
74 REBUILD P_EXTENT service action	
75 Rebuild types	
76 REBUILD P_EXTENT parameter list	
77 REBUILD PERIPHERAL DEVICE service action	
78 Rebuild types	
79 REBUILD PERIPHERAL DEVICE parameter list	
80 RECALCULATE CHECK DATA service action	
81 VERIFY CHECK DATA service action	
82 Service actions for volume set (in) command	
83 REPORT VOLUME SETS service action	
84 REPORT VOLUME SETS parameter list	
85 Format of REPORT VOLUME SET DESCRIPTOR	
86 VOLUME SET PS_EXTENT DESCRIPTOR	
87 Service actions for VOLUME SET (OUT) command	
88 CONTROL GENERATION OF CHECK DATA service action	
89 CONTROL WRITE OPERATIONS service action	
90 CREATE/MODIFY VOLUME SET service action	
91 CREATE/MODIFY VOLUME SET parameter list	
92 Data format of CREATE/MODIFY PS_EXTENT DESCRIPTOR	
93 DELETE VOLUME SET service action	
94 RECALCULATE VOLUME SET CHECK DATA service action	106
95 RECALCULATE VOLUME SET CHECK DATA parameter list	
96 VERIFY VOLUME SET CHECK DATA service action	108
97 VERIFY RANGE	
98 VERIFY VOLUME SET CHECK DATA parameter list	110
99 Service actions for SPARE (IN) command	111
100 REPORT P_EXTENT SPARE service action	111
101 REPORT P_EXTENT SPARE parameter list	112
102 Format of REPORT P_EXTENT SPARE DESCRIPTOR	
103 REPORT PERIPHERAL DEVICE/COMPONENT DEVICE SPARE service action	114
104 REPORT PERIPHERAL DEVICE/COMPONENT DEVICE SPARE parameter list	
105 Format of REPORT PERIPHERAL DEVICE/COMPONENT DEVICE SPARE DESCRIPTOR	
106 Data format of covered LOGICAL UNIT DESCRIPTOR	
107 LOGICAL UNIT TYPES	
108 Service actions for spare (out) command	
109 CREATE/MODIFY P_EXTENT SPARE service action	
110 CREATE/MODIFY P_EXTENT SPARE parameter list	
111 CREATE/MODIFY PERIPHERAL DEVICE/COMPONENT DEVICE SPARE service action	

112 CREATE/MODIFY PERIPHERAL DEVICE/COMPONENT DEVICE SPARE parameter li	st122
113 DELETE SPARE service action	123
114 Mode page codes	124
115 LUN mapping page	125
	126

## Figures

	Page
1 SCSI-3 document road map	1
2 Protocol conversion layer	8
3 SACL conversion layer	9
4 Typical system diagram	10
5 Branch of generic layers	11
6 Software SACL with a branch of SCSI disks	
7 Branch with HBA SACL	13
8 Branch with bridge controller SACL	14
9 Branch with SACLs in multiple layers	15
10 Single redundancy group	24
11 Multiple volume sets associated with a single redundancy group	
12 Redundancy group check data mapping flow chart	
13 Multiple redundancy groups	29
14 Single volume set associated with multiple redundancy groups	29
15 Volume set user data mapping flow chart (part 1)	31
16 Volume set user data mapping flow chart (part 2)	
17 Volume set user data mapping flow	33
C.1 XOR redundancy mapping example	
C.2 User data mapping for a RAID 5 configuration	133
C.3 User data mapping for a RAID 3 configuration	

#### Foreword

This foreword is not part of ANSI X3.276 - 199x.

The SCSI-3 Controller Commands (SCC) standard is divided into six clauses:

- Clause 1 is the scope;
- Clause 2 enumerates the normative references that apply to this standard:
- Clause 3 describes the definitions, symbols and abbreviations used in this standard;
- Clause 4 describes the conceptual relationship between this document and the SCSI-3 Architecture Model;
- Clause 5 describes the command model for SCSI-3 storage array devices;
- Clause 6 defines the commands that may be implemented by an SCSI-3 storage array device.

The annexes provide information to assist with implementation of the SCSI-3 Controller Commands standard. Annex A is normative and is considered part of this standard. Annexes B and C are for information only.

This standard was developed by a joint effort between the X3T10 SCSI Controller Commands working group and the RAID Advisory Board Host Interface working group during 1992-94. The standards approval process started in 1995.

Requests for interpretation, suggestions for improvement and addenda, or defect reports are welcome. They should be sent to the X3 Secretariat, Computer and Business Equipment Manufacturers Association, 1250 Eye Street, NW, Suite 200, Washington, DC 20005-3922.

This standard was processed and approved for submittal to ANSI by Accredited Standards Committee on Information Processing Systems, X3. Committee approval of the standard does not necessarily imply that all committee members voted for approval.

The joint X3T10 SCSI Controller Commands working group/RAID Advisory Board Host Interface working group, which developed this standard, has the following members:

#### George O. Penokie, Chair

Dal Allan Doug Hagerman Ed Haske John Baudrexl Charles Binford Andrew Hill Paul Boulay Gerry Houlder Allen Cole Bill Hutchinson Bill Dallas M. Jibbe Peter Dougherty Gerry Johnsen David Fellinger Larry Lamers Mike Fitzpatrick Paul Massiglia Giles Frazier Dick McCormick Jerry Fredin Gene Milligan Bill Galloway Joe Molina Mike Glass David Reilly Howard Grill Herb Silverman Randy Hall David Skinner

Bob Snively Bob Solomon George Su Gary Watson Ralph Weber Jeffery Williams

Technical Committee X3T10 on Lower Level Interfaces, which approved this standard, had the following members:

John B. Lohmeyer, Chair Lawrence J. Lamers, Vice-Chair Ralph O. Weber, Secretary

I. Dal Allan Paul D. Aloisi Ron Apt Geoffrey Barton Robert Bellino Charles Brill Peter Brown Michael Bryan Joe Chen Chris D'Iorio Joe Dambach Jan V. Dedek Stephen G. Finch **Edward Fong** Louis Grantham Norm Harris **Edward Haske** Dennis R. Haynes Stephen F. Heil Stephen Holmstead David Hudson Peter Johansson Gerry Johnsen Skip Jones **Edward Lappin** Joe Lawlor David Lawson Robert Liu Bob Masterson David McFadden James McGrath Pete McLean Patrick Mercer Gene Milligan Charles Monia Dennis P. Moore Ian Morrell John Moy S. Nadershahi Erich Oetting Alan R. Olson Dennis Pak Duncan Penman George Penokie Doug Piper Donna Pope

Robert N. Snively Jeff Stai Gary R. Stephens Clifford E. Strang Jr. Thomas 'Rick' Tewell Dean Wallace Harvey Waltersdorf Gary M. Watson Michael Wingard Mark Woithe Ezra Alcudia (Alt.) Michael Alexenko (Alt.) Steven A. Anderson (Alt.) David Andreatta (Alt.) Tak Asami (Alt.) Akram Atallah (Alt.) Paul Boulay (Alt.) Kevin Calvert (Alt.) John Cannon (Alt.) Kurt Chan (Alt.) Shufan Chan (Alt.) Ting Li Chan (Alt.) Mike Chenery (Alt.) Nancy Cheng (Alt.) William Clemmey (Alt.) Dan Colegrove (Alt.) Roger Cummings (Alt.) Zane Daggett (Alt.) William Dallas (Alt.) Varouj Der-Hacopian (Alt.) Dhiru N. Desai (Alt.) Mike Eneboe (Alt.) Timothy Feldman (Alt.) Edward A. Gardner (Alt.) John Geldman (Alt.) Chuck Grant (Alt.) Peter Haas (Alt.) Douglas Hagerman (Alt.) Kenneth J. Hallam (Alt.) William Ham (Alt.) Tom Hanan (Alt.) Rick Heidick (Alt.) Mike Hetzel (Alt.) Gerald Houlder (Alt.)

Paul Jackson (Alt.)

Kevin James (Alt.)

Mark Jordan (Alt.)

Brian Johnson (Alt.)

Richard Kalish (Alt.) Greg Kapraun (Alt.) Thomas J. Kulesza (Alt.) Dennis Lang (Alt.) Bill Mable (Alt.) Gerald Marazas (Alt.) John Masiewicz (Alt.) Daniel E. Moczarny (Alt.) E.J. Mondor (Alt.) Jay Neer (Alt.) Tim Norman (Alt.) Vit Novak (Alt.) Kevin R. Pokorney (Alt.) Gary Porter (Alt.) Doug Prins (Alt.) Steven Ramberg (Alt.) Ron Roberts (Alt.) John P. Scheible (Alt.) J. R. Sims (Alt.) Michael Smith (Alt.) Allen Spalding (Alt.) Arlan P. Stone (Alt.) Joe Stoupa (Alt.) George Su (Alt.) Nicos Syrimis (Alt.) Pete Tobias (Alt.) Adrienne Turenne (Alt.) Joseph Wach (Alt.) Roger Wang (Alt.) Dave Weber (Alt.) Bob Whiteman (Alt.) Jeffrey L. Williams (Alt.) Kurt Witte (Alt.) Devon Worrell (Alt.) Charles I. Yang (Alt.) Danny Yeung (Alt.) Mike Yokoyama (Alt.)

Robert Reiseh

Scott Smyers

#### 0 Introduction

The SCSI command set is designed to provide efficient peer-to-peer operation of input/output devices (disks, tapes, printers, etc.) by an operating system, The SCSI command set assumes a command-response protocol. Action on SCSI commands shall not be deemed completed until a response is received. The response shall include a status that indicates the final disposition of the command.

The SCSI command set provides multiple operating systems concurrent control over one or more input/output devices. However, the multiple operating systems must properly coordinate their actions or data corruption will result. This standard defines commands that assist with coordination between multiple operations systems. However, details of the coordination are beyond the scope of the SCSI command set.

This standard defines a device model for SCSI-3 storage arrays. This standard defines the SCSI commands that may apply to SCSI-3 storage arrays and the SCSI commands that are uniquely for SCSI-3 storage arrays.

With any technical document there may arise questions of interpretation as new products are implemented, The X3 Committee has established procedures to issue technical opinions concerning the standards developed by the X3 organization. These procedures may result in SCSI Technical Information Bulletins being published by X3.

Any such bulletins, while reflecting the opinion of the Technical Committee that developed the standard, are intended solely as supplementary information to other users of the standard. This standard, ANSI X3.276 - 199x, as approved though the publication and voting procedures of the American National Standards Institute, is not altered by these bulletins. Any subsequent revision to this standard may or may not reflect the contents of any such Technical Information Bulletins.

Current X3 practice is to make Technical Information Bulletins available through:

Global Engineering Telephone: 303-792-2181 or

15 Inverness Way East 800-854-7179 Englewood, CO 80112-5704 Facsimile: 303-792-2192

#### 1 Scope

This standard defines the command set extensions to facilitate operation of SCSI-3 storage array devices. The clause(s) of this standard pertaining to the SCSI-3 storage array device class, implemented in conjunction with the applicable clauses within any of the SCSI-3 command standards, shall specify the standard command set available for SCSI-3 storage arrays.

The objectives of the SCSI-3 Controller Commands is to provide the following:

- a) Transfer commands unique to SCSI-3 Controller Command devices:
- b) Control commands to manage the operation of an SCSI-3 Controller Command device;
- c) Optional device mapping and pass-through support.

Figure 1 is intended to show the relationship of this document to other SCSI-3 standards. The figure is not intended to imply a relationship such as a hierarchy, protocol stack, or system architecture. It indicates the applicability of a standard to the implementation of a given transport.




Figure 1 - SCSI-3 document road map

The term SCSI is used wherever it is not necessary to distinguish between the versions of SCSI. The Small Computer System Interface - 2 (ANSI X3.131-1994), is referred to herein as SCSI-2.

The term SCSI-3 refers collectively to the following documents:

- SCSI-3 Parallel Interface Standard [X3T10/855D]
- SCSI-3 Interlocked Protocol Standard [X3T10/856D]
- SCSI-3 Fiber Channel Protocol Standard [X3T10/993D]
- SCSI-3 Serial Bus Protocol Standard [X3T10/992D]
- SCSI-3 Architecture Model Standard [X3T10/994D]
- SCSI-3 Primary Commands Standard [X3T10/995D]
- SCSI-3 Block Commands Standard [X3T10/996D]
- SCSI-3 Stream Commands Standard [X3T10/997D]
- SCSI-3 Graphic Commands Standard [X3T10/998D]
- SCSI-3 Medium Changer Commands Standard [X3T10/999D]
- SCSI-3 Multi-Media Commands Standard [X3T10/1048D]

#### 2 Normative references

The following standards contain provisions which, through reference in the text, constitute provisions of this standard. At the time of publication, the editions indicated were valid. All standards are subject to revision, and parties to agreements based on this standard are encouraged to investigate the possibility of applying the most recent editions of the standards listed below.

Copies of the following documents can be obtained from ANSI: Approved ANSI standards, approved and draft international and regional standards (ISO, IEC, CEN/CENELEC, ITUT), and approved and draft foreign standards (including BSI, JIS, and DIN). For further information, contact ANSI Customer Service Department at 212-642-4900 (phone), 212-302-1286 (fax) or via the World Wide Web at http://www.ansi.org.

Members of IEC and ISO maintain registers of currently valid standards.

#### 2.1 Approved references

None

#### 2.2 References under development

At the time of publication, the following referenced standards were still under development. For information on the current status of the document, or regarding availability, contact the relevant standards body or other organization as indicated.

- SCSI-3 Architecture Model Standard, ANSI X3.270 199x
- SCSI-3 Interlocked Protocol Standard, ANSI X3.292 199x
- SCSI-3 Primary Commands Standard [X3T10/995D]

NOTE 1 - For more information on the current status of the document, contact the X3 Secretariat at 202-737-8888 (phone), 202-638-4922 (fax) or via Email at x3sec@itic.nw.dc.us. To obtain copies of this document, contact Global Engineering at 15 Inverness Way East Englewood, CO 80112-5704 at 303-792-2181 (phone), 800-854-7179 (phone), or 303-792-2192 (fax).

#### 3 Definitions, symbols, abbreviations, and conventions

#### 3.1 Definitions

3.1.1 application client: An object that is the source of SCSI commands. Further definition of an application client can be found in the SCSI-3 Architecture Model Standard.

- 3.1.2 association: The linking of SCSI-3 storage array objects in a manner explicitly defined within this standard.
- 3.1.3 attachment: The linking of SCSI-3 storage array objects in a vendor specific manner.
- 3.1.4 base address: The LUN that an application client addresses to configure an SCSI-3 storage array and to determine information about an SCSI-3 storage array and the logical units attached to it.
- 3.1.5 byte: Indicates an 8-bit construct.
- 3.1.6 check data: Information contained within a redundancy group that allows lost or destroyed user data to be recreated.
- 3.1.7 check data mapping: The distribution of the check data within a redundancy group.
- 3.1.8 command: A request describing a unit of work to be performed by a device server. See the SCSI-3 Architecture Model Standard for a detailed definition of a command.
- 3.1.9 command descriptor block: The structure of up to 16 bytes used to communicate commands from an initiator to a target.
- 3.1.10 component device: Any physical addressable component not identifiable as an SCSI-3 peripheral device type. See table 18 for a list of components.
- 3.1.11 configuration: A collection of SCSI-3 storage array objects that follow the rules defined within this standard. For a list of SCSI-3 storage array objects see 5.2.2.
- 3.1.12 covering: The linking of spare objects to other SCSI-3 storage array objects in a manner explicitly defined within this standard.
- 3.1.13 field: A group of one or more contiguous bits.
- 3.1.14 initiator: An SCSI device containing application clients that originate device service requests to be processed by a target SCSI device. See the SCSI-3 Architecture Model Standard for a detailed definition of an initiator.
- 3.1.15 invalid: An illegal or unsupported field or code value.
- 3.1.16 groups: Objects that are independent from one another that may overlay one another.
- 3.1.17 logical block address: An address of a unit of data supplied or requested by an initiator.
- 3.1.18 logical unit: An externally addressable entity within a target that implements an SCSI device model. See the SCSI-3 Architecture Model Standard for a detailed definition of a logical unit.
- 3.1.19 logical unit identifier: An object that is part of the SCSI-3 Architecture Model Standard definition of a logical unit. A logical unit identifier uniquely identifies a logical unit in a SCSI domain. See the SCSI-3 Architecture Model Standard for a detailed definition of SCSI domain and logical unit identifier.
- 3.1.20 logical unit number: An identifier for a logical unit.
- 3.1.21 mandatory: The referenced item is required to claim compliance with this standard.
- 3.1.22 one: A true signal value or a true condition of a variable.
- 3.1.23 optional: The referenced item is not required to claim compliance with this standard. Implementation of an optional item shall be as defined in this standard.

- 3.1.24 page: Several commands use regular parameter structures that are referred to as pages. These pages are identified with a value known as a page code.
- 3.1.25 p\_extent: All or part of the host addressable space within a single peripheral device of a SCSI-3 storage array.
- 3.1.26 peripheral device: Any addressable device identifiable as a SCSI-3 peripheral device type. See the IDENTIFY COMMAND description in the SCSI-3 Primary Commands Standard for the list of SCSI-3 peripheral device types.
- 3.1.27 protected space: The portion of a redundancy group that does not contain check data.
- 3.1.28 ps\_extent: All or part of the protected space within a single peripheral device configured as a redundancy group.
- 3.1.29 rebuild operation: Re-creation of protected space contents or any check data within a p\_extent using check data and protected space contents from the remaining p\_extents within the redundancy group.
- 3.1.30 recalculate operation: Re-creation of check data from protected space contents.
- 3.1.31 redundancy group: A grouping of protected space and associated check data (Check data may be null) into a single logical unit that shall only have a single type of redundancy.
- 3.1.32 regenerate operation: Re-creation of inaccessible protected space contents from accessible check data and protected space contents.
- 3.1.33 reserved: Identifies bits, fields, and code values that are set aside for future standardization.
- 3.1.34 SCSI-3 storage array: A target that processes SCSI command descriptor blocks and performs the services of a SACL. A single SCSI-3 storage array may contain multiple SACLs.
- 3.1.35 service action: A request describing a unit of work to be performed by a device server. A service action is an extension of a command. See the SCSI-3 Architecture Model Standard for a detailed definition of a command.
- 3.1.36 set: Objects that do not intersect and are independent from one another. Sets may span more than one device. A single device may contain more than one set or may contain the entire set.
- 3.1.37 spare: A range of logical block addresses, a component device, or a peripheral device covered by one or more redundancy groups, component devices, or peripheral devices that can be used to replace all or part of a redundancy group or a peripheral device or all of a component device.
- 3.1.38 storage array conversion layer (SACL): Converts input logical unit numbers to output logical unit numbers and may convert input logical block addresses to output logical block addresses.
- 3.1.39 stripe: All or part of a volume set that is bounded by a number of contiguous units within a single ps\_extent and by a number of ps\_extents.
- 3.1.40 target: In this standard a target refers to an SCSI-3 storage array device that performs an operation requested by an application client.
- 3.1.41 underlying redundancy group: The portion of a redundancy group that contains protected space that has been mapped to specific volume set(s).
- 3.1.42 unit: A standard basic quantity in bits, bytes, words, logical blocks, etc., specified by the GRANULARITY OF UNITS field (see table 62).

- 3.1.43 user data: The addressable logical blocks that are input to the SACL. Check data is not part of the addressable logical blocks.
- 3.1.44 user data mapping: The distribution of user data within a volume set.
- 3.1.45 vendor-specific: Something (e.g., a bit, field, code value, etc.) that is not defined by this standard and may be used differently in various implementations.
- 3.1.46 verify operation: Re-creation of check data from protected space contents and the comparison of the recreated check data with the current check data.
- 3.1.47 volume set: One or more ps\_extents grouped into a single LUN\_V.
- 3.1.48 zero: A false signal value or a false condition of a variable.

#### 3.2 Symbols and abbreviations

HBA	Host bus adapter
ITTU	I'm talking to you
LBA_P	Peripheral device logical block address
LBA_PS	Protected space logical block address
LBA_V	Volume set logical block address
LSB	Least significant bit
LUI	Logical unit identifier
LUN	Logical unit number
LUN_C	Component device logical unit number
LUN_P	Peripheral device logical unit number
LUN_R	Redundancy group logical unit number
LUN_S	Spare logical unit number
LUN_V	Volume set logical unit number
MSB	Most significant bit
SCSI	Either SCSI-2 or SCSI-3
SCSI-2	The Small Computer System Interface - 2 (ANSI X3.131)
SCSI-3	The Small Computer System Interface - 3
SIM	SCSI interface module

#### 3.3 Conventions

Certain words and terms used in this American National Standard have a specific meaning beyond the normal English meaning. These words and terms are defined either in 3.1 or in the text where they first appear, Names of messages, commands, statuses, sense keys, additional sense codes, and additional sense code qualifiers are in all uppercase (e.g., REQUEST SENSE), names of fields are in small uppercase (e.g., STATE OF SPARE), lower case is used for words having the normal English meaning.

Fields containing only one bit are usually referred to as the name bit instead of the name field.

Field names are in SMALL CAPS to distinguish them from normal English.

Numbers that are not immediately followed by lower-case b or h are decimal values.

Numbers immediately followed by lower-case b (xxb) are binary values.

Numbers immediately followed by lower-case h (xxh) are hexadecimal values

#### 4 General

This standard defines a device model for SCSI-3 storage arrays and the SCSI commands that apply to SCSI-3 storage arrays. This standard assumes all interconnects between devices are SCSI interconnects.

The SCSI command set assumes a command-response protocol. The fundamental properties of the command-response protocol are defined in the SCSI-3 Architecture Model Standard. In accordance with the SCSI-3 Architecture Model Standard, the command-response protocol can be modelled as a procedure call, specifically:

Service response = execute command (task identifier, command descriptor block, [data-out buffer], task attributes, || [data-in buffer], [autosense data], [autosense return flag], status).

The SCSI-3 Architecture Model Standard defines all of the inputs and outputs in the procedure call. As they may apply to any SCSI device, this standard defines the contents of the following procedure call inputs and outputs; command descriptor block, data-out buffer, data-in buffer, and autosense data. This standard does not define all possible instances of these procedure inputs and outputs. This standard defines only those instances that may apply to SCSI-3 storage array devices.

This standard references values returned via the status output parameter. Examples of such status values are CHECK CONDITION and COMMAND TERMINATED. Status values are not defined by this standard, The SCSI-3 Architecture Model Standard defines all status values.

The entity that makes the procedure call from an initiator is an application client, as defined by the SCSI-3 Architecture Model Standard. The procedure call's representation arrives at the target in the form of a device service request. The entity that performs the work of the procedure call in a target is a device server. A device server is an object within a logical unit and is defined by the SCSI-3 Architecture Model Standard.

#### 5 Models for systems containing arrays of devices

The first part of this clause defines a system layering model that uses the concept of SACLs to control arrays of devices. The second part of this clause defines the model for SCSI-3 storage array devices. The model assumes all the SCSI peripheral devices controlled within a SCSI-3 storage array are either fixed block or variable block devices.

#### 5.1 System layering model

#### 5.1.1 SACL functions

A SACL initiates several functions when an application client requests a media access. The type of media access and the configuration in effect determine which functions are used. The following are the functions available within a SACL:

- a) Translation of input logical unit identifiers to output logical unit identifiers;
- b) Translation of input logical block addresses to output logical block addresses;
- c) Reading data from and writing data to locations based on the configuration in effect for the addressed volume set;
- d) Calculating and updating the check data (if any);
- e) Regeneration of protected space contents within the volume set using check data information or duplicate data;
- f) Rebuilding of protected space contents associated with the redundancy group and(or) check data within the redundancy group using the contents of the redundancy group;
- g) Recalculation of the check data within a redundancy group;
- h) Recalculation of the check data within any redundancy group underlaying a volume set;
- i) Determining when a p\_extent should be disabled and/or replaced;
- j) Returning a confirmation to the application client as to the success or failure of a request and, in the case of a failure, gives possible corrective actions.

#### 5.1.2 Protocol conversion layer

A system is typically composed of many protocol conversion layers (see figure 2), and these layers may exist in hardware or software. Each of these layers has input(s) and output(s). The next layer accessed is determined by the preceding layer's output.

These protocol conversion layers include, but are not limited to: transport modules, host adapter drivers, SIMs (SCSI interface module), HBAs (host bus adapter), bridge controllers, and storage drives. In this model each of these layers will be represented by a simple block that has an input and output.

All requests to or from a SACL contain logical unit identifiers but not all requests contain logical block addresses.

NOTE 2 - The logical unit identifier is defined in the SCSI-3 Architecture Model Standard. SIMs and HBAs are defined in the SCSI-2 Common Access Method Transport and SCSI Interface Module Standard.




Figure 2 - Protocol conversion layer

Generic Layers do not modify the logical unit identifier or the logical block address.

NOTE 3 - There are types of layers other than generic and SACLs, however, these are not covered in this model.

#### 5.1.3 Storage array conversion layer (SACL)

The SACL is capable of extensive manipulation on the logical unit identifier and the logical block address, based upon a consistent algorithm that follows the defined configuration. It is possible that a single logical unit identifier input or logical block address input may be converted to multiple different logical unit identifier outputs and logical block address outputs. In the following figures (figure 3, figure 4, and figure 6 through figure 9) SACLs will be shown with 'SACL' in the block.

The model does not require a one to one correspondence between logical unit identifiers and SCSI devices.




Figure 3 - SACL conversion layer

#### 5.1.4 Examples of system layering variations

Typically a system diagram will be composed of many layers combined into a tree. For example, a driver may connect to multiple HBAs, which in turn may connect to multiple SCSI devices, etc. See figure 4 for an example of a system that consists of:

- a) one initiator that has two SCSI devices attached on a single SCSI bus that is not expandable;
- b) one initiator has two SCSI devices attached on a single SCSI that is expandable. One of the SCSI devices contains a SACL:
- c) the SCSI device that contains the SACL has three SCSI buses with SCSI devices attached and is capable of driving more SCSI buses:
  - a) two of the SCSI buses contain two SCSI devices each and these SCSI buses are not expandable:
  - b) one of the SCSI buses contains one SCSI device and is expandable.




Figure 4 - Typical system diagram

#### 5.1.5 Branch of generic layers

Figure 5 shows a system that does not contain any SCSI-3 storage arrays. In such a system all layers pass the logical unit identifier and logical block addresses directly through.




Figure 5 - Branch of generic layers

#### 5.1.6 Software SACL with a branch of SCSI disks

Figure 6 shows system software performing SACL functions. These functions convert the input logical unit identifier(X) and the input logical block address(X) to the output logical unit identifier(Y) and output logical block address(Y). All other layers pass the logical unit identifier and logical block address through.




Figure 6 - Software SACL with a branch of SCSI disks

#### 5.1.7 Branch with HBA SACL

Figure 7 shows a HBA performing SACL functions. These functions convert the input logical unit identifier(X) and the input logical block address(X) to the output logical unit identifier(Y) and output logical block address(Y). All other layers pass the logical unit identifier and logical block address through.




Figure 7 - Branch with HBA SACL

#### 5.1.8 Branch with bridge controller SACL

Figure 8 shows a bridge controller performing SACL functions. These functions convert the input logical unit identifier(X) and the input logical block address(X) to the output logical unit identifier(Y) and output logical block address(Y). All other layers pass the logical unit identifier and logical block address through.




Figure 8 - Branch with bridge controller SACL

#### 5.1.9 Branch with SACLs in multiple layers

Figure 9 shows an example with SACLs in multiple layers. This example shows a software layer performing SACL functions and a bridge controller performing SACL functions.

The software functions convert the input logical unit identifier(X) and the input logical block address(X) to the output logical unit identifier(Y) and output logical block address(Y). The bridge controller functions then convert the input logical unit identifier(Y) and the input logical block address(Y) to the output logical unit identifier(Z) and output logical block address(Z). All other layers pass the logical unit identifier and logical block address through.




Figure 9 - Branch with SACLs in multiple layers

#### 5.2 Model for SCSI-3 storage arrays

The SCSI-3 storage array model defines:

- a) the addressing of multiple devices and the addressing of multiple types of devices through multiple layers of SCSI-3 storage arrays as a single target,
- b) objects and how they are to be configured to create an operational SCSI-3 storage array; and
- c) the operations that occur within SCSI-3 storage arrays.

#### 5.2.1 SCSI storage array addressing

See table 1 for the methods used when addressing a SCSI-3 storage array.

Method of addressing	Directly addressable by application client	Suffix	Space addressed
Component device	no	_C	none
Peripheral device	yes	_P	physical
Redundancy group	no	_R	protected
Spare	no	_S	none
Volume set	yes	_V	user data

Table 1 - Addressing methods within a SCSI-3 storage array

The application client shall access redundancy groups, spares, and components by issuing commands to the SCSI-3 storage array's base address (LUN 0). The application client may directly address peripheral devices and volume sets by using eight byte LUN fields (see 5.2.1.2). For SCSI-3 storage array devices that conform to the SCSI-3 Interlocked Protocol Standard a method has been defined using a modified IDENTIFY message (see A.1) and a LUN mapping page (see 6.9.1.1) to allow direct addressing of peripheral devices and volume sets that conform to the SCSI-3 storage array addressing model.

All peripheral device addresses, except the base address, default to vendor specific values. All component device, redundancy group, spare, and volume set addresses may default to vendor specific values or may be defined by an application client during configuration.

#### 5.2.1.1 SCSI-3 storage array base address

All SCSI-3 storage arrays shall accept a LUN value of zero as a valid address. For SCSI-3 storage arrays that have more than one logical unit, logical unit zero shall be the logical unit that an application client addresses to configure an SCSI-3 storage array and to determine information about the target and the logical units contained within the target. INQUIRY commands to an SCSI-3 storage array base address shall return a device type of array controller device.

To address the base address of the SCSI-3 storage array the peripheral device address method shall be used.

#### 5.2.1.2 Eight byte LUN structure

The eight byte LUN structure (see table 3) allows up to four levels of devices to be addressed under a single target. Each level shall use bytes 0-1 to define the address and/or location of the SCSI device to be addressed on that level.

The eight byte LUN structure defined in this standard shall apply to SCSI-3 storage array devices that

conform to the SCSI-3 Controller Command.

If the LUN indicates that the command is to be passed to the next layer then the current layer shall use bytes 0-1 of the eight byte LUN structure to determine the address of the device to which the command is to be sent. When the command is sent to the target the eight byte LUN structure that was received shall be adjusted to create a new eight byte LUN structure (see table 2).

SCSI-3 storage arrays shall keep track of the necessary addressing information to allow reconnection to the correct task during reselection.

Table 2 - Eight byte LUN structure adjustments

Byte position					
Old		New			
0 - 1	Moves to	Not used			
2 - 3	Moves to	0 - 1			
4 - 5	Moves to	2 - 3			
6 - 7	Moves to	4 - 5			

Bytes six and seven of each new eight byte LUN structure shall be set to zero.

Table 3 - Eight byte LUN structure

Bit Byte	7	6	5	4	3	2	1	0		
0		FIRST LEVEL ADDRESSING —————								
2	SECOND LEVEL ADDRESSING —————									
4 5	THIRD LEVEL ADDRESSING ————————————————————————————————————									
6 7	FOURTH LEVEL ADDRESSING —————									

The FIRST LEVEL ADDRESSING field indicates the first level address of a peripheral device or volume set. See table 4 for a definition of the FIRST LEVEL ADDRESSING field.

The SECOND LEVEL ADDRESSING field indicates the second level address of a peripheral device or volume set. See table 4 for a definition of the SECOND LEVEL ADDRESSING field.

The THIRD LEVEL ADDRESSING field indicates the third level address of a peripheral device or volume set. See table 4 for a definition of the THIRD LEVEL ADDRESSING field.

The FOURTH LEVEL ADDRESSING field indicates the fourth level address of a peripheral device or volume set.

See table 4 for a definition of the FOURTH LEVEL ADDRESSING field.

Table 4 - FIRST LEVEL ADDRESSING field, SECOND LEVEL ADDRESSING field, and FOURTH LEVEL ADDRESSING field

Bit Byte	7	6	5	4	3	2	1	0		
n-1	ADDRESS	METHOD								
n	ADDRESS METHOD SPECIFIC									

The ADDRESS METHOD field defines the contents of the ADDRESS METHOD SPECIFIC field. See table 5 for the defined address methods.

Table 5 - ADDRESS METHOD

Codes	Description
10b	Logical unit addressing method
00b	Peripheral device addressing method
01b	Volume set addressing method
11b	Reserved

See 5.2.1.5 and 5.2.1.8 for the definitions of the ADDRESS METHOD SPECIFIC field.

#### 5.2.1.3 Component device address method

A component shall only be addressed by addressing the base address of the SCSI-3 storage array that controls or will control the component device. For information on addressing the base address see 5.2.1.1.

#### 5.2.1.4 Logical unit address method

All SCSI commands are allowed when the logical unit address method is selected, however logical units and SCSI-3 storage arrays are only required to support mandatory SCSI commands. SCSI-3 storage arrays are not required to honor pass-through requests from the application client. Any command that is not supported or passed-through shall be terminated with a CHECK CONDITION status. The sense key shall be set to ILLEGAL REQUEST and the additional sense code shall be set to INVALID COMMAND OPERATION CODE.

If the logical unit addressing method is selected the SCSI-3 storage array shall relay the received command, if supported, to the addressed logical unit. See table 6 for the definition of the ADDRESS METHOD SPECIFIC field used when the logical unit addressing method is selected.

Table 6 - Logical unit addressing

Bit Byte	7	6	5	4	3	2	1	0	
n-1	1	0	TARGET						
n	BUS			LUN					

The TARGET field indicates the target address of the peripheral device to which the SCSI-3 storage array shall relay the received command. The TARGET field indicates the address of the target on the bus indicated by the BUS NUMBER field that the received command shall be relayed to.

NOTE 4 - The value of targets within the TARGET field are defined by individual standards. (e.g., SCSI-3 Parallel Interface Standard defines targets to be in the range 0-7, 0-15, and 0-31).

The BUS NUMBER field indicates the location of the bus that the SCSI-3 storage array shall use to relay the received command.

The LUN field indicates the address of the logical unit to which the SCSI-3 storage array shall relay the received command. The LUN field indicates the address of the logical unit within the target indicated by the TARGET field that the received command shall be relayed to.

#### 5.2.1.5 Peripheral device address method

All SCSI commands are allowed when the peripheral address method is selected, however peripheral devices and SCSI-3 storage arrays are only required to support mandatory SCSI commands. SCSI-3 storage arrays are not required to honor pass-through requests from the application client. Any command that is not supported or passed-through shall be terminated with a CHECK CONDITION status. The sense key shall be set to ILLEGAL REQUEST and the additional sense code shall be set to INVALID COMMAND OPERATION CODE.

If the peripheral device addressing method is selected the SCSI-3 storage array shall relay the received command, if supported, to the addressed peripheral device providing a bypass of the SACL. See table 7 for the definition of the ADDRESS METHOD SPECIFIC field used when the peripheral device addressing method is selected.

Table 7 - Peripheral device addressing

Bit Byte	7	6	5	4	3	2	1	0
n-1	0	0	BUS NUMBER					
n	TARGET/LUN							

The BUS NUMBER field indicates the location of the bus that the SCSI-3 storage array shall use to relay the received command.

The TARGET/LUN field indicates the address of the peripheral device/LUN to which the SCSI-3 storage array shall relay the received command. If the BUS NUMBER field is set to zero the TARGET/LUN field indicates the address of the logical unit to relay the received command to, is located within the current level of the

SCSI-3 storage array. If the bus number field is not zero the TARGET/LUN filed indicates the address of the target on the bus indicated by the bus number field that the received command shall be relay to. The logical unit to relay the received command to shall be LUN zero.

The base device located within the current level shall be addressed by a BUS NUMBER field and a TARGET/LUN field of all zeros.

NOTE 5 - The value of targets within the TARGET/LUN field are defined by individual standards. (e.g., SCSI-3 Parallel Interface Standard defines targets to be in the range 0-7, 0-15, and 0-31).

#### 5.2.1.6 Redundancy group address method

A redundancy group shall only be addressed by addressing the base address of the SCSI-3 storage array that controls or will control the redundancy group. For information on addressing the base address see 5.2.1.1.

#### 5.2.1.7 Spare address method

A spare shall only be addressed by addressing the base address of the SCSI-3 storage array that controls or will control the spare. For information on addressing the base address see 5.2.1.1.

#### 5.2.1.8 Volume set address method

The volume set address method points to the SACL that executes the command using the algorithms defined by the configuration.

NOTE 6 - The volume set might not be under the control of the addressed SCSI-3 storage array. It is allowed to be in an SCSI-3 storage array lower in the tree structure.

All SCSI commands are allowed when the volume set address method is used, however volume sets are not required to support all SCSI commands. Any command that is not supported shall terminate in error.

In the response to an INQUIRY command the addressed volume set shall return a valid SCSI-3 peripheral device type.(e.g., direct access device, streaming device, etc.)

When the volume set addressing method is selected the SCSI-3 storage array shall use a SACL at the current level to address peripheral devices as required to execute the received command. See table 8 for the definition of the ADDRESS METHOD SPECIFIC field used when the volume set addressing method is selected.

Bit 7 6 5 4 3 2 1 0 Byte n-1 0 (MSB) 1 LUN (LSB)

Table 8 - Volume set addressing

The LUN field indicates the address of the volume set that the SCSI-3 storage array shall direct the received command to.

#### 5.2.2 SCSI-3 storage array objects

An SCSI-3 storage array consists of several objects that are configured to create an operating device. The rules for configuring objects and their interactions are defined in the following clauses. An SCSI-3 storage array shall save the current configuration throughout all task management functions and power conditions.

NOTE 7 - The configuration becomes the current configuration on successful completion of a configuration command.

#### The objects are:

- a) component device;
- b) peripheral device;
- c) p extent;
- d) ps extent;
- e) redundancy group;
- f) spare;
- g) volume set.

#### 5.2.2.1 Adding objects

Objects that have been added to a SCSI-3 storage array shall be addressable (see 5.2.1) by an application client.

Peripheral devices and component devices may be logically added to a SCSI-3 storage array. The ADD PERIPHERAL DEVICE/COMPONENT DEVICE service action (see 6.2.1.1) adds objects. Adding a peripheral device or a component device may or may not automatically cause the device to become part of a configuration.

#### 5.2.2.2 Association of objects

Objects become associated during the configuration of SCSI-3 storage arrays. The create/modify service actions for redundancy groups (see 6.4.1.2) and volume sets (see 6.6.1.3) create associations and the delete service actions (see 6.4.1.3 and 6.6.1.4) remove associations. The rules for objects that are associated are explicitly defined throughout this clause and within the create/modify service actions.

An SCSI-3 storage array may create associations through mechanisms other than the create/modify service actions defined in this document (e.g., by factory settings or by external configuration facilities). Whether such associations may be modified by the create/modify service actions specified by this standard or by other mechanisms is vendor specific. The only requirement on such associations is that they shall be reported using the report service actions defined in this standard.

NOTE 8 - One example of an association would be to associate a group of p\_extents with a redundancy group using a CREATE/MODIFY REDUNDANCY GROUP service action.

#### 5.2.2.3 Attachment of objects

Objects shall only be attached to component devices. The ATTACH TO COMPONENT DEVICE service action (6.2.1.2) establishes attachments.

The behavior of attachments and their interactions with component devices are vendor specific.

The attachment of component devices shall not be reflexive (i.e. attaching LUN\_C 1 to LUN\_C 2 does not attach LUN\_C 2 to LUN\_C 1).

NOTE 9 - One example of an attachment would be to attach a redundancy group to a specific power supply. This attachment could mean that the power supply would only supply power to that redundancy

group. Another example would be to attach a controller card to another controller card. This attachment could mean that the work load is shared between the two controllers.

An SCSI-3 storage array may create attachments through mechanisms other than the attach service actions defined in this document (e.g., by factory settings or by external configuration facilities). Whether such attachments may be modified by the attach service actions specified by this standard or by other mechanisms is vendor specific. The only requirement on such attachments is that they shall be reported using the report service actions defined in this standard.

#### 5.2.2.4 Covering of objects

Any object or group of objects may be covered by a like object. The SPARE(OUT) command (see 6.8.1) establishes the covering of the objects.

When an object or group of objects are covered and there is a failure, the covering object shall assume all the characteristics of the failed object, in effect doing an automatic exchange. The length of time the exchange stays in effect is vendor specific.

Objects may be covered by a SCSI-3 storage array without any spare requests being issued from an application client. The SCSI-3 storage array may have covered objects based on internal requirements.

NOTE 10 - One example of covering would be for a peripheral device to cover like peripheral device(s) within a redundancy group. This would cause any peripheral device that failed within the covered redundancy group to be replaced by the peripheral device covering that redundancy group. Two controllers could also be configured to cover one another, using two spare service actions, in which case if either fails the other will take over the entire work load.

#### 5.2.2.5 Exchanging objects

A peripheral device, p\_extent, or component device may be exchanged with a like device. The exchange service actions (see 6.2.1.4 and 6.2.1.5) are used to exchange objects. When an old peripheral device, p\_extent, or component device is exchanged, the new peripheral device, p\_extent, or component device takes on all the characteristics of the old peripheral device, p\_extent, or component device (e.g., redundancy group, volume set mappings, attachments, etc.). An exact copy of any protected space contents and/or check data on the old device shall be replicated on the new device. The characteristics of the old peripheral device are vendor specific.

#### 5.2.2.6 Protected objects

Protected objects are objects that are able to tolerate one or more objects failing without any loss of user data or loss of SCSI-3 storage array availability.

#### 5.2.2.7 Removing objects

Objects that have been removed from a SCSI-3 storage array shall not be addressable by an application client, until the object is re-added or recreated. The remove service actions (see 6.2.1.7, 6.4.1.3 and 6.8.1.3) are used to remove objects.

Any object may be removed from a configuration. However, some restrictions may apply as to when an object may be removed. Those restrictions are defined in 6.2.1.7, 6.4.1.3, and 6.8.1.3.

When the object is removed all attachments, associations, and covers relating to the object being removed are erased from any configurations containing the object. Any addressable logical block addresses within a removed volume set shall become unassigned protected space. Any addressable logical block addresses within a removed redundancy group or spare shall become unassigned p\_extent space.

5.2.2.8 Component device

See 3.1.10 for the definition of component devices.

5.2.2.9 Peripheral device

See 3.1.26 for the definition of peripheral devices.

5.2.2.10 P\_extent

See 3.1.25 for the definition of p\_extents.

P\_extents are used by the application client to create and modify redundancy groups and spares. A single assigned p\_extent or unassigned p\_extent that contains no check data may be configured into one or more redundancy groups. A single assigned p\_extent or unassigned p\_extent may be configured into one or more spares. A single p\_extent shall not be associated with a redundancy group and configured as a spare at the same time. After a p\_extent has been configured into a redundancy group or as a spare it becomes an assigned p\_extent.

Any addressable logical block addresses within an operating peripheral device connected within a SCSI-3 storage array that have not been configured into a redundancy group shall be unassigned p\_extents. Before assignment, all the consecutive addressable logical block addresses on a single peripheral device shall be grouped into a single unassigned p\_extent.

The application client uses a REPORT ASSIGNED/UNASSIGNED P\_EXTENT service action (see 6.1.1.1) to determine the unassigned p\_extents.

A single unassigned p\_extent may be subdivided into one or more p\_extents by the application client. The subdivided p\_extents may be used within one or more CREATE/MODIFY REDUNDANCY GROUP service actions.

5.2.2.11 Ps\_extent

See 3.1.28 for the definition of ps\_extent.

Ps\_extents are used by the application client to create and modify volume sets. Ps\_extents are created on the successful completion of a CREATE/MODIFY REDUNDANCY GROUP service action (6.4.1.2.) A single ps\_extent shall only be configured into one volume set. After a ps\_extent has been configured into a volume set it becomes an assigned ps\_extent.

Any addressable logical block addresses, not defined as containing check data, within an operating peripheral device connected within a SCSI-3 storage array that have not been configured into a volume set shall be unassigned ps\_extents. All the consecutive addressable logical block addresses on a single peripheral device, excluding logical blocks defined as containing check data, shall be grouped into a single unassigned ps\_extent.

The application client uses a REPORT UNASSIGNED REDUNDANCY GROUP SPACE service action (see 6.3.1.2) to determine the unassigned ps\_extents.

A single unassigned ps\_extent may be subdivided into one or more ps\_extents by the application client. The subdivided ps\_extents may be used within one or more CREATE/MODIFY VOLUME SET service actions.

A ps\_extent is different from a p\_extent in that the ps\_extent does not include any logical block addresses that have been mapped as check data where the p\_extent includes all addressable logical blocks within the selected range on a peripheral device.

#### 5.2.2.12 Redundancy group

See 3.1.31 for the definition of redundancy group.

Redundancy groups are created by the application client to protect user data contained within volume sets by mapping check data within a redundancy group. Redundancy groups may overlap, however, the underlaying p\_extents within the overlap shall not contain any check data.

As a result of a successful creation of a redundancy group ps\_extents are formed. The ps\_extents then may be used by the application client to create volume sets.

Figure 10 shows the relationship between the check data and protected space before any volume sets have been defined.




Figure 10 - Single redundancy group

Figure 11 shows the relationship between the check data and protected space after two volume sets have been defined within the redundancy group.




Figure 11 - Multiple volume sets associated with a single redundancy group

The application client may map check data within a redundancy group using the following three parameters:

- a) START CHECK DATA INTERLEAVE UNIT field;
- b) NUMBER OF UNITS OF CHECK DATA field;
- c) NUMBER OF UNITS OF USER DATA field.

The START CHECK DATA INTERLEAVE UNIT field contains the location of the first unit of check data within the p\_extent. There is a unique START CHECK DATA INTERLEAVE UNIT field for each p\_extent.

The NUMBER OF UNITS OF CHECK DATA field contains the number of consecutive units to be reserved for check data within the p\_extent. There is a unique NUMBER OF UNITS OF CHECK DATA field for each p\_extent.

The NUMBER OF UNITS OF USER DATA field contains the number of consecutive units to be reserved for protected space within the p\_extent. There is a unique NUMBER OF UNITS OF USER DATA field for each p\_extent.

The flow chart in figure 12 is an example of an implementation of a SCSI-3 storage array redundancy group being configured with a check data mapping of XOR redundancy. The check data mapping routine uses the START CHECK DATA INTERLEAVE UNIT field, NUMBER OF UNITS OF CHECK DATA field, and NUMBER OF UNITS OF USER DATA field and assumes a non-zero value for the NUMBER OF UNITS OF CHECK DATA field and the NUMBER OF UNITS USER DATA field.




Figure 12 - Redundancy group check data mapping flow chart

The application may choose any one of the following methods of check data mapping within a redundancy group:

a) No redundancy;

#### X3T10/1047D revision 6c

- b) Copy redundancy;
- c) XOR redundancy;
- d) P+Q redundancy;
- e) Vendor specific redundancy.

### 5.2.2.12.1 No redundancy method of check data mapping

In a redundancy group that the application client requests no redundancy, user data is not protected. If this method is requested then the following fields in the CREATE/MODIFY REDUNDANCY GROUP service action (see 6.4.1.2) shall all be set as indicated:

- a) GRANULARITY OF UNITS field = 0;
- b) START CHECK DATA INTERLEAVE UNIT field = 0;
- c) NUMBER OF UNITS OF CHECK DATA field = 0;
- d) NUMBER OF UNITS OF USER DATA field = set to desired value.

#### 5.2.2.12.2 Copy redundancy method of check data mapping

In a redundancy group that the application client requests copy redundancy all user data is replicated on all the p\_extents listed in the CREATE/MODIFY REDUNDANCY GROUP service action (6.4.1.2). If this method is requested then the following fields in the CREATE/MODIFY REDUNDANCY GROUP service action (see 6.4.1.2) shall be set as indicated:

- a) GRANULARITY OF UNITS field = logical block;
- b) START CHECK DATA INTERLEAVE UNIT field = 0;
- c) NUMBER OF UNITS OF CHECK DATA field = 0;
- d) NUMBER OF UNITS OF USER DATA field = set to desired value.

For copy redundancy the NUMBER OF UNITS OF USER DATA field shall be equal for all the p\_extents within a single CREATE/MODIFY REDUNDANCY GROUP service action.

#### 5.2.2.12.3 XOR or P+Q redundancy method of check data mapping

In a redundancy group that the application client requests XOR redundancy, or P+Q redundancy the user data is protected by use of check data located within the check data areas. The check data mapping is defined by the check data interleave fields. If this method is requested then the following fields in the CREATE/MODIFY REDUNDANCY GROUP service action (see 6.4.1.2) shall be set as indicated:

- a) GRANULARITY OF UNITS field = set to desired value;
- b) START CHECK DATA INTERLEAVE UNIT field = set to desired value;
- c) NUMBER OF UNITS OF CHECK DATA field = set to desired value;
- d) NUMBER OF UNITS OF USER DATA field = set to desired value.

# 5.2.2.12.4 Vendor specific redundancy method of check data mapping

In a redundancy group for which the application client requests a redundancy type method of vendor specific redundancy, the user data is protected in a vendor specific manner.

### 5.2.2.13 Spares

# See 3.1.37 for the definition of spares.

Spares are created by the application client to allow a failed p\_extent, peripheral device, or component device to be automatically exchanged (see 5.2.2.5). P\_extents shall only be exchanged with p\_extents, peripheral devices shall only be exchanged with peripheral devices, and component devices shall only be exchanged with component devices. A redundancy group or peripheral device that contains a failed range of LBA\_P(s), a failed peripheral device, or a failed component shall be covered by a spare before an

automatic exchange is allowed to occur.

After an automatic exchange the spare takes on all the characteristics of the failed p\_extent, peripheral device, or component device. After the automatic exchange the covering p\_extent, peripheral device, or component device shall no longer be available to cover another object. The failed p\_extent, peripheral device, or component device shall be marked as broken.

The method for replacing the failed p\_extent, peripheral device, or component device and restoring the spare is vendor specific.

NOTE 11 - One method of replacing a failed p\_extent, peripheral device, or component device would be to automatically exchange a new p\_extent, peripheral device, or component device with the spare that covered the failure. After a successful exchange the spare is available to cover failures and the failed p\_extent, peripheral device, or component device is as it was before the failure.

NOTE 12 - Another method would be to automatically add the new p\_extent, peripheral device, or component device into the SCSI-3 storage array, delete the original covering spare, then create a new spare with the new p\_extent, peripheral device, or component device that would cover the same p\_extent, peripheral device, or component device as the original spare.

#### 5.2.2.14 Volume sets

See 3.1.47 for the definition of volume sets.

Volume sets are created by the application client to provide a contiguous range of logical block addresses for reading and writing user data. Volume sets shall not overlap and shall be independent from one another.

The application client issues a REPORT UNASSIGNED REDUNDANCY GROUP SPACE service action (see 6.3.1.2) to determine the boundaries of any unassigned protected space. The unassigned protected space may be used to create volume sets or to expand existing volume sets. This service action provides information to the application client so it can place volume sets on specific peripheral devices.

Figure 13 shows a relationship between the check data and protected space before any volume sets have been defined.




Figure 13 - Multiple redundancy groups

Figure 14 shows the relationship between check data, user data and protected space after a single volume set has been defined across the two redundancy groups.




Figure 14 - Single volume set associated with multiple redundancy groups

NOTE 13 - The volume set in figure 14 is ready to receive user data.

The application client may map user data within a volume set using the following three parameters:

- a) USER DATA STRIPE DEPTH field;
- b) PS EXTENT STRIPE LENGTH field;
- c) PS\_EXTENT INTERLEAVE DEPTH field.

The USER DATA STRIPE DEPTH field contains the number of contiguous units to count within a ps\_extent before proceeding to the next ps\_extent. There is a USER DATA STRIPE DEPTH field for each ps\_extent.

The PS\_EXTENT STRIPE LENGTH field contains the number of contiguous ps\_extents to count before looping back to the first ps\_extent of the current stripe.

The PS\_EXTENT INTERLEAVE DEPTH field contains the number of stripes to count before continuing onto the next consecutive ps\_extent beyond the current stripe.

The ps\_extent interleave depth is only used if the ps\_extent stripe length is not equal to the number of ps extents.

The flow chart in figure 15 and figure 16 is an example of an implementation of a SCSI-3 storage array volume set user data mapping routine using the USER DATA STRIPE DEPTH field, PS\_EXTENT STRIPE length field, and ps\_extent interleave depth field. For simplicity the user data stripe depth field is assumed to be the same value for all the ps\_extents in the flow chart.




Figure 15 - Volume set user data mapping flow chart (part 1)




Figure 16 - Volume set user data mapping flow chart (part 2)

Figure 17 shows the most general implementation of the three parameters used to map the user data.




Figure 17 - Volume set user data mapping flow

#### 5.2.3 SCSI-3 storage array operations

### 5.2.3.1 Rebuild operation

The rebuild operation recreates protected space contents or any check data within a p\_extent using check data and protected space contents from the remaining p\_extents within the redundancy group. The regenerated protected space contents or any recalculated check data shall be written to the p\_extent being rebuilt.

#### 5.2.3.2 Recalculate operation

The recalculate operation recreates check data from protected space contents. The recreated check data shall be written to the check data location being recalculated.

# 5.2.3.3 Regenerate operation

The regenerate operation recreates inaccessible protected space contents from accessible check data and protected space contents. The recreated protected space contents is not saved after it is transferred to the application client.

### 5.2.3.4 Verify operation

The verify operation recreates check data from protected space contents and compares the recreated check data with the current check data. If the recreated check data does not match the current check data an exception condition shall be created. See 6.6.1.6 and 6.4.1.7 for exception handling information.

#### 5.2.4 SCSI-3 storage array states

A SCSI-3 storage array defines states for each type of logical unit that may be connected within the SCSI-3 storage array or configured by an application client. The state gives an application client information on the current operating condition of selected logical unit(s).

The state of a SCSI-3 storage array (LUN 0), a peripheral device, or a volume set may be determined by using the same methods as any other SCSI device (e.g., a TEST UNIT READY command followed by a REQUEST SENSE command). However, more detailed state information may be obtained by issuing a REPORT STATES service action.

The REPORT STATES service action (see 6.1.1.7) reports all available state information for the selected logical unit(s) (e.g., If a logical unit has two states, both of those states are reported in the REPORT STATES service action.). States are also returned to the application client in many of the report service actions and only one state shall be returned per report service action. The priority of reporting multiple states is vendor specific.

#### 5.2.5 SCSI-3 storage array exception conditions

Exception conditions inform an application client that:

- a) a change occurred in the physical configuration;
- b) a change occurred in a volume set configuration;
- c) a change occurred in a redundancy group configuration;
- d) a change occurred in a spare;
- e) a change occurred in the operation state of the SACL;
- f) a repair action is requested (e.g., device is predicting failure);
- g) a repair action is required to restore the volume sets availability (e.g., power supply failure);
- h) a repair action is required to restore the volume sets level of integrity (e.g., device fails); or
- i) an error occurred.

#### X3T10/1047D revision 6c

Which exception conditions are returned and how often they are returned is based on configuration requests received from an application client.

Not all exception conditions reported from an SCSI-3 storage array indicate a task failed. Some are informational, in that, they provide the application client information on the condition of the SCSI-3 storage array. (e.g., the SCSI-3 storage array is predicting a failure of a logical unit, something is broken but the SCSI-3 storage array is still operational, etc). The method of reporting informational exception conditions is defined in the SCSI-3 Primary Commands Standard.

# 6 Commands for SCSI-3 storage array devices

The operation codes for commands that apply only to SCSI-3 storage array devices are listed in table 9.

Table 9 - Commands for SCSI storage array devices

Command Name	Operation code	Туре	Subclause
INQUIRY	12h	М	SPC
LOG SELECT	4Ch	0	SPC
LOG SENSE	4Dh	0	SPC
MAINTENANCE(IN)	A3h	М	6.1
MAINTENANCE(OÚT)	A4h	0	6.2
MODE SELECT(6)	15h	0	SPC
MODE SELECT(10)	55h	0	SPC
MODE SENSE(6)	1Ah	0	SPC
MODE SENSE(10)	5Ah	0	SPC
PERSISTENT RESERVE IN	5Eh	0	SPC
PERSISTENT RESERVE OUT	5Fh	0	SPC
PORT STATUS	1Fh	0	SPC
READ BUFFER	3Ch	Ο	SPC
RECEIVE DIAGNOSTICS RESULTS	1Ch	Ο	SPC
REDUNDANCY GROUP(IN)	BAh	M	6.3
REDUNDANCY GROUP(OUT)	BBh	0	6.4
RELEASE(6)	17h	0	SPC
RELEASE(10)	57h	0	SPC
REPORT LUNS	A0h	M	SPC
REQUEST SENSE	03h	M	SPC
RESERVE(6)	16h	0	SPC
RESERVE(10)	56h	0	SPC
SEND DIAGNOSTIC	1Dh	0	SPC
SPARE(IN)	BCh	M	6.7
SPARE(OUT)	BDh	0	6.8
START STOP UNIT	1Bh	0	SPC
TEST UNIT READY	00h	М	SPC
VOLUME SET(IN)	BEh	М	6.5
VOLUME SET(OUT)	BFh	0	6.6
WRITE BUFFER	3Bh	0	SPC

Key: M = Command implementation is mandatory.
O = Command implementation is optional.

SPC = SCSI-3 Primary Commands Standard.

# 6.1 MAINTENANCE(IN) command

# 6.1.1 MAINTENANCE(IN) command service actions

The service actions for the MAINTENANCE(IN) command are listed in table 10.

Table 10 - Service actions for MAINTENANCE(IN) command

Service name	Service actions	Туре	Subclause
REPORT ASSIGNED/UNASSIGNED P_EXTENT REPORT COMPONENT DEVICE REPORT COMPONENT DEVICE ATTACHMENTS REPORT PERIPHERAL DEVICE	00h 01h 02h 03h	M M M	6.1.1.1 6.1.1.2 6.1.1.3 6.1.1.4
REPORT PERIPHERAL DEVICE ASSOCIATIONS REPORT PERIPHERAL DEVICE/COMPONENT DEVICE	04h	M	6.1.1.5
IDENTIFIER REPORT STATES	05h 06h	M M	6.1.1.6 6.1.1.7
Reserved Vendor specific	07h-17h 18h-1Fh		<b></b>
Key: M = Service action implementation is mandatory. O = Service action implementation is optional.		1	

# 6.1.1.1 REPORT ASSIGNED/UNASSIGNED P\_EXTENT service action

The REPORT ASSIGNED/UNASSIGNED P\_EXTENT service action (see table 11) requests that information regarding assigned p\_extents or unassigned p\_extents within the target be sent to the application client. See 5.2.2.10 for a definition of assigned and unassigned p\_extents.

Table 11 - REPORT ASSIGNED/UNASSIGNED P\_EXTENT service action

Bit Byte	7	6	5	4	3	2	1	0			
0		OPERATION CODE (A3h)									
1		RESERVED SERVICE ACTION (00h)									
2		RESERVED									
3		RESERVED									
4	(MSB)										
5		-	LUN_P (LSB)								
6	(MSB)										
7		-		ALL OCATIO	NI I FNOTU		•				
8		-		ALLOCATIO	IN LENGTH		•				
9		-	(LSB								
10		RESERVED ASSIGN RESERVED						RPTSEL			
11				CON	TROL						

The LUN\_P field specifies the address of the peripheral device from which the p\_extent(s) shall be reported per table 12. If the requested logical unit has not been added to the target the command shall be terminated with a CHECK CONDITION status. The sense key shall be set to ILLEGAL REQUEST, and the additional sense code set to LOGICAL UNIT NOT SUPPORTED.

A report selected bit (RPTSEL) of zero indicates the target shall report all the assigned p\_extent(s) or all the unassigned p\_extents within the target. The LUN\_P field shall be ignored when the RPTSEL bit is zero. A RPTSEL bit of one indicates the target shall report only the assigned p\_extent(s) or the unassigned p\_extents on the peripheral device indicated in the LUN\_P field.

A report assigned p\_extents bit (ASSIGN) of zero indicates the target shall report unassigned p\_extents. A ASSIGN bit of one indicates the target shall report assigned p\_extents.

The REPORT ASSIGNED/UNASSIGNED P\_EXTENT parameter list (see table 12) contains a four-byte header that contains the length in bytes of the parameter list and a list of ASSIGNED/UNASSIGNED P\_EXTENT DESCRIPTORS.

Table 12 - REPORT ASSIGNED/UNASSIGNED P\_EXTENT parameter list

Bit Byte	7	6	5	4	3	2	1	0			
0	(MSB)										
1		ACC	ASSIGNED/UNASSIGNED P_EXTENT(S) LIST LENGTH (n-3) —								
2		. A55									
3		•									
		ASSIGNED/UNASSIGNED P_EXTENT(s) (if any)									
4		. Δ	SSIGNED/UN	NASSIGNED I	P EYTENT N	ESCRIPTOR	0				
19		,	OSIGNED/OI	VASSIGIVED I	_LXTENT D	LOCKII TOK	0				
					•						
n-15		. Д	ASSIGNED/UNASSIGNED P_EXTENT DESCRIPTOR X								
n			.00.0.425/01	., .00.014201							

The ASSIGNED/UNASSIGNED P\_EXTENT(S) LIST LENGTH field specifies the length in bytes of the following ASSIGNED/UNASSIGNED P\_EXTENT DESCRIPTOR(s).

The ASSIGNED/UNASSIGNED P\_EXTENT DESCRIPTOR is defined in table 13.

Table 13 - Data format of ASSIGNED/UNASSIGNED P\_EXTENT DESCRIPTOR

Bit Byte	7	6	5	4	3	2	1	0			
0		D EVTENT DESCRIPTOR									
11		P_EXTENT DESCRIPTOR									
12		RESERVED									
13				RESE	RVED						
14		PERIPHERAL DEVICE TYPE									
15	RESERVED			P_	EXTENT STA	·ΤΕ					

The P\_EXTENT DESCRIPTOR is defined in table 14.

The PERIPHERAL DEVICE TYPE field contains the type of SCSI device that contains the p\_extent defined by the P\_EXTENT DESCRIPTOR. See the SCSI-3 Primary Commands Standard for a list of SCSI peripheral device types.

The P\_EXTENT STATE field is defined in table 40.

Table 14 - Data format of P\_EXTENT DESCRIPTOR

Bit Byte	7	6	5	4	3	2	1	0			
0	(MSB)			1.116	I D						
1		•		LUI	<b>_</b> F			(LSB)			
2	(MSB)										
3		•	START LBA_P								
4		•									
5		•									
6	(MSB)										
7		•		NI IMPED O							
8		•		NUMBER O	F LBA_P(S)						
9		•									
10	(MSB)		NUMBER OF BYTES PER LBA_P								
11		•	NUI	IVIDER OF BY	IES PER LB/	<u></u>		(LSB)			

The LUN\_P field contains the address of the peripheral device that contains the p\_extent.

The START LBA\_P field contains the first addressable logical block address of the p\_extent.

The NUMBER OF LBA\_P(S) field contains the capacity of the p\_extent in blocks.

The NUMBER OF BYTES PER LBA\_P field contains the size, in bytes, of the blocks in the p\_extent. A value of zero in the NUMBER OF BYTES PER LBA\_P field shall indicate the NUMBER OF BYTES PER LBA\_P is variable.

# 6.1.1.2 REPORT COMPONENT DEVICE service action

The REPORT COMPONENT DEVICE service action (see table 15) requests that information regarding component device(s) within the target be sent to the application client.

Table 15 - REPORT COMPONENT DEVICE service action

Bit Byte	7	6	5	4	3	2	1	0			
0		OPERATION CODE (A3h)									
1		RESERVED SERVICE ACTION (01h)									
2		RESERVED									
3		RESERVED									
4	(MSB)	- LUN_C									
5		•		LUI	1_C			(LSB)			
6	(MSB)										
7		•		ALL 00ATIO	NI ENOTH						
8		•		ALLOCATIO	IN LENGTH						
9		-						(LSB)			
10		RESERVED									
11				CON	TROL						

The LUN\_C field specifies the address of the component device that shall be reported per table 16. If the requested logical unit has not been added to the target, the command shall be terminated with a CHECK CONDITION status. The sense key shall be set to ILLEGAL REQUEST, and the additional sense code set to LOGICAL UNIT NOT SUPPORTED.

A report selected bit (RPTSEL) of zero indicates the target shall report on all the component device(s) within the target. The LUN\_C field shall be ignored when the RPTSEL bit is zero. A RPTSEL bit of one indicates the target shall report only on the component device indicated in the LUN\_C field.

The REPORT COMPONENT DEVICE parameter list (see table 16) contains a four-byte header that contains the length in bytes of the parameter list and a list of COMPONENT DEVICE DESCRIPTORS.

Table 16 - REPORT COMPONENT DEVICE parameter list

Bit Byte	7	6	5	4	3	2	1	0				
0	(MSB)		COMPONENT DEVICE LIST LENGTH (n-3)									
1		•										
2		•										
3		(LSB)										
		COMPONENT DEVICE(S) (if any)										
4			COMP	ONENT DEVI	CE DESCRIB	тор О						
7			COMP	ONENT DEVI	GE DESCRIP	TOR U						
		· ·										
n-3			COMPONENT DEVICE DESCRIPTOR X									
n												

The COMPONENT DEVICE LIST LENGTH field specifies the length in bytes of the following COMPONENT DEVICE DESCRIPTOR(s).

The COMPONENT DEVICE DESCRIPTOR is defined in table 17.

Table 17 - Data format of **component Device Descriptor** 

Bit Byte	7	6	5	4	3	2	1	0			
0		COMPONENT DEVICE TYPE									
1	REPLACE	REPLACE COMPONENT DEVICE STATE									
2	(MSB)										
3				LUI	N_C			(LSB)			

The COMPONENT DEVICE TYPE field contains the type of component device. See table 18 for a list of component device types.

The component device types table (see table 18) contains a list of non-data type devices the target may address as component devices.

TABLE 18 - COMPONENT DEVICE TYPES

Code	Description
00h	Controller electronics that contain a SACL
01h	Non-volatile cache
02h	Power supply
03h	Uninterruptable power supply
04h	Display
05h	Key pad entry
06h	Fan
07h-7Fh	Reserved
80h-FFh	Vendor specific

The component device STATE field is defined in table 42.

A replace bit (REPLACE) of zero indicates the component device indicated in the LUN\_C field is not a replaceable unit. A replace bit of one indicates the component device indicated in the LUN\_C field is a replaceable unit.

The LUN\_C field contains the address of the component device.

# 6.1.1.3 REPORT COMPONENT DEVICE ATTACHMENTS service

The REPORT COMPONENT DEVICE ATTACHMENTS service action (see table 19) requests that information regarding logical units that are attached to component device(s) be sent to the application client.

Table 19 - REPORT COMPONENT DEVICE ATTACHMENTS service action

Bit Byte	7	6	5	4	3	2	1	0		
0	OPERATION CODE (A3h)									
1		RESERVED SERVICE ACTION (02h)								
2		RESERVED								
3		RESERVED								
4	(MSB)	MSB) LUN_C								
5		-		LUI	1_C			(LSB)		
6	(MSB)									
7		-		ALLOCATIO	NI I FNOTU					
8		-		ALLOCATIO	IN LENGTH					
9		-						(LSB)		
10		RESERVED								
11				CON	TROL					

The LUN\_C field specifies the address of the component device for which the target shall report information per table 20. If the requested logical unit has not been added to the target the command shall be terminated with a CHECK CONDITION status. The sense key shall be set to ILLEGAL REQUEST, and the additional sense code set to LOGICAL UNIT NOT SUPPORTED.

A report selected bit (RPTSEL) of zero indicates the target shall report on all the component device(s) within the target. The LUN\_C field shall be ignored when the RPTSEL bit is zero. A RPTSEL bit of one indicates the target shall report only on the component device indicated in the LUN\_C field.

The REPORT COMPONENT DEVICE ATTACHMENTS parameter list (see table 20) contains a four-byte header that contains the length in bytes of the parameter list and a list of COMPONENT DEVICE ATTACHMENT DESCRIPTORS.

Table 20 - REPORT COMPONENT DEVICE ATTACHMENTS parameter list

Bit Byte	7	6	5	4	3	2	1	0				
0	(MSB)											
1			COMPONENT DEVICE ATTACHMENT LIST LENGTH (n-3)									
2												
3		(LSB										
		COMPONENT DEVICE ATTACHMENT(S) (if any)										
4		CON	MPONENT DE	EVICE ATTAC		CRIPTOR (F	irst)					
x+3				(Len	gth x)							
		· ·										
n-y+1		COMPONENT DEVICE ATTACHMENT DESCRIPTOR (Last) (Length y)										
n				(Len	Jui y <i>)</i>							

The COMPONENT DEVICE ATTACHMENT LIST LENGTH field specifies the length in bytes of the following COMPONENT DEVICE ATTACHMENT DESCRIPTOR(s).

The COMPONENT DEVICE ATTACHMENT DESCRIPTOR is defined in table 21.

Table 21 - Format of **COMPONENT DEVICE ATTACHMENT DESCRIPTOR** 

Bit Byte	7	6	5	4	3	2	1	0			
0	(MSB)			1.110	1.0						
1		•		LUN	<b>1_</b> C			(LSB)			
2	(MSB)										
3		•	LOGICAL UNIT LIST LENGTH (n-3)								
			LOGICAL UNIT (S) (if any)								
4			10	GICAL UNIT	)ESCDIDTOE	ο <b>Λ</b>					
7			LO	GICAL UNIT	JESCKIF TOP	ν. Ο					
			·								
n-3		_	LOGICAL UNIT DESCRIPTOR X								
n				CIONE CIVIT	22301111101						

The LUN\_C field specifies the address of the component device to which the LOGICAL UNIT DESCRIPTOR(s) listed in the COMPONENT DEVICE ATTACHMENT DESCRIPTOR list are attached.

The LOGICAL UNIT LIST LENGTH field specifies the length In bytes of the following LOGICAL UNIT DESCRIPTOR(s).

The LOGICAL UNIT DESCRIPTOR(S) contain a list of logical units that are attached to the component device addressed in the LUN\_C field of the COMPONENT DEVICE ATTACHMENT DESCRIPTOR. See table 22 for the format of the LOGICAL UNIT DESCRIPTOR.

Table 22 - Data format of LOGICAL UNIT DESCRIPTOR

Bit Byte	7	6	5	4	3	2	1	0		
0		RESERVED								
1		RESE	RVED			LOGICAL (	JNIT TYPE			
2	(MSB)									
3		•		LU	JIN			(LSB)		

The LOGICAL UNIT TYPE field (see table 23) indicates the type of logical unit addressed in the LUN field.

Table 23 - LOGICAL UNIT types

Codes	Description
0h	Physical logical unit (peripheral device)
1h	Volume set
2h-3h	Reserved
4h	Component logical unit (component device)
5h	Redundancy group
6h	Spare
7h-Bh	Reserved
Ch-Fh	Vendor specific

The LUN field contains the logical unit number of the logical unit indicated by the LOGICAL UNIT TYPE field.

# 6.1.1.4 REPORT PERIPHERAL DEVICE service action

The REPORT PERIPHERAL DEVICE service action (see table 24) requests that information regarding peripheral device(s) within the target be sent to the application client.

Table 24 - REPORT PERIPHERAL DEVICE service action

Bit Byte	7	6	5	4	3	2	1	0			
0		OPERATION CODE (A3h)									
1		RESERVED SERVICE ACTION (03h)									
2				RESE	RVED						
3		RESERVED									
4	(MSB)	- LUN_P —									
5		-		LON	N_P			(LSB)			
6	(MSB)										
7		-		ALLOCATIO	NI I ENIOTU						
8		-		ALLOCATIC	IN LENGTH						
9		<u>-</u>	(LS								
10		RESERVED RPTMBUS RESERVED SELECT R									
11				CON	ΓROL						

The LUN\_P field specifies the address of the peripheral device that shall be reported per table 26. If the requested logical unit has not been added to the target, the command shall be terminated with a CHECK CONDITION status. The sense key shall be set to ILLEGAL REQUEST, and the additional sense code set to LOGICAL UNIT NOT SUPPORTED.

The SELECT REPORT field contains the information on which peripheral device(s) the target shall report. See table 25 for the defined states.

TABLE 25 - SELECT REPORT

Codes	Description
00b	The target shall report on all the peripheral device(s) within the target. The LUN_P field shall be ignored if this option is selected.
01b	The target shall report only on the peripheral device indicated in the LUN_P field.
10b	The target shall report all the peripheral device(s) within the target that have the state of not available. The LUN_P field shall be ignored if this option is selected.
11b	Reserved

A report multiple buses (RPTMBUS) bit of zero indicates only one LUN\_P shall be reported for each peripheral device indicated by the SELECT REPORT field. A RPTMBUS bit of one indicates all LUN\_P(s) shall be reported for each peripheral device indicated by the SELECT REPORT field.

The REPORT PERIPHERAL DEVICE parameter list (see table 26) contains a four-byte header that contains the length in bytes of the parameter list and a list of PERIPHERAL DEVICE DESCRIPTORS.

Table 26 - REPORT PERIPHERAL DEVICE parameter List

Bit Byte	7	6	5	4	3	2	1	0				
0	(MSB)		PERIPHERAL DEVICE LIST LENGTH (n-3)									
1												
2		•										
3		•										
		PERIPHERAL DEVICE(S) (if any)										
4			DEDID	HERAL DEVI	CE DESCRIP	TOP ()						
7			FLNIF	TIERAL DEVI	GE DESCRIF	TORU						
n-3			PERIP	HERAL DEVI	CE DESCRIP	TOR Y						
n			i Livii	TILIVAL DEVI	OL DEGOM!	TORK						

The PERIPHERAL DEVICE LIST LENGTH field specifies the length in bytes of the following PERIPHERAL DEVICE DESCRIPTOR(s).

The PERIPHERAL DEVICE DESCRIPTOR is defined in table 27.

Table 27 - Format of PERIPHERAL DEVICE DESCRIPTOR

Bit Byte	7	6	5	4	3	2	1	0			
0		PERIPHERAL DEVICE TYPE									
1	REPLACE	PERIPHERAL DEVICE STATE									
2	(MSB)		LUN P								
3		•		LUI	N_F			(LSB)			

The PERIPHERAL DEVICE TYPE field contains the type of SCSI device. See the SCSI-3 Primary Commands Standard for a list of SCSI peripheral device types.

The peripheral device STATE field is defined in table 40.

A replace bit (REPLACE) of zero indicates the peripheral device indicated in the LUN\_P field is not a replaceable unit. A replace bit of one indicates the peripheral device indicated in the LUN\_P field is a replaceable unit.

The LUN\_P field contains the address of the peripheral device.

# 6.1.1.5 REPORT PERIPHERAL DEVICE ASSOCIATIONS service action

The REPORT PERIPHERAL DEVICE ASSOCIATIONS service action (see table 28) requests that information regarding logical units that are associated with peripheral device(s) be sent to the application client.

Table 28 - REPORT PERIPHERAL DEVICE ASSOCIATIONS service action

Bit Byte	7	6	5	4	3	2	1	0			
0		OPERATION CODE (A3h)									
1		RESERVED SERVICE ACTION (04h)									
2		RESERVED									
3		RESERVED									
4	(MSB)	LUN_P —									
5		=		LUI	N_P		•	(LSB)			
6	(MSB)										
7		-		ALL OCATIO	NI FNOTI						
8		-		ALLOCATIC	ON LENGTH		•				
9		-	(LS								
10		RESE	RESERVED RPTMBUS RESERVED RESERVED								
11				CON	TROL	•					

The LUN\_P field specifies the address of the peripheral device that the target shall report information as to which logical unit(s) are associated with the peripheral device per table 30. If the requested logical unit has not been added to the target the command shall be terminated with a CHECK CONDITION status. The sense key shall be set to ILLEGAL REQUEST, and the additional sense code set to LOGICAL UNIT NOT SUPPORTED.

A report selected bit (RPTSEL) of zero indicates the target shall report on all the peripheral device(s) within the target. The LUN\_P field shall be ignored when the RPTSEL bit is zero. A RPTSEL bit of one indicates the target shall report only on the peripheral device indicated in the LUN\_P field.

A report multiple buses (RPTMBUS) bit of zero indicates only one LOGICAL UNIT DESCRIPTOR (see table 30) shall be reported for each object associated with the peripheral device listed in the LUN\_P field (see table 30). A RPTMBUS bit of one indicates all LOGICAL UNIT DESCRIPTOR(s) (see table 30) shall be reported for each object associated with the peripheral device listed in the LUN\_P field (see table 30).

The REPORT PERIPHERAL DEVICE ASSOCIATIONS parameter list (see table 29) contains a four-byte header that contains the length in bytes of the parameter list and a list of PERIPHERAL DEVICE ASSOCIATION DESCRIPTORS.

Table 29 - REPORT PERIPHERAL DEVICE ASSOCIATIONS parameter list

Bit Byte	7	6	5	4	3	2	1	0				
0	(MSB)											
1		DEE	NULLEDAL DE	WCE 45500	PIATIONE LIE	TIENOTII (	o 2)					
2		PERIPHERAL DEVICE ASSOCIATIONS LIST LENGTH (n-3)										
3		•										
		PERIPHERAL DEVICE ASSOCIATION(s) (if any)										
4		PER	IPHERAL DE	VICE ASSOC	ATIONS DES	SCRIPTOR (F	First)					
x+3				(Len	gth x)							
		: : :										
n-y+1		PER	IPHERAL DE	VICE ASSOC		SCRIPTOR (L	_ast)					
n				(Len	gtn y)							

The PERIPHERAL DEVICE ASSOCIATIONS DESCRIPTOR LIST LENGTH field specifies the length in bytes of the following PERIPHERAL DEVICE ASSOCIATIONS DESCRIPTOR(s).

The PERIPHERAL DEVICE ASSOCIATIONS DESCRIPTOR is defined in table 30.

Table 30 - Format of PERIPHERAL DEVICE ASSOCIATIONS DESCRIPTOR

Bit Byte	7	6	5	4	3	2	1	0		
0	(MSB)			LUI	J D					
2				LOI	N_F			(LSB)		
3	(MSB)		100	ICAL LINIT LI	ST LENGTH /	'n 2\				
4		•	LOGICAL UNIT LIST LENGTH (n-3)							
				LOGICAL UN	IT(S) (if any)	)				
5			10	GICAL UNIT	DESCRIPTO	<b>2</b> 0				
8			LO	GICAL UNIT	DESCRIPTOR	νο				
			: : :							
n-3 n		-	LO	GICAL UNIT	DESCRIPTOR					

The LUN\_P field specifies the address of the peripheral device to which the LOGICAL UNIT DESCRIPTOR(s) listed in the PERIPHERAL DEVICE ASSOCIATIONS DESCRIPTOR list are associated.

The LOGICAL UNIT LIST LENGTH field specifies the length in bytes of the following LOGICAL UNIT DESCRIPTOR(s).

The LOGICAL UNIT DESCRIPTOR(s) contain a list of logical units that are associated with the peripheral device addressed in the LUN\_P field of the PERIPHERAL DEVICE ASSOCIATIONS DESCRIPTOR. See table 22 for the format of the LOGICAL UNIT DESCRIPTOR.

#### 6.1.1.6 REPORT PERIPHERAL DEVICE/COMPONENT DEVICE IDENTIFIER service action

The REPORT PERIPHERAL DEVICE/COMPONENT DEVICE IDENTIFIER service action (see table 31) requests the location of the selected logical unit be sent to the application client.

Table 31 - REPORT PERIPHERAL DEVICE/COMPONENT DEVICE IDENTIFIER service action

Bit Byte	7	6	5	4	3	2	1	0		
0		OPERATION CODE (A3h)								
1		RESERVED SERVICE ACTION (05h)								
2		RESERVED								
3		RESERVED								
4	(MSB)	B)LUN								
5		•		LU	JIN			(LSB)		
6	(MSB)									
7		•		ALL OCATIO	NI I ENICELI					
8		•		ALLOCATIO	IN LENGTH					
9		-								
10		RESERVED PORCLU						RESERVED		
11				CON	TROL		•	•		

The LUN field contains the logical unit number of the peripheral device or component device that the target shall report per table 32. If the requested logical unit has not been added to the target the command shall be terminated with a CHECK CONDITION status. The sense key shall be set to ILLEGAL REQUEST, and the additional sense code set to LOGICAL UNIT NOT SUPPORTED.

A report physical or component logical unit bit (PORCLU) of zero indicates the LUN field shall contain the address of a peripheral device. A PORCLU bit of one indicates the LUN field shall contain the address of a component device.

The REPORT PERIPHERAL DEVICE/COMPONENT DEVICE IDENTIFIER parameter list (see table 32) contains a four-byte field that contains the length in bytes of the parameter list and the location of the selected logical unit.

Table 32 - REPORT PERIPHERAL DEVICE/COMPONENT DEVICE IDENTIFIER parameter list

Bit Byte	7	6	5	4	3	2	1	0			
0	(MSB)										
1		•	1.004	TION IDENTI	FIED LIST LE	NOTH					
2		•	LOCATION IDENTIFIER LIST LENGTH -								
3		•	-								
4			LOCATION IDENTIFIER								
n		•		LOCATION	IDENTIFIER						

The LOCATION IDENTIFIER LIST LENGTH field specifies the length in bytes of the IDENTIFIER field.

The LOCATION IDENTIFIER field shall be an ASCII value that indicates the position of the peripheral device or component device within the target. The ASCII value within the IDENTIFIER field is vendor specific.

#### 6.1.1.7 REPORT STATES service action

The REPORT STATES service action (see table 33) requests that state information about the selected logical unit(s) within the target be sent to the application client.

Table 33 - REPORT STATES service action

Bit Byte	7	6	5	4	3	2	1	0
0				OPERATION	CODE (A3h)			
1		RESERVED			SERVICE ACTION (06h)			
2		RESERVED						
3		RESE	RVED		LOGICAL UNIT TYPE			
4	(MSB)							
5		LUN (LSB)						
6	(MSB)							
7		ALLOCATION LENGTH						
8								
9		(LSB)						
10	RESERVED REPORT			STATES		RESE	RVED	
11	CONTROL							

The LOGICAL UNIT TYPE field contains the type of logical unit designated by the LUN field. See table 23 for the list of logical unit types. If the requested logical unit has not been added to the target the command shall be terminated with a CHECK CONDITION status. The sense key shall be set to ILLEGAL REQUEST, and the additional sense code set to LOGICAL UNIT NOT SUPPORTED.

The LUN field specifies the address of the logical unit the target shall report state information per table 35.

The REPORT STATES field contains the information on which logical unit(s) the target shall report state information. See table 34 for the defined states.

Table 34 - REPORT STATES

Codes	Description
00Ь	Report all states for all logical units within the selected target. The LOGICAL UNIT TYPE and the LUN fields shall be ignored if this option is selected.
01b	Report all states for all of the logical unit(s) of the type listed in the LOGICAL UNIT TYPE field within the selected target. The LUN field shall be ignored if this option is selected.
10b	Report all states for the selected logical unit. The LOGICAL UNIT TYPE and the LUN field shall designate the address of the logical unit if this option is selected.
11b	Reserved

The REPORT STATES parameter list (see table 35) contains a four-byte header that indicates the length in bytes of the parameter list plus a list of LOGICAL UNIT STATE DESCRIPTORS.

Table 35 - REPORT STATES parameter list

Bit Byte	7	6	5	4	3	2	1	0	
0	(MSB)								
1		•							
2		LOGICAL UNIT STATES LIST LENGTH (n-3)  (LSB)							
3									
	LOGICAL UNIT STATE(S) (if any)								
4		LOGICAL UNIT STATE(S) DESCRIPTOR (First)							
x+3		(Length x)							
		· ·							
n-y+1		LOGICAL UNIT STATE(S) DESCRIPTOR (Last)							
n			(Length y)						

The LOGICAL UNIT LIST LENGTH field specifies the length in bytes of the following LOGICAL UNIT STATE(S) DESCRIPTOR(s).

The LOGICAL UNIT STATE(S) DESCRIPTOR is defined in table 36.

Bit 7 6 5 3 2 1 0 4 Byte 0 **DEVICE TYPE** 1 RESERVED LOGICAL UNIT TYPE 2 (MSB) LUN 3 (LSB) 4 RESERVED 5 RESERVED 6 (MSB) STATE LIST LENGTH (n-7) 7 (LSB) STATE DESCRIPTORS(S) (if any) 8 **REPLACE** STATE OF THE LOGICAL UNIT n REPLACE STATE OF THE LOGICAL UNIT

Table 36 - Format of LOGICAL UNIT STATES DESCRIPTORS

The DEVICE TYPE field shall contain a component device type if the LOGICAL UNIT TYPE field indicates a component device type. See table 18 for a list of component device types. If the LOGICAL UNIT TYPE field does not indicate a component device type the DEVICE TYPE field shall contain a peripheral device type. See the SCSI-3 Primary Commands Standard for a list of SCSI peripheral device types.

The LOGICAL UNIT TYPE field contains the type of logical unit contained within the LUN field. See table 23 for the list of logical unit types.

The LUN field contains the address of the logical unit the target is reporting state information about.

The STATE LIST LENGTH field specifies the length in bytes of the following STATE DESCRIPTOR(s).

The STATE OF THE LOGICAL UNIT field specifies the state of logical unit addressed by the LUN field. The contents of the STATE OF THE LOGICAL UNIT field depends on the logical unit type field. See table 37, table 38, table 39, table 40, table 41, and table 42 for a definition of the states by logical unit type that shall be reported to the application client.

The order in which states are reported is vendor specific.

A replace bit (REPLACE) of zero shall indicate the logical unit is not a replaceable unit if the LOGICAL UNIT TYPE field indicates the logical unit is a peripheral device or component device. A REPLACE bit of one shall indicate the logical unit is a replaceable unit if the LOGICAL UNIT TYPE field indicates the logical unit is a peripheral device or component device. The target shall not set the REPLACE bit to one unless the LOGICAL UNIT TYPE field is either peripheral device or component device. The definition of replaceable is vendor specific.

Table 37 - Target base device (LUN 0) states

Bit	7	6	5	4	3	2	1	0
	RESERVED	VS	RESERVED			ABNORMAL	NONAFAIL	READYING

A readying bit (READYING) of zero indicates there are no logical units within the target that have a state of readying. A READYING bit of one indicates one or more logical units within the target are being initialized and access to the target is limited.

The amount of accessibility of a target during the readying state is vendor-specific.

A non-addressable component failure bit (NONAFAIL) of zero indicates that all non-addressable parts are operational. A NONAFAIL bit of one indicates one or more non-addressable part(s) have failed. (e.g., power supply failure, LED failure, cache failure, etc., that are not defined as component devices).

NOTE 14 - More information on the failure may be available within the sense data from a REQUEST SENSE command issued to the target's base device address.

An abnormal bit (ABNORMAL) of zero indicates that all addressable devices within the target have a state of available. An ABNORMAL bit of one indicates that one or more addressable devices within the target are indicating a state other than available.

NOTE 15 - To determine which device is indicating it is not available, issue a state request to each addressable device within the target.

The vendor specific (VS) bit indicates a vendor specific state.

Table 38 - Volume set states

		38 - Volume set states
Codes	States	Description
00h	Available	The addressed volume set is operational.
01h	Broken	The addressed volume set is capable of being supported but it has failed.
02h	Data lost	Within the addressed volume set data has been lost.
03h	Exposed	Within the addressed volume set data is not protected. In this state all data is still valid, however, a failure will cause a loss of data or a loss of data availability.
0Eh	Fractionally exposed	Within the addressed volume set data is not protected. In this state all data is still valid, however, a failure may cause a loss of data or a loss of data availability.
04h	Partially exposed	Within the addressed volume set one or more logical unit(s) have failed. In this state all data is still protected.
05h	Protected rebuild	One or more of the redundancy groups underlaying the addressed volume set is in the process of a rebuild operation. In this state all data is protected.
0Ch	Protection dis- abled	Within the addressed volume set the generation of check data has been disabled. In this state all data is still valid, however, a failure will cause a loss of data or a loss of data availability.
06h	Not available	The addressed volume set is capable of being supported but has not been configured.
07h	Not supported	The addressed volume set is not capable of being configured.
08h	Readying	The addressed volume set is being initialized and access to the volume set is limited.
		NOTE 16 - The amount of accessibility to the volume set during the readying state is vendor-specific. This state should be indicated if any of the logical units within the volume set are not ready. Intervention may be required by the application client to remove this state. (e.g., START UNIT command)
09h	Rebuild	One or more of the underlaying redundancy groups of the addressed volume set is in the process of a rebuild operation. In this state data is not protected.
0Ah	Recalculate	The addressed volume set is in the process of a recalculate operation.
		NOTE 17 - The recalculate operation may involve one or more underlaying redundancy groups.
0Bh	Spare in use	Within the addressed volume set a spare is being used. In this state all data is still protected.
0Dh	Verify in progress	Within the addressed volume set data is being verified.
		NOTE 18 - The verify operation may involve one or more underlaying redundancy groups.
0Fh-3Fh	Reserved	
40h-7Fh	Vendor specific	

Table 39 - Redundancy group states

Codes	States	Description
00h	Available	The addressed redundancy group is configured.
01h	Exposed	Within the addressed redundancy group data is not protected. In this state all data is still valid, however, a failure causes a loss of data or a loss of data availability.
02h	Invalidated protected space	Within the addressed redundancy group data has been lost. In this state the protected space is no longer intact.
03h	Not available	The addressed redundancy group is capable of being supported but has not been configured.
04h	Not supported	The addressed redundancy group is not capable of being configured.
05h	Partially exposed	Within the addressed redundancy group one or more logical unit(s) have failed. In this state the protected space is protected.
06h	Present	The addressed redundancy group is present but no other status is available.
07h	Protected rebuild	The addressed redundancy group is in the process of a rebuild operation. In this state the protected space is protected.
0Ah	Protection dis- abled	Within the addressed redundancy group the generation of check data has been disabled. In this state all data is still valid, however, a failure causes a loss of data or a loss of data availability.
08h	Rebuild	The addressed redundancy group is in the process of a rebuild operation. In this state the protected space is not protected.
09h	Recalculate	The addressed redundancy group is in the process of a recalculate operation.
0Bh	Verify in progress	Within the addressed redundancy group data is being verified.
0Ch-3Fh	Reserved	
40h-7Fh	Vendor specific	

Table 40 - Peripheral device and p\_extent states

Codes	States	Description
00h	Available	The addressed peripheral device or p_extent is operational.
01h	Broken	The addressed peripheral device or p_extent is capable of being supported but it has failed.
02h	Not available	The addressed peripheral device or p_extent is capable of being supported but no device is connected.
03h	Not supported	The target is not capable of supporting a device at the addressed peripheral device or p_extent.
04h	Present	The addressed peripheral device or p_extent is present but no other status is available.
05h	Readying	The addressed peripheral device or p_extent is being initialized and access to the peripheral device or p_extent is limited.
06h	Rebuild	The addressed peripheral device or p_extent is being rebuilt.
07h-3Fh	Reserved	
40h-7Fh	Vendor specific	

Table 41 - Spare states

Codes	States	Description
00h	Available	The addressed spare is operational.
01h	Broken	The addressed spare is capable of being supported but it has failed.
02h	Not available	The addressed spare is capable of being supported but has not been configured.
03h	Not supported	The addressed spare is not capable of being configured.
04h	Present	The addressed spare is present but no other status is available.
05h	Spare in use	The addressed spare has been exchanged with a failed object.
06h-3Fh	Reserved	
40h-7Fh	Vendor specific	

Table 42 - Component device states

Codes	States	Description
00h	Available	The addressed component device is fully operational.
01h	Broken	The addressed component device is capable of being supported but it has failed.
02h	Reserved	
03h	ITTU	The addressed component device is the reporting component device. This state shall not be reported unless the command allows the reporting of multiple states. More that one component device may report an ITTU state in a single state request.
04h	Not available	The addressed component device is capable of being supported but no component is present.
05h	Not supported	The target is not capable of supporting a component at the given address.
06h	Present	The addressed component device is present but no other status is available.
07h	Readying	The addressed component device is being initialized and access to the component device is limited.
08h-3Fh	Reserved	
40h-7Fh	Vendor specific	

# 6.2 MAINTENANCE (OUT) commands

# 6.2.1 MAINTENANCE (OUT) command service actions

The service actions for the MAINTENANCE(OUT) command are listed in table 43.

Table 43 - Service actions for MAINTENANCE (OUT) command

Service name	Service actions	Туре	Subclause
ADD PERIPHERAL DEVICE/COMPONENT DEVICE	00h	0	6.2.1.1
ATTACH TO COMPONENT DEVICE	01h	0	6.2.1.2
BREAK PERIPHERAL DEVICE/COMPONENT DEVICE	07h	0	6.2.1.3
EXCHANGE P_EXTENT	02h	0	6.2.1.4
EXCHANGE PERIPHERAL DEVICE/COMPONENT			
DEVICE	03h	0	6.2.1.5
INSTRUCT COMPONENT DEVICE	04h	0	6.2.1.6
REMOVE PERIPHERAL DEVICE/COMPONENT DEVICE	05h	0	6.2.1.7
SET PERIPHERAL DEVICE/COMPONENT DEVICE			
IDENTIFIER	06h	0	6.2.1.8
Reserved	08h-17h		
Vendor specific	18h-1Fh		
Key: M = Service action implementation is mandatory.  O = Service action implementation is optional.		•	

3

4

5

6

7

8

9

10

11

(MSB)

RESERVED

**SETLUN** 

#### 6.2.1.1 ADD PERIPHERAL DEVICE/COMPONENT DEVICE service action

The ADD PERIPHERAL DEVICE/COMPONENT DEVICE service action (see table 44) requests a peripheral device or a component device be added to the target. If the add operation fails to complete successfully the command shall be terminated with a CHECK CONDITION status. The sense key shall be set to HARDWARE ERROR, and the additional sense code set to ADD LOGICAL UNIT FAILED.

Bit 7 6 5 4 3 2 1 0 Byte 0 OPERATION CODE (A4h) 1 SERVICE ACTION (00h) **RESERVED** 2 **DEVICE TYPE** 

RESERVED

LUN

RESERVED

**RESERVED** 

RESERVED

RESERVED

RESERVED

CONTROL

Table 44 - ADD PERIPHERAL DEVICE/COMPONENT DEVICE service action

The DEVICE TYPE field contains the peripheral device type or the component device type of the device that the target shall add. See the SCSI-3 Primary Commands Standard for a list of valid peripheral device types. See table 18 for a list of valid component device types.

The LUN field contains the logical unit number to assign to the peripheral device or component device that shall be added to the target if the SETLUN bit is set to zero. If the requested logical unit cannot be added to the target the command shall be terminated with a CHECK CONDITION status. The sense key shall be set to ILLEGAL REQUEST, and the additional sense code set to LOGICAL UNIT NOT SUPPORTED.

An add physical or component logical unit bit (ADDPORC) of zero indicates the DEVICE TYPE field shall contain a valid peripheral device type. See the SCSI-3 Primary Commands Standard for a list of valid peripheral device types. An ADDPORC bit of one indicates the DEVICE TYPE field shall contain a valid component device type. See table 18 for a list of valid component device types.

A set LUN (SETLUN) bit of zero indicates the target shall assign to the peripheral device or component device the logical unit number contained in the LUN field. A SETLUN bit of one indicates that the target shall assign a logical unit number to the peripheral device or component device. The LUN field shall be ignored when the SETLUN bit is set to one.

(LSB)

ADDPORC RESERVED

#### 6.2.1.2 ATTACH TO COMPONENT DEVICE service action

The ATTACH TO COMPONENT DEVICE service action (see table 45) requests the target logically attach one or more logical unit(s) to a component device. If the attach operation fails to complete successfully the command shall be terminated with a CHECK CONDITION status. The sense key shall be set to HARDWARE ERROR, and the additional sense code set to ATTACHMENT OF LOGICAL UNIT FAILED.

NOTE 19 - The behavior of attached logical units and their interactions with component devices are vendor specific.

To detach a logical unit from a component device, issue the ATTACH TO COMPONENT DEVICE service action with the logical unit(s) to be detached removed from the parameter list. If the LIST LENGTH field is set to zero then all logical unit(s) attached to the component device shall be detached.

NOTE 20 - If LUN\_C 1 is attached to LUN\_C 2 and LUN\_C 2 is attached to LUN\_C 1 then a detach request to LUN\_C 2 shall only detach LUN\_C 1 from LUN\_C 2. The attachment of LUN\_C 2 to LUN\_C 1 remains intact.

Bit 7 3 2 1 6 5 4 0 Byte 0 OPERATION CODE (A4h) 1 RESERVED SERVICE ACTION (01h) 2 RESERVED 3 **RESERVED** 4 (MSB) LUN C 5 (LSB) 6 (MSB) 7 LIST LENGTH 8 9 (LSB) 10 RESERVED 11 CONTROL

Table 45 - ATTACH COMPONENT DEVICE service actions

The LUN\_C field specifies the address of the component device to which the target shall attach the logical unit(s) listed in the ATTACH COMPONENT DEVICE parameter list (see table 46). If the requested logical unit has not been added to the target the command shall be terminated with a CHECK CONDITION status. The sense key shall be set to ILLEGAL REQUEST, and the additional sense code set to LOGICAL UNIT NOT SUPPORTED.

Table 46 - ATTACH COMPONENT DEVICE parameter list

Bit Byte	7	6	5	4	3	2	1	0			
		LOGICAL UNIT(S) (if any)									
0					DECODIDA	2.0					
3		•	LU	GICAL UNIT	DESCRIPTOR	₹0					
					•						
n-3		LOGICAL UNIT DESCRIPTOR X									
n				GICAL UNIT	DESCRIPTOR	\					

The LOGICAL UNIT DESCRIPTOR(s) contain a list of logical units that shall be attached to the component device addressed by the ATTACH COMPONENT DEVICE service action. See table 22 for the format of the LOGICAL UNIT DESCRIPTOR.

### 6.2.1.3 BREAK PERIPHERIAL DEVICE/COMPONENT DEVICE service action

The BREAK PERIPHERAL DEVICE/COMPONENT DEVICE service action (see table 47) requests a peripheral device or a component device be placed into a broken state.

Table 47 - BREAK PERIPHERAL DEVICE/COMPONENT DEVICE service action

Bit Byte	7	6	5	4	3	2	1	0	
0		OPERATION CODE (A4h)							
1		RESERVED			SERV	ICE ACTION	(07h)		
2				DEVIC	E TYPE				
3				RESE	RVED				
4	(MSB)			LU	INI				
5		•		LU	JIN			(LSB)	
6				RESE	RVED				
7				RESE	RVED				
8				RESE	RVED				
9		RESERVED							
10		RESERVED BRKPORC RESERVE						RESERVED	
11				CON	TROL				

The DEVICE TYPE field contains the peripheral device type or the component device type of the device that the target shall break.

The LUN field contains the logical unit number of the peripheral device or component device that shall be broken. If the requested logical unit has not been added to the target the command shall be terminated with a CHECK CONDITION status. The sense key shall be set to ILLEGAL REQUEST, and the additional sense code set to LOGICAL UNIT NOT SUPPORTED.

A break physical or component logical unit bit (BRKPORC) of zero indicates the LUN field contains the address of a peripheral device and the DEVICE TYPE field contains a valid peripheral device type. See the SCSI-3 Primary Commands Standard for a list of valid peripheral device types. A BRKPORC bit of one indicates the LUN field shall contain the address of a component device and the DEVICE TYPE field contains a valid component device type. See table 18 for a list of valid component device types.

## 6.2.1.4 EXCHANGE P\_EXTENT service action

The EXCHANGE P\_EXTENT service action (see table 48) requests the target replace a p\_extent with another p\_extent. If the exchange operation fails to complete successfully the command shall be terminated with a CHECK CONDITION status. The sense key shall be set to HARDWARE ERROR, and the additional sense code set to EXCHANGE OF LOGICAL UNIT FAILED.

Table 48 - EXCHANGE P\_EXTENT service action

Bit Byte	7	6	5	4	3	2	1	0	
0				OPERATION	CODE (A4h)	)			
1		RESERVED			SERV	ICE ACTION	(02h)		
2				RESE	RVED				
3				RESE	RVED				
4				RESE	RVED				
5				RESE	RVED				
6	(MSB)								
7		•		LICTLI	NOTH				
8		•		LIST LE	ENGIH				
9		(LSB)							
10		RESERVED IMMED							
11				CON	TROL			•	

An immediate (IMMED) bit of zero indicates that status shall be returned after the exchange operation has completed. An IMMED bit value of one indicates that the target shall return status as soon as the command descriptor block has been validated, and the entire EXCHANGE P\_EXTENT parameters list has been transferred.

The EXCHANGE P\_EXTENT parameters list (see table 49) contains the addresses of the logical units that shall be exchanged.

Table 49 - EXCHANGE P\_EXTENT parameters list

Bit Byte	7	6	5	4	3	2	1	0	
0			OI	DD EVTEN		OD.			
11		OLD P_EXTENT DESCRIPTOR —————							
12			NE	W.D. EVTEN	T DECODIDE	0.0			
23			INE	W P_EXTEN	I DESCRIPTI	UK			

The OLD P\_EXTENT DESCRIPTOR contains the p\_extent that shall be replaced by a new p\_extent. See table 14 for the format of the OLD P\_EXTENT DESCRIPTOR.

The NEW P\_EXTENT DESCRIPTOR contains the p\_extent that shall replace an old p\_extent. See table 14 for

the format of the NEW P\_EXTENT DESCRIPTOR. If the old p\_extent and the new p\_extent are not the same size or have different peripheral device types the command shall be terminated with a CHECK CONDITION status. The sense key shall be set to ILLEGAL REQUEST, and the additional sense code set to INVALID FIELD IN PARAMETER LIST.

It is not an error for the old p\_extent and new p\_extent to address the same p\_extent.

#### 6.2.1.5 EXCHANGE PERIPHERAL DEVICE/COMPONENT DEVICE service action

The EXCHANGE PERIPHERAL DEVICE/COMPONENT DEVICE service action (see table 50) requests that the target replace one logical unit with another logical unit.

Bit 7 6 5 4 3 2 1 0 Byte 0 OPERATION CODE (A4h) 1 **RESERVED** SERVICE ACTION (03h) 2 **RESERVED** 3 **RESERVED** 4 (MSB) OLD LUN 5 (LSB) 6 **RESERVED** 7 **RESERVED** 8 (MSB) **NEW LUN** 9 (LSB) 10 **EXPORC RESERVED IMMED** 11 CONTROL

Table 50 - EXCHANGE PERIPHERAL DEVICE/COMPONENT DEVICE Service Action

The OLD LUN field contains the logical unit number of the peripheral device or component device that the target shall exchange with the logical unit addressed in the NEW LUN field.

The NEW LUN field contains the logical unit number of the peripheral device or component device that the target shall exchange with the logical unit addressed in the OLD LUN field. If the old logical unit or the new logical unit has not been added to the target the command shall be terminated with a CHECK CONDITION status. The sense key shall be set to ILLEGAL REQUEST, and the additional sense code set to LOGICAL UNIT NOT SUPPORTED

It is not an error for the OLD LUN and NEW LUN fields to address the same logical unit.

An immediate (IMMED) bit of zero indicates that status shall be returned after the exchange operation has completed. An IMMED bit value of one indicates that the target shall return status as soon as the command descriptor block has been validated.

#### X3T10/1047D revision 6c

An exchange physical or component logical unit bit (EXPORC) of zero indicates the OLD LUN and NEW LUN fields shall contain the addresses of peripheral devices. A EXPORC bit of one indicates the OLD LUN and NEW LUN fields shall contain the addresses of component devices.

## 6.2.1.6 INSTRUCT COMPONENT DEVICE service action

The INSTRUCT COMPONENT DEVICE service action (see table 51) requests the target to take the requested action on the addressed component device.

Table 51 - INSTRUCT COMPONENT DEVICE service action

Bit Byte	7	6	5	4	3	2	1	0		
0		OPERATION CODE (A4h)								
1		RESERVED SERVICE ACTION (04h)								
2			COMF	PONENT DEV	ICE INSTRU	CTION				
3				RESE	RVED					
4	(MSB)	LUN_C								
5		<u>-</u>		LUI	N_C			(LSB)		
6	(MSB)									
7		-		LIST LE	NOTH					
8		-		LIST LE	INGIA					
9		(LSB)								
10		RESERVED								
11				CON	TROL					

The COMPONENT DEVICE INSTRUCTION field contains the action to be taken. See table 52 for a list of actions.

Table 52 - COMPONENT DEVICE INSTRUCTION field

Codes	Description
00h	Turn selected component device off
01h	Turn selected component device on
02h-7Fh	Reserved
80h-FFh	Vendor specific

The LUN\_C field specifies the address of the component device to which the action shall be applied. If the requested logical unit has not been added to the target the command shall be terminated with a CHECK CONDITION status. The sense key shall be set to ILLEGAL REQUEST, and the additional sense code set to LOGICAL UNIT NOT SUPPORTED.

A list length of zero shall indicate the INSTRUCT COMPONENT DEVICE service action contains no parameter list.

The INSTRUCT COMPONENT DEVICE parameter list (see table 53) contains vendor specific actions to be applied to the component device addressed in the INSTRUCT COMPONENT DEVICE service action command descriptor block.

Table 53 - INSTRUCT COMPONENT DEVICE parameter list

Bit Byte	7	6	5	4	3	2	1	0
0				VENDOR	SPECIFIC			
n		•		VENDOR	SFEGIFIC			

#### 6.2.1.7 REMOVE PERIPHERAL DEVICE/COMPONENT DEVICE service action

The REMOVE PERIPHERAL DEVICE/COMPONENT device service action (see table 54) requests a peripheral device or a component device be removed from the target.

Table 54 - REMOVE PERIPHERAL DEVICE/COMPONENT DEVICE service action

Bit Byte	7	6	5	4	3	2	1	0
0				OPERATION	CODE (A4h)	)		
1		RESERVED			SERV	ICE ACTION	(05h)	
2				RESE	RVED			
3				RESE	RVED			
4	(MSB)				INI			
5		•		Ll	JIN			(LSB)
6				RESE	RVED			
7				RESE	RVED			
8				RESE	RVED			
9		RESERVED						
10		RESERVED REMPORC RESERVED						
11				CON	TROL		•	•

The LUN field contains the logical unit number of the peripheral device or component device that shall be removed from the target. If the requested logical unit has not been added to the target the command shall

#### X3T10/1047D revision 6c

be terminated with a CHECK CONDITION status. The sense key shall be set to ILLEGAL REQUEST, and the additional sense code set to LOGICAL UNIT NOT SUPPORTED.

A remove physical or component logical unit bit (REMPORC) of zero indicates the LUN field shall contain the address of a peripheral device. A REMPORC bit of one indicates the LUN field shall contain the address of a component device.

If the peripheral device contains any assigned p\_extents or if any logical units are attached to the component device being removed the command shall be terminated with a CHECK CONDITION status. The sense key shall be set to ILLEGAL REQUEST, and the additional sense code set to REMOVE OF LOGICAL UNIT FAILED.

#### 6.2.1.8 SET PERIPHERAL DEVICE/COMPONENT DEVICE IDENTIFIER service action

The SET PERIPHERAL DEVICE/COMPONENT DEVICE IDENTIFIER service action (see table 55) requests the target identify the addressed logical unit with the location received in the SET PERIPHERAL DEVICE/COMPONENT DEVICE IDENTIFIER parameter list.

Table 55 - SET PERIPHERAL DEVICE/COMPONENT DEVICE IDENTIFIER service action

Bit Byte	7	6	5	4	3	2	1	0				
0	OPERATION CODE (A4h)											
1		RESERVED SERVICE ACTION (06h)										
2		RESERVED										
3		RESERVED										
4	(MSB)	(MSB)										
5				LC	JIN			(LSB)				
6	(MSB)											
7		<u>-</u>		LIST LE	ENCTH							
8		-		LIST LE	INGIA							
9		-						(LSB)				
10		RESERVED IDPORC RESERVE										
11				CONTROL								

The LUN field contains the logical unit number of the peripheral device or component device that shall be identified by the LOCATION IDENTIFIER field received in the SET PERIPHERAL DEVICE/COMPONENT DEVICE IDENTIFIER parameter list. If the requested logical unit has not been added to the target the command shall be terminated with a CHECK CONDITION status. The sense key shall be set to ILLEGAL REQUEST, and the additional sense code set to LOGICAL UNIT NOT SUPPORTED.

A set identification peripheral device or component device bit (IDPORC) of zero indicates the LUN field shall contain the address of a peripheral device. A IDPORC bit of one indicates the LUN field shall contain the address of a component device.

The SET PERIPHERAL DEVICE/COMPONENT DEVICE IDENTIFIER parameter list (see table 56) contains the location identifier of the addressed logical unit.

Table 56 - SET PERIPHERAL DEVICE/COMPONENT DEVICE IDENTIFIER parameter list

Bit Byte	7	6	5	4	3	2	1	0			
0		LOCATION IDENTIFIED									
n		LOCATION IDENTIFIER —————									

The LOCATION IDENTIFIER field shall be an ASCII value that indicates the position of the peripheral device or component device within the target. The ASCII value within the IDENTIFIER field is vendor specific.

# 6.3 REDUNDANCY GROUP (IN) command

## 6.3.1 REDUNDANCY GROUP (IN) command service actions

The service actions for the REDUNDANCY GROUP (IN) command are listed in table 57.

Table 57 - Service actions for REDUNDANCY GROUP (IN) command

Service name	Service actions	Туре	Subclause
REPORT REDUNDANCY GROUPS REPORT UNASSIGNED REDUNDANCY GROUP SPACE RESERVED VENDOR SPECIFIC	00h 01h 09h-17h 18h-1Fh	M M	6.3.1.1 6.3.1.2
Key: M = Service action implementation is mandatory. O = Service action implementation is optional.			

#### 6.3.1.1 REPORT REDUNDANCY GROUPS service action

The REPORT REDUNDANCY GROUPS service action (see table 58) requests that information regarding redundancy groups within the target be sent to the application client.

NOTE 21 - The information returned by the REPORT REDUNDANCY GROUPS service action may be used by the application client to determine the boundaries of all the current redundancy groups to allow more redundancy groups to be configured or to allow a redundancy group to be expanded.

Table 58 - REPORT REDUNDANCY GROUPS service action

Bit Byte	7	6	5	4	3	2	1	0			
0		OPERATION CODE (BAh)									
1	RESERVED SERVICE ACTION (00h)										
2		RESERVED									
3		RESERVED									
4	(MSB)	LUN D									
5		-	LUN_R (LSB)								
6	(MSB)										
7		-		ALL OCATIO	NI I ENIOTII						
8		-		ALLOCATIO	IN LENGTH						
9		-						(LSB)			
10		RESERVED RPTSE									
11				CON	ΓROL						

The LUN\_R field specifies the address of the redundancy group for which information shall be reported per table 59. If the requested logical unit has not been configured the command shall be terminated with a CHECK CONDITION status. The sense key shall be set to ILLEGAL REQUEST, and the additional sense code set to LOGICAL UNIT NOT CONFIGURED.

A report selected bit (RPTSEL) of zero indicates the target shall report on all the redundancy group(s) within the target. The LUN\_R field shall be ignored when the RPTSEL bit is zero. A RPTSEL bit of one indicates the target shall only report information on the redundancy group addressed by the LUN\_R field.

The REPORT REDUNDANCY GROUPS parameter list (see table 59) contains a four-byte header that defines the length in bytes of the parameter list and a list of REPORT REDUNDANCY GROUP DESCRIPTORS.

Table 59 - REPORT REDUNDANCY GROUPS parameter list

Bit Byte	7	6	5	4	3	2	1	0				
0	(MSB)		REPORT REDUNDANCY GROUP LIST LENGTH (n-3)  (LSB)									
1												
2		- г										
3		•										
		REPORT REDUNDANCY GROUP DESCRIPTORS(S) (if any)										
4		R	REPORT REDUNDANCY GROUP DESCRIPTOR (First)									
x+3				(Len	gth x)							
		: :										
n-y+1		R	REPORT REDUNDANCY GROUP DESCRIPTOR (Last)									
n				(Len	gth y)							

The REPORT REDUNDANCY GROUP LIST LENGTH field specifies the length in bytes of the following REPORT REDUNDANCY GROUP DESCRIPTOR(s).

The REPORT REDUNDANCY GROUP DESCRIPTOR is defined in table 60.

Table 60 - Format of REPORT REDUNDANCY GROUP DESCRIPTOR

Bit Byte	7	6	5	4	3	2	1	0			
0	(MSB)			1.116	l D						
1				LUN	1_K			(LSB)			
2				RESE	RVED						
3		REDUNDANCY GROUP IDENTIFIER									
4		RESERVED GRANULARITY OF UNITS									
5	RESERVED	RESERVED REDUNDANCY GROUP STATE									
6	(MSB)	(MSB) REDUNDANCY GROUP P_EXTENT LIST LENGTH (n-7)									
7		K	EDUNDANC	GROUP P_	EXTENT LIST	I LENGIH (N	-7)	(LSB)			
		İ	REDUNDANC	Y GROUP P_	EXTENT DE	SCRIPTOR(S	)				
8		Dr	DUNDANCY	CDOUD D . E	VTENT DEC	PRIDTOR /Ei	rct)				
31		ΝE	DUNDANCY	GROUP P_E	VIENI DESC	KIPTOR (FI	151)				
		- - -									
n-23 n		RE	DUNDANCY	GROUP P_E	KTENT DESC	RIPTOR (La	st)				

The LUN\_R field specifies the address of the redundancy group to which the information listed in this REPORT REDUNDANCY GROUP DESCRIPTOR is associated.

The REDUNDANCY GROUP IDENTIFIER field (see table 61) indicates the type of protection being used within the redundancy group.

Table 61 - REDUNDANCY GROUP IDENTIFIERS

Codes	Description				
00h	No redundancy				
01h	Copy redundancy				
02h	XOR redundancy				
03h	P+Q redundancy				
04h-7Fh	Reserved				
80h-FFh	Vendor specific				

The GRANULARITY OF UNITS field (see table 62) indicates units being used within the redundancy group.

Table 62 - GRANULARITY OF UNITS

Codes	Description
0h	Bit
1h	Byte
2h	2-Byte word
3h	4-Byte word
4h	Logical block
5h-Bh	Reserved
Ch-Fh	Vendor specific

The REDUNDANCY GROUP STATE field is defined in table 39.

The REDUNDANCY GROUP P\_EXTENT LIST LENGTH field specifies the length in bytes of the following REDUNDANCY GROUP P\_EXTENT DESCRIPTOR(s).

The REDUNDANCY GROUP P\_EXTENT DESCRIPTOR filed(s) contain a list of p\_extents and the p\_extents protected space mapping (see 5.2.2.12) for the addressed redundancy group. See table 63 for the format of the REDUNDANCY GROUP P\_EXTENT DESCRIPTOR field.

Table 63 - REDUNDANCY GROUP P\_EXTENT DESCRIPTOR

Bit Byte	7	6	5	4	3	2	1	0			
0				D EVTENT P	FECRIPTOR						
11				P_EXTENT D	ESCRIPTOR						
12	(MSB)										
13			START CHECK DATA INTERLEAVE UNIT								
14			START CHECK DATA INTERLEAVE UNIT								
15											
16	(MSB)										
17			NILIME	BER OF UNITS	OE CHECK	DATA					
18			NOIVIE	DER OF UNITS	OF CHECK	DATA					
19								(LSB)			
20	(MSB)										
21		•	N II 18 41		e of Heff	DATA					
22		•	NUMBER OF UNITS OF USER DATA -								
23		•						(LSB)			

#### X3T10/1047D revision 6c

See table 14 for a description of the P\_EXTENT DESCRIPTOR field.

The START CHECK DATA INTERLEAVE UNIT field contains the location of the first unit of check data within the p\_extent.

The NUMBER OF UNITS OF CHECK DATA field contains the number of consecutive units to be reserved for check data within the p extent.

The NUMBER OF UNITS OF USER DATA field contains the number of consecutive units to be reserved for protected space within the p\_extent.

#### 6.3.1.2 REPORT UNASSIGNED REDUNDANCY GROUP SPACE service action

The REPORT UNASSIGNED REDUNDANCY GROUP SPACE service action (see table 64) requests that information regarding the redundancy groups within the target that have protected space not yet configured into to any volume sets be sent to the application client.

Bit 7 6 5 4 3 2 1 0 Byte 0 OPERATION CODE (BAh) 1 **RESERVED** SERVICE ACTION (01h) 2 **RESERVED** 3 **RESERVED** 4 (MSB) LUN\_R 5 (LSB) 6 (MSB) 7 ALLOCATION LENGTH 8 9 (LSB) 10 RESERVED **RPTSEL** 11 CONTROL

Table 64 - REPORT UNASSIGNED REDUNDANCY GROUP SPACE service action

The LUN\_R field specifies the address of the redundancy group that shall be examined for any unassigned ps\_extents. Any unassigned ps\_extents within the addressed redundancy group shall be reported to the application client per table 65. If the requested logical unit has not been configured the command shall be terminated with a CHECK CONDITION status. The sense key shall be set to ILLEGAL REQUEST, and the additional sense code set to LOGICAL UNIT NOT CONFIGURED.

A report selected bit (RPTSEL) of zero indicates the target shall report all the redundancy group(s) within the target. The LUN\_R field shall be ignored when the RPTSEL bit is zero. A RPTSEL bit of one indicates the target shall report only on the redundancy group indicated in the LUN\_R field.

The REPORT UNASSIGNED REDUNDANCY GROUP SPACE parameter list (see table 65) contains a four-byte header that defines the length in bytes of the parameter list and a list of REPORT UNASSIGNED REDUNDANCY GROUP SPACE DESCRIPTORS.

Table 65 - REPORT UNASSIGNED REDUNDANCY GROUP SPACE parameter list

Bit Byte	7	6	5	4	3	2	1	0				
0	(MSB)		PORT UNASSIGNED REDUNDANCY GROUP SPACE LIST LENGTH (n-3)									
1												
2		-REPORT UNASSIGNED REDUNDANCY GROUP SPACE LIST LENGTH (n-3)										
3		-						(LSB)				
	REF	REPORT UNASSIGNED REDUNDANCY GROUP SPACE DESCRIPTORS(S) (if any)										
4		REPORT	UNASSIGNE	D REDUNDA		SPACE DES	CRIPTOR					
x+3				(First) (L	ength x)							
n-y+1		REPORT	REPORT UNASSIGNED REDUNDANCY GROUP SPACE DESCRIPTOR									
n				(Last) (L	ength y)							

The REDUNDANCY GROUP LIST LENGTH field specifies the length in bytes of the following REPORT UNASSIGNED REDUNDANCY GROUP SPACE DESCRIPTOR(S).

The REPORT UNASSIGNED REDUNDANCY GROUP SPACE DESCRIPTOR(s) contains information on all unassigned protected space within the addressed redundancy group. See table 66 for the format of the REPORT UNASSIGNED REDUNDANCY GROUP SPACE DESCRIPTOR.

Table 66 - Format of REPORT UNASSIGNED REDUNDANCY GROUP SPACE DESCRIPTOR

Bit Byte	7	6	5	4	3	2	1	0			
0	(MSB)			1.110	l D						
1		•		LUI	N_K			(LSB)			
2				RESE	RVED						
3		REDUNDANCY GROUP IDENTIFIER									
4		RESERVED									
5	RESERVED	STATE OF THE REDUNDANCY GROUP									
6	(MSB)		PS_EXTENT LIST LENGTH (n-7)								
7		•	P5_	EXTENT LIS	I LENGIH (I	1-7)		(LSB)			
			P	S_EXTENT D	ESCRIPTOR(	S)					
8			D	e EVIENT D	FECRIPTOR	0					
19			r	S_EXTENT D	ESCRIPTOR	U					
		·									
n-11			PS_EXTENT DESCRIPTOR X								
n											

See table 61 for a description of the REDUNDANCY GROUP IDENTIFIER field.

The LUN\_R field specifies the address of the redundancy group to which the information listed in this REPORT UNASSIGNED REDUNDANCY GROUP SPACE DESCRIPTOR is associated.

The REDUNDANCY GROUP IDENTIFIER field indicates the type of protection being used within the redundancy group that contains the unassigned ps\_extents. See table 61 for a list of the types of protection.

The REDUNDANCY GROUP STATE field is defined in table 39.

The PS\_EXTENT LIST LENGTH field specifies the length in bytes of the following PS\_EXTENT DESCRIPTOR(s).

The PS\_EXTENT DESCRIPTOR(s) contain a list of unassigned ps\_extents from the addressed redundancy group. The PS\_EXTENT DESCRIPTOR is defined in table 67.

Table 67 - Data format of PS EXTENT DESCRIPTOR

Bit Byte	7	6	5	4	3	2	1	0			
0	(MSB)			1.1.10	l D						
1		•		LUI	N_F			(LSB)			
2	(MSB)		START LBA_PS -								
3		•									
4		•									
5		•									
6	(MSB)										
7		•		NILIMADED OF	- LDA DC(a)						
8		•		NUMBER OF	· LBA_PS(S)						
9		•						(LSB)			
10	(MSB)		NUMBER OF BYTES PER LBA_PS								
11		•	NUN	IDER OF BY	E9 PEK LBA			(LSB)			

The LUN\_P field contains the address of the peripheral device that contains the ps\_extent.

The START LBA\_PS field contains the first unassigned addressable logical block address of protected space within the addressed ps\_extent.

The NUMBER OF LBA\_PS(s) field contains the capacity of the protected space ps\_extent in blocks.

NOTE 22 - In ps\_extents the number of LBA\_PS(s) does not include any logical blocks that have been configured to contain check data; in contrast to p\_extents in which the NUMBER OF LBA\_P(s) includes all addressable logical blocks on a peripheral device.

The NUMBER OF BYTES PER LBA\_PS field contains the size, in bytes, of the blocks in the ps\_extent.

# 6.4 REDUNDANCY GROUP (OUT) command

## 6.4.1 REDUNDANCY GROUP (OUT) command service actions

The service actions for the REDUNDANCY GROUP (OUT) command are listed in table 68.

Table 68 - Service actions for REDUNDANCY GROUP (OUT) command

Service name	Service actions	Туре	Subclause
CONTROL GENERATION OF CHECK DATA CREATE/MODIFY REDUNDANCY GROUP DELETE REDUNDANCY GROUP REBUILD P_EXTENT REBUILD PERIPHERAL DEVICE RECALCULATE CHECK DATA	00h 01h 02h 03h 04h 05h	0 0 0 0 0	6.4.1.1 6.4.1.2 6.4.1.3 6.4.1.4 6.4.1.5 6.4.1.6
VERIFY CHECK DATA  RESERVED  VENDOR SPECIFIC  Key: M = Service action implementation is mandatory.  O = Service action implementation is optional.	06h 09h-17h 18h-1Fh	0	6.4.1.7

#### 6.4.1.1 CONTROL GENERATION OF CHECK DATA service action

The CONTROL GENERATION OF CHECK DATA service action (see table 69) requests that the generation of check data within a redundancy group be enabled or disabled.

Table 69 - CONTROL GENERATION OF CHECK DATA service action

Bit Byte	7	6	5	4	3	2	1	0	
0			ı	OPERATION	CODE (BBh	)			
1		RESERVED			SERV	ICE ACTION	(00h)		
2				RESE	RVED				
3		RESERVED							
4	(MSB)								
5		LUN_R (LSB)							
6				RESE	RVED				
7				RESE	RVED				
8				RESE	RVED				
9				RESE	RVED				
10		RESERVED DISCHK RESERVED ALLRG RESERVED					RESERVED		
11				CON	TROL				

The LUN\_R field specifies the address of the redundancy group that shall have the generation of check data enabled or disabled. If the requested logical unit has not been configured the command shall be terminated with a CHECK CONDITION status. The sense key shall be set to ILLEGAL REQUEST, and the additional sense code set to LOGICAL UNIT NOT CONFIGURED.

An all redundancy group bit (ALLRG) of zero indicates that the check data generation being enabled/disabled shall only be enabled/disabled on the addressed redundancy group. An ALLRG bit of one indicates that the check data generation being enabled/disabled shall be enabled/disabled on all the redundancy groups within the target. The LUN\_R field shall be ignored if the ALLRG bit is one.

A disable check data bit (DISCHK) of zero indicates the generation of check data shall be enabled on the selected redundancy group(s). A DISCHK bit of one indicates the generation of check data shall be disabled on the selected redundancy group(s). Generation of check data shall be disabled until a CONTROL GENERATION OF CHECK DATA service action is requested with the DISCHK bit set to zero and the ALLRG bit set to one or the ALLRG bit set to zero and the LUN\_R field set to the address of the redundancy group that is equal to the LUN\_R from the original CONTROL GENERATION OF CHECK DATA service action.

A VOLUME SET (OUT) command's CONTROL GENERATION OF CHECK DATA service action shall not cause the generation of check data to be enabled if the generation of check data was disabled using the REDUNDANCY GROUP (OUT) command's CONTROL GENERATION OF CHECK DATA service action.

#### 6.4.1.2 CREATE/MODIFY REDUNDANCY GROUP service action

The CREATE/MODIFY REDUNDANCY GROUP service action (see table 70) requests the creation of a new redundancy group or the modification of an existing redundancy group. This service action contains all the information required for the target to define a redundancy group and the check data mapping within that redundancy group (see 5.2.2.12). If the create operation fails to complete successfully the command shall be terminated with a CHECK CONDITION status. The sense key shall be set to HARDWARE ERROR, and the additional sense code set to CREATION OF LOGICAL UNIT FAILED. If the modification operation fails to complete successfully the command shall be terminated with a CHECK CONDITION status. The sense key shall be set to HARDWARE ERROR, and the additional sense code set to MODIFICATION OF LOGICAL UNIT FAILED.

Bit 7 5 4 3 2 1 6 0 Byte 0 OPERATION CODE (BBh) 1 RESERVED SERVICE ACTION (01h) 2 REDUNDANCY TYPE IDENTIFIER 3 **RESERVED GRANULARITY OF UNITS** 4 (MSB) LUN\_R 5 (LSB) 6 (MSB) 7 LIST LENGTH 8 9 (LSB) 10 RESERVED **SETLUN** RESERVED **IMMED** 11 CONTROL

Table 70 - CREATE/MODIFY REDUNDANCY GROUP service action

#### X3T10/1047D revision 6c

The REDUNDANCY GROUP IDENTIFIER field indicates the type of protection that shall be used within the redundancy group being created or modified. See table 61 for the format of the REDUNDANCY GROUP IDENTIFIER field.

The GRANULARITY OF UNITS field indicates if bits, bytes, words, or logical blocks shall be used within the redundancy group being created or modified. See table 62 for the format of the GRANULARITY OF UNITS field.

The LUN\_R field specifies the address of the redundancy group that shall be created or modified. If the addressed redundancy group already exists within the target the target shall modify the existing redundancy group as requested in the CREATE/MODIFY REDUNDANCY GROUP service action. If the requested logical unit is not configurable the command shall be terminated with a CHECK CONDITION status. The sense key shall be set to ILLEGAL REQUEST, and the additional sense code set to LOGICAL UNIT NOT CONFIGURED.

An immediate (IMMED) bit of zero indicates that status shall be returned after the create/modify redundancy group operation has completed. An IMMED bit value of one indicates that the target shall return status as soon as the command descriptor block has been validated, and the entire CREATE/MODIFIY REDUNDANCY GROUP parameters list has been transferred.

A set LUN (SETLUN) bit of zero indicates the target shall assign to the redundancy group being created the logical unit number contained in the LUN\_R field. A SETLUN bit of one indicates that the target shall assign a logical unit number to the redundancy group per the addressing rules (see 5.2.1). The LUN\_R field shall be ignored when the SETLUN bit is set to one.

The CREATE/MODIFY REDUNDANCY GROUP parameter list (see table 71) contains a list of CREATE/MODIFY P\_EXTENT DESCRIPTORS that shall be combined to create or modify the addressed redundancy group.

Bit 7 6 5 4 3 2 1 0 Byte CREATE/MODIFY P\_EXTENT DESCRIPTORS(S) (if any) 0 CREATE/MODIFY P\_EXTENT DESCRIPTOR 0 27 n-27 CREATE/MODIFY P\_EXTENT DESCRIPTOR X n

Table 71 - CREATE/MODIFY REDUNDANCY GROUP parameter list

The CREATE/MODIFY P\_EXTENT DESCRIPTOR contains information the target shall use to control the protected space mapping of the p\_extent. See table 72 for the format of the CREATE/MODIFY P\_EXTENT DESCRIPTOR.

Table 72 - Data format of **CREATE/MODIFY P EXTENT DESCRIPTOR** 

Bit Byte	7	6	5	4	3	2	1	0			
0		P_EXTENT DESCRIPTOR									
11		, _EXTENT BESOME FOR									
12	SETPAT	RESE	RVED	PRESERVE		RESERVED		DEFERCAL			
13				RESE	RVED						
14				RESE	RVED						
15			PF	ROTECTED SE	PACE PATTE	RN					
16	(MSB)										
17											
18			START CHECK DATA INTERLEAVE UNIT								
19								(LSB)			
20	(MSB)										
21			NII IME	BER OF UNITS	S OE CHECK	ΠΑΤΑ					
22			NOWL	SER OF GIVITY	JOI OILON	DATA					
23								(LSB)			
24	(MSB)										
25			NII IN A	BER OF UNIT	'S OF LISED I	ΠΔΤΔ					
26			INOIVI	DEK OF UNIT	O OF USER	אוא					
27								(LSB)			

The P\_EXTENT DESCRIPTOR defines the boundaries of the protected space mapping information contained in the CREATE/MODIFY P\_EXTENT DESCRIPTOR. See table 14 for a description of the P\_EXTENT DESCRIPTOR.

All bits and fields within the CREATE/MODIFY P\_EXTENT DESCRIPTOR shall be bounded by the p\_extent. It is not an error for a group of p\_extents that define a redundancy group to contain different parameters within the CREATE/MODIFY P\_EXTENT DESCRIPTORS.

A defer recalculate bit (DEFERCAL) of zero indicates the target shall recalculate check data before the CREATE/MODIFY REDUNDANCY GROUP service action returns status. A DEFERCAL bit of one indicates the target shall recalculate check data after the CREATE/MODIFY REDUNDANCY GROUP service action returns status.

A preserve protected space bit (PRESERVE) of zero indicates the protected space information shall be vendor specific on completion of the CREATE/MODIFY REDUNDANCY GROUP service action. A PRESERVE bit of one indicates the protected space information shall be preserved during the modification of a redundancy group. If the PRESERVE bit is set to one and a create redundancy group is requested the

#### X3T10/1047D revision 6c

target shall terminate the command with a CHECK CONDITION status and the sense key shall be set to ILLEGAL REQUEST with an additional sense code of INVALID FIELD IN PARAMETER LIST.

A set pattern bit (SETPAT) of zero indicates the protected space information contained within the protected space shall be vendor specific. The PROTECTED SPACE PATTERN field shall be ignored when the SETPAT bit is zero. A SETPAT bit of one indicates the pattern contained within the PROTECTED SPACE PATTERN field shall be replicated throughout the protected space.

The START CHECK DATA INTERLEAVE UNIT field contains the location of the first unit of check data within the p\_extent.

It is not required that the START CHECK DATA INTERLEAVE UNIT be located at the beginning of the first logical block address of the p\_extent. All units between the beginning of the first logical block address of the p\_extent and the START CHECK DATA INTERLEAVE UNIT value shall be protected space.

The NUMBER OF UNITS OF CHECK DATA field contains the number of consecutive units to be reserved for check data within the p extent.

The NUMBER OF UNITS OF USER DATA field contains the number of consecutive units to be reserved for protected space within the p\_extent.

### 6.4.1.3 DELETE REDUNDANCY GROUP service action

The DELETE REDUNDANCY GROUP service action (see table 73) requests that the selected redundancy group be deleted.

Bit 7 6 5 4 3 2 1 0 Byte 0 OPERATION CODE (BBh) 1 **RESERVED** SERVICE ACTION (02h) 2 **RESERVED** 3 **RESERVED** 4 (MSB) LUN\_R 5 (LSB) 6 **RESERVED** 7 **RESERVED** 8 RESERVED 9 RESERVED 10 RESERVED 11 CONTROL

Table 73 - DELETE REDUNDANCY GROUP service action

The LUN\_R field specifies the address of the redundancy group that the target shall delete. If the requested

logical unit has not been configured the command shall be terminated with a CHECK CONDITION status. The sense key shall be set to ILLEGAL REQUEST, and the additional sense code set to LOGICAL UNIT NOT CONFIGURED. If the selected redundancy group contains any assigned ps\_extents the command shall be terminated with CHECK CONDITION status and the sense key shall be set to ILLEGAL REQUEST with an additional sense code of REMOVE OF LOGICAL UNIT FAILED.

### 6.4.1.4 REBUILD P EXTENT service action

The REBUILD P\_EXTENT service action (see table 74) requests the rebuild of all or part of one or more redundancy group(s).

Bit 7 5 3 2 1 6 4 0 Byte 0 OPERATION CODE (BBh) 1 **RESERVED** SERVICE ACTION (03h) 2 **RESERVED** 3 **RESERVED** 4 **RESERVED** 5 **RESERVED** 6 (MSB) 7 LIST LENGTH 8 9 (LSB) 10 **REBUILD** RESERVED IMMED **RESERVED** 11 CONTROL

Table 74 - REBUILD P\_EXTENT service action

An immediate (IMMED) bit of zero indicates that status shall be returned after the rebuild operation has completed. An IMMED bit value of one indicates that the target shall return status as soon as the command descriptor block has been validated, and the entire REBUILD P\_EXTENT parameters list has been transferred.

The REBUILD field specifies the rebuild instructions the target shall use. See table 75 for the format of the REBUILD field.

Table 75 - Rebuild types

Codes	Description
00b	All assigned space associated with the selected p_extent shall be rebuilt. The list of redundancy group(s) in the REBUILD P_EXTENTS parameter list shall be ignored.  Protected space associated with overlapping redundancy groups shall be successfully rebuilt multiple times for a successful completion of the REBUILD P_EXTENT service action. The order of the rebuilds is vender specific.
01b	All assigned space association with the selected p_extent shall be rebuilt using any associated redundancy group. The list of redundancy group(s) in the REBUILD P_EXTENTS parameter list shall be ignored. Any protected space associated with overlapping redundancy groups shall only be successfully rebuilt one time for the successful completion of the REBUILD P_EXTENT service action. There is no indication of a failure if an overlapped redundancy group fails to rebuild.
10b	All assigned space associated with the selected p_extent shall be rebuilt. Any redundancy group(s) listed in the REBUILD P_EXTENT parameter list shall not be used to rebuild any part of the selected p_extent. Any protected space associated with overlapping redundancy groups shall be successfully rebuilt at least one time for a successful completion of the REBUILD P_EXTENT service action.
11b	Reserved

If the rebuild operation fails to complete successfully the command shall be terminated with a CHECK CONDITION status. The sense key shall be set to HARDWARE ERROR, and the additional sense code set to REBUILD FAILURE OCCURED.

The REBUILD P\_EXTENT parameter list (see table 76) contains the p\_extent to be rebuilt and a list of redundancy groups to not be used to rebuild the p\_extent.

Table 76 - REBUILD P\_EXTENT parameter list

Bit Byte	7	6	5	4	3	2	1	0			
0		D. EVITANT DECODIDATED									
11		P_EXTENT DESCRIPTOR —————									
		LUN_R(S) (if any)									
12		RESERVED									
13		RESERVED									
14	(MSB)										
15		•		LUN	_R 0			(LSB)			
					-						
n-3				RESE	RVED						
n-2				RESE	RVED						
n-1	(MSB)	B) LUN_R X									
n		•		LUN	_\`^			(LSB)			

The  $P_{EXTENT}$  DESCRIPTOR defines the boundaries of the rebuild. See table 14 for a description of the  $P_{EXTENT}$  DESCRIPTOR.

The LUN\_R field(s) specifies the address(es) of the redundancy group(s) that shall not be used to rebuild the p\_extent.

## 6.4.1.5 REBUILD PERIPHERAL DEVICE service action

The REBUILD PERIPHERAL DEVICE service action (see table 77) requests the rebuild of all or part of one or more redundancy group(s).

Table 77 - REBUILD PERIPHERAL DEVICE service action

Bit Byte	7	6	5	4	3	2	1	0	
0		OPERATION CODE (BBh)							
1		RESERVED SERVICE ACTION (04h)							
2		RESERVED							
3		RESERVED							
4		RESERVED							
5		RESERVED							
6	(MSB)								
7		•		LIST LI	NOTH				
8		•		LIST LI	ENGIH				
9		•						(LSB)	
10	RESE	ERVED REBUILD RESERVED IMMED					IMMED		
11		CONTROL							

An immediate (IMMED) bit of zero indicates that status shall be returned after the rebuild operation has completed. An IMMED bit value of one indicates that the target shall return status as soon as the command descriptor block has been validated, and the entire REBUILD PERIPHERAL DEVICE parameters list has been transferred.

The REBUILD field specifies the rebuild instructions the target shall use. See table 78 for the format of the REBUILD field.

Table 78 - Rebuild types

Codes	Description
00b	All assigned space associated with the selected peripheral device shall be rebuilt. The list of redundancy group(s) in the REBUILD PERIPHERAL DEVICES parameter list shall be ignored.  Protected space associated with overlapping redundancy groups shall be successfully rebuilt multiple times for a successful completion of the REBUILD PERIPHERAL DEVICE service action. The order of the rebuilds is vender specific.
01b	All assigned space associated with the selected peripheral device shall be rebuilt using any associated redundancy group. The list of redundancy group(s) in the REBUILD PERIPHERAL DEVICES parameter list shall be ignored.  Any protected space associated with overlapping redundancy groups shall only be successfully rebuilt one time for the successful completion of the REBUILD PERIPHERAL DEVICE service action. There is no indication of a failure if an overlapped redundancy group fails to rebuild.
10b	All assigned space associated with the selected peripheral device shall be rebuilt. Any redundancy group(s) listed in the REBUILD PERIPHER-AL DEVICE parameter list shall not be used to rebuild any part of the selected peripheral device.  Any protected space associated with overlapping redundancy groups shall be successfully rebuilt at least one time for a successful completion of the REBUILD PERIPHERAL DEVICE service action.
11b	Reserved

If the rebuild operation fails to complete successfully the command shall be terminated with a CHECK CONDITION status. The sense key shall be set to HARDWARE ERROR, and the additional sense code set to REBUILD FAILURE OCCURED.

The REBUILD PERIPHERAL DEVICE parameter list (see table 79) contains the peripheral device to be rebuilt and a list of redundancy groups to not be used to rebuild the peripheral device.

Table 79 - REBUILD PERIPHERAL DEVICE parameter list

Bit Byte	7	6	5	4	3	2	1	0		
0		RESERVED								
1		RESERVED								
2	(MSB)	LUN_P								
3		•		LUI	N_P			(LSB)		
		LUN_R(S) (if any)								
4		RESERVED								
5				RESE	RVED					
6	(MSB)				5.0					
7		•		LUN	_K U			(LSB)		
n-3				RESE	RVED					
n-2				RESE	RVED					
n-1	(MSB)		LUN_R X							
n		•		LUN	_г. ^			(LSB)		

The LUN\_P FIELD specifies the address of the peripheral device to be rebuilt.

The LUN\_R field(s) specifies the address(es) of the redundancy group(s) that shall not be used to rebuild the peripheral device.

## 6.4.1.6 RECALCULATE CHECK DATA service action

The RECALCULATE CHECK DATA service action (see table 80) requests the target to recalculate check data within a redundancy group. If the recalculate operation fails to complete successfully the command shall be terminated with a CHECK CONDITION status. The sense key shall be set to HARDWARE ERROR, and the additional sense code set to RECALCULATE FAILURE OCCURRED.

Table 80 - RECALCULATE CHECK DATA service action

Bit Byte	7	6	5	4	3	2	1	0	
0			ı	OPERATION	CODE (BBh)	)			
1		RESERVED			SERV	ICE ACTION	(05h)		
2				RESE	RVED				
3		RESERVED							
4	(MSB)	(MSB)							
5		•		LUI	N_K			(LSB)	
6				RESE	RVED				
7				RESE	RVED				
8				RESE	RVED				
9		RESERVED							
10	RESERVED ALLRG IMMED						IMMED		
11				CON	TROL		•	•	

The LUN\_R field specifies the address of the redundancy group for which the target shall recalculate the check data. If the requested logical unit has not been configured the command shall be terminated with a CHECK CONDITION status. The sense key shall be set to ILLEGAL REQUEST, and the additional sense code set to LOGICAL UNIT NOT CONFIGURED.

An immediate (IMMED) bit of zero indicates that status shall be returned after the recalculate operation has completed. An IMMED bit value of one indicates that the target shall return status as soon as the command descriptor block has been validated.

An all redundancy group bit (ALLRG) of zero indicates the recalculation of check data shall only occur on the addressed redundancy group. An ALLRG bit of one indicates the recalculation of check data shall occur on all redundancy groups within the target. The LUN\_R field shall be ignored when the ALLRG bit is one.

### 6.4.1.7 VERIFY CHECK DATA service action

The VERIFY CHECK DATA service action (see table 81) requests that check data be verified consistent with the protected space within a redundancy group.

6	5	4	3	2	1	0

Bit 7 Byte 0 OPERATION CODE (BBh) 1 **RESERVED** SERVICE ACTION (06h) 2 **RESERVED** 3 **RESERVED** 4 (MSB) LUN\_R 5 (LSB) 6 **RESERVED** 7 **RESERVED** 8 **RESERVED** 9 **RESERVED** 10 CONTVER RESERVED ALLRG RESERVED **IMMED** 11 CONTROL

Table 81 - VERIFY CHECK DATA service action

The LUN\_R field specifies the address of the redundancy group that shall have its check data verified. If the requested logical unit has not been configured the command shall be terminated with a CHECK CONDITION status. The sense key shall be set to ILLEGAL REQUEST, and the additional sense code set to LOGICAL UNIT NOT CONFIGURED.

An immediate (IMMED) bit of zero indicates that status shall be returned after the verification operation has completed. An IMMED bit value of one indicates that the target shall return status as soon as the command descriptor block has been validated.

An all redundancy group bit (ALLRG) of zero indicates the verification of check data shall only occur on the addressed redundancy group. An ALLRG bit of one indicates the verification of check data shall occur on all redundancy groups within the target. The LUN\_R field shall be ignored when the ALLRG bit is one.

A continuous verification bit (CONTVER) of zero indicates the check data shall be verified only once. A CONTVER bit of one indicates the check data shall be continuously verified. Verification shall continue until a VERIFY CHECK DATA service action is requested with the CONTVER bit set to zero and the ALLRG bit set to one or the ALLRG bit set to zero and the LUN\_R field set to the address of the redundancy group that is equal to the LUN R from the original VERIFY CHECK DATA service action.

NOTE 23 - If continuous verification is selected the verification executes as a background operation within the target in a vendor specific manner. Continuously may be defined as only verifying check data associated with the LBA range of any write commands that occur within the range on LBA Vs that overlay a redundancy group that has continuous verification enabled.

Any verification failures occurring before the VERIFY CHECK DATA service action has completed shall cause the target to terminate the command with a CHECK CONDITION status. The sense key shall be set to MEDIUM ERROR, and the additional sense code shall be set to MISCOMPARE DURING VERIFY

#### OPERATION.

Any verification failures occurring after the VERIFY CHECK DATA service action has completed shall cause the target to generate a unit attention condition for all initiators. When reporting the unit attention condition the additional sense code shall be set to MISCOMPARE DURING VERIFY OPERATION.

The relationship between the VERIFY VOLUME SET CHECK DATA service action and the VERIFY CHECK DATA service action when both service actions have requested the same area be verified is vendor specific. This standard only requires the requested area be verified.

# 6.5 VOLUME SET (IN) command

## 6.5.1 VOLUME SET (IN) command service actions

The service actions for the VOLUME SET(IN) command are listed in table 82.

Table 82 - Service actions for volume set (in) command

Service name	Service actions	Туре	Subclause
REPORT VOLUME SETS RESERVED VENDOR SPECIFIC	00h 01h-17h 18h-1Fh	М	6.5.1.1
Key: M = Service action implementation is mandatory. O = Service Action implementation is optional.			

## 6.5.1.1 REPORT VOLUME SETS service action

The REPORT VOLUME SETS service action (see table 83) requests that information regarding volume sets within the target be sent to the application client.

Table 83 - REPORT VOLUME SETS service action

Bit Byte	7	6	5	4	3	2	1	0		
0		OPERATION CODE (BEh)								
1		RESERVED SERVICE ACTION (00h)								
2		RESERVED								
3		RESERVED								
4	(MSB)	LUN_V								
5		-		LUI	<b>_</b> V			(LSB)		
6	(MSB)									
7		-		ALLOCATIO	NI I ENICELI					
8		-		ALLOCATIC	IN LENGTH					
9		-						(LSB)		
10		RESERVED								
11				CON	rrol					

The LUN\_V field specifies the address of the volume set for which information shall be reported per table 84. If the requested logical unit has not been configured the command shall be terminated with a CHECK CONDITION status. The sense key shall be set to ILLEGAL REQUEST, and the additional sense code set

## to LOGICAL UNIT NOT CONFIGURED.

A report selected bit (RPTSEL) of zero indicates the target shall report on all the volume set(s) within the target. The LUN\_V field shall be ignored when the RPTSEL bit is zero. A RPTSEL bit of one indicates the target shall only report information on the volume set addressed by the LUN\_V field.

The REPORT VOLUME SETS parameter list (see table 84) contains a four-byte header that contains the length in bytes of the parameter list and a list of REPORT VOLUME SET DESCRIPTORS.

Table 84 - REPORT VOLUME SETS parameter list

Bit Byte	7	6	5	4	3	2	1	0
0	(MSB)	REPORT VOLUME SET LIST LENGTH (n-3)  (LSB)						
1								
2								
3								
	REPORT VOLUME SET DESCRIPTORS(S) (if any)							
4		REPORT VOLUME SET DESCRIPTOR (First) (Length x)						
x+3								
n-y+1		REPORT VOLUME SET DESCRIPTOR (Last)						
n		(Length y)						

The REPORT VOLUME SET LIST LENGTH field specifies the length in bytes of the following REPORT VOLUME SET DESCRIPTOR(s).

The REPORT VOLUME SET DESCRIPTOR is defined in table 85.

Table 85 - Format of REPORT VOLUME SET DESCRIPTOR

Bit Byte	7	6	5	4	3	2	1	0		
0	(MSB)			LUI	.1. \/					
1				LOI	<b>_</b>			(LSB)		
2				RESE	RVED					
3				RESE	RVED					
4		RESE	RVED			GRANULARI	TY OF UNITS			
5	RESERVED	STATE OF THE VOLUME SET								
6	(MSB)									
7			PS_EXTENT STRIPE LENGTH							
8			F3_EXTENT STRIPE LENGTH							
9										
10	(MSB)									
11			PS	EXTENT INTI	FRI FAVE DE	PTH				
12			. 0_							
13								(LSB)		
14	(MSB)	F	REPORT VOI	LUME SET DE	SCRIPTOR I	IST I FNGTH	4			
15							•	(LSB)		
			VOLUME	SET PS_EXT	ENT DESCR	IPTOR(S)				
16			VOLUME SI	ET PS_EXTEI	NT DESCRIP	TOR (First)				
36			. 525,1112 01		22301111	()				
	: : :									
n-20			VOLUME SET PS_EXTENT DESCRIPTOR (Last)							
n			VULUIVIE SI	ET PO_EXTE	NI DESCRIP	IUR (Last)				

The LUN\_V field specifies the address of the volume set to which the information listed in this REPORT VOLUME SET DESCRIPTOR is associated.

The GRANULARITY OF UNITS field indicates if bits, bytes, words, or logical blocks are being used within the volume set being reported. See table 62 for the format of the GRANULARITY OF UNITS field.

The VOLUME SET STATE field is defined in table 38.

The PS\_EXTENT STRIPE LENGTH field contains the number of contiguous ps\_extents counted before looping back to the first ps\_extent of the current stripe.

The PS\_EXTENT INTERLEAVE DEPTH field contains the number of stripes counted before continuing onto the next consecutive ps\_extent beyond the current stripe.

The VOLUME SET PS\_EXTENT LIST LENGTH field specifies the length in bytes of the following VOLUME SET PS\_EXTENT DESCRIPTOR(s).

The VOLUME SET PS\_EXTENT DESCRIPTOR contains a list of assigned ps\_extents and the assigned ps\_extents user data mapping for the addressed volume set. See table 86 for the format of the VOLUME SET PS\_EXTENT DESCRIPTOR field.

Bit 7 2 6 5 4 3 1 0 Byte 0 PS\_EXTENT DESCRIPTOR 11 12 **INCDEC RESERVED** 13 **RESERVED** 14 LUN R 15 16 (MSB) 17 **USER DATA STRIPE DEPTH** 18 19 (LSB)

TABLE 86 - VOLUME SET PS\_EXTENT DESCRIPTOR

See table 67 for a description of the PS\_EXTENT DESCRIPTOR field.

An increment/decrement bit (INCDEC) of zero indicates logical blocks within the ps\_extent have been mapped in ascending order. An INCDEC bit of one indicates the logical blocks within the ps\_extent have been mapped in descending order.

The LUN\_R field specifies the address of the redundancy group that caused the formation of the ps\_extent.

The USER DATA STRIPE DEPTH field contains the number of contiguous units counted within a ps\_extent before proceeding to the next ps\_extent.

# 6.6 VOLUME SET (OUT) command

## 6.6.1 VOLUME SET (OUT) command service actions

The service actions for the VOLUME SET(OUT) command are listed in table 87.

Table 87 - Service actions for VOLUME SET (OUT) command

Service name	Service actions	Туре	Subclause
CONTROL GENERATION OF CHECK DATA	00h	0	6.6.1.1
CONTROL WRITE OPERATIONS	01h	0	6.6.1.2
CREATE/MODIFY VOLUME SET	02h	0	6.6.1.3
DELETE VOLUME SET	03h	0	6.6.1.4
RECALCULATE VOLUME SET CHECK DATA	04h	0	6.6.1.5
VERIFIY VOLUME SET CHECK DATA	05h	0	6.6.1.6
RESERVED	06h-17h		
VENDOR SPECIFIC	18h-1Fh		
Key: M = Service action implementation is mandatory. O = Service action implementation is optional.			

## 6.6.1.1 CONTROL GENERATION OF CHECK DATA service action

The CONTROL GENERATION OF CHECK DATA service action (see table 88) requests that the generation of check data within the underlaying redundancy group(s) of a volume set be enabled or disabled.

Table 88 - CONTROL GENERATION OF CHECK DATA service action

Bit Byte	7	6	5	4	3	2	1	0	
0	OPERATION CODE (BFh)								
1		RESERVED			SERV	ICE ACTION	(00h)		
2		RESERVED							
3		RESERVED							
4	(MSB)								
5		- LUN_V ———— (LSB)							
6				RESE	RVED				
7				RESE	RVED				
8				RESE	RVED				
9		RESERVED							
10		RESERVED DISCHK RESERVED ALLVLU RESERVED					RESERVED		
11				CON	TROL			•	

The LUN\_V field specifies the address of the volume set that shall have the generation of check data contained within the underlaying redundancy group(s) enabled or disabled. If the requested logical unit has not been configured the command shall be terminated with a CHECK CONDITION status. The sense key shall be set to ILLEGAL REQUEST, and the additional sense code set to LOGICAL UNIT NOT

#### CONFIGURED.

An all volume set bit (ALLVLU) of zero indicates that the check data generation being enabled/disabled shall only be enabled/disabled within the underlaying redundancy group(s) of the addressed volume set. An ALLVLU bit of one indicates that the check data generation being enabled/disabled shall be enabled/disabled within the underlaying redundancy group(s) of all volume set(s) within the target. The LUN\_V field shall be ignored if the ALLVLU bit is one.

A disable check data bit (DISCHK) of zero indicates the generation of check data contained within all of the underlaying redundancy group(s) of the selected volume(s) shall be enabled. A DISCHK bit of one indicates the generation of check data contained within all of the underlaying redundancy group(s) of the selected volume set(s) shall be disabled. Generation of check data shall be disabled until a CONTROL GENERATION OF CHECK DATA service action is requested with the DISCHK bit set to zero and the ALLVLU bit set to one or the ALLVLU bit set to zero and the LUN\_V field set to the address of the volume set that is equal to the LUN\_V from the original CONTROL GENERATION OF CHECK DATA service action.

A REDUNDANCY GROUP (OUT) command's CONTROL GENERATION OF CHECK DATA service action shall not cause the generation of check data to be enabled if the generation of check data was disabled using the VOLUME SET (OUT) command's CONTROL GENERATION OF CHECK DATA service action.

#### 6.6.1.2 CONTROL WRITE OPERATIONS service action

The CONTROL WRITE OPERATIONS service action (see table 89) requests that write operations to a volume set be enabled or disabled.

This service action shall cause the following commands to be enabled/disabled:

- a) ERASE command;
- b) FORMAT command;
- c) WRITE command;
- d) WRITE FILE MARKS command;
- e) WRITE LONG command;
- f) WRITE SAME command;
- g) WRITE & VERIFY command.

Table 89 - CONTROL WRITE OPERATIONS service action

Bit Byte	7	6	5	4	3	2	1	0	
0	OPERATION CODE (BFh)								
1		RESERVED			SERV	ICE ACTION	(01h)		
2		RESERVED							
3		RESERVED							
4	(MSB)								
5		LUN_V(LSB)							
6				RESE	RVED				
7				RESE	RVED				
8				RESE	RVED				
9	RESERVED								
10		RESERVED DISWR RESERVED ALLVLU RESI					RESERVED		
11				CON	TROL	•		•	

The LUN\_V field specifies the address of the volume set that shall have write operations enabled or disabled. If the requested logical unit has not been configured the command shall be terminated with a CHECK CONDITION status. The sense key shall be set to ILLEGAL REQUEST, and the additional sense code set to LOGICAL UNIT NOT CONFIGURED.

An all volume set bit (ALLVLU) of zero indicates the write operation control shall only apply to the addressed volume set. An ALLVLU bit of one indicates the write operation control shall apply to all volume set(s) within the target. The LUN\_V field shall be ignored if the ALLVLU bit is one.

A disable write operations bit (DISWR) of zero indicates write operations shall be enabled on the selected volume set(s). A DISWR bit of one indicates write operations shall be disabled on the selected volume set(s). Write operations shall disabled until a CONTROL WRITE OPERATIONS service action is requested with the DISWR bit set to zero and the ALLVLU bit set to one or the ALLVLU bit set to zero and the LUN\_V field set to the address of the volume set that is equal to the LUN\_V from the original CONTROL WRITE OPERATIONS service action.

### 6.6.1.3 CREATE/MODIFY VOLUME SET service action

The CREATE/MODIFY VOLUME SET service action (see table 90) requests the creation of a new volume set or the modification of an existing volume set. If the create operation fails to complete successfully the command shall be terminated with a CHECK CONDITION status. The sense key shall be set to HARDWARE ERROR, and the additional sense code set to CREATION OF LOGICAL UNIT FAILED. If the modification operation fails to complete successfully the command shall be terminated with a CHECK CONDITION status. The sense key shall be set to HARDWARE ERROR, and the additional sense code set to MODIFICATION OF LOGICAL UNIT FAILED.

Bit 7 6 5 4 3 2 1 0 Byte 0 OPERATION CODE (BFh) 1 **RESERVED** SERVICE ACTION (02h) 2 **RESERVED** 3 **RESERVED GRANULARITY OF UNITS** 4 (MSB) LUN\_V 5 (LSB) 6 (MSB) 7 LIST LENGTH 8 9 (LSB) 10 RESERVED SETLUN **RESERVED IMMED** 11 CONTROL

Table 90 - CREATE/MODIFY VOLUME SET service action

The GRANULARITY OF UNITS field indicates if bits, bytes, words, or logical blocks shall be used within the volume set being created or modified. See table 62 for the format of the GRANULARITY OF UNITS field.

The LUN\_V field specifies the address of the volume set that shall be created or modified. If the addressed volume set already exists within the target the target shall modify the existing volume set as requested in the CREATE/MODIFIY VOLUME SET service action. If the requested logical unit is not configurable the command shall be terminated with a CHECK CONDITION status. The sense key shall be set to ILLEGAL REQUEST, and the additional sense code set to LOGICAL UNIT NOT SUPPORTED.

An immediate (IMMED) bit of zero indicates that status shall be returned after the create/modify volume set operation has completed. An IMMED bit value of one indicates that the target shall return status as soon as the command descriptor block has been validated, and the entire CREATE/MODIFIY VOLUME SET parameters list has been transferred.

A set LUN (SETLUN) bit of zero indicates the target shall assign to the volume set being created the logical unit number contained in the LUN\_V field. A SETLUN bit of one indicates that the target shall assign a logical unit number to the volume set per the addressing rules (see 5.2.1). The LUN\_V field shall be ignored when the SETLUN bit is set to one.

The CREATE/MODIFY VOLUME SET parameter list (see table 91) contains user data mapping information and a list of CREATE/MODIFY PS\_EXTENT DESCRIPTORS that shall be combined to create or modify the addressed volume set.

Table 91 - CREATE/MODIFY VOLUME SET parameter list

Bit Byte	7	6	5	4	3	2	1	0		
0	(MSB)									
1		•	PS_EXTENT STRIPE LENGTH							
2		•								
3		•						(LSB)		
4	(MSB)		PS_EXTENT INTERLEAVE DEPTH ——							
5										
6		•								
7		•						(LSB)		
		CR	EATE/MODIF	Y PS_EXTEN	T DESCRIPT	ORS(S) (if a	ny)			
8			CDEATE/N	ODIFY PS_E	VTENT DESC					
27			CREATE/IV	IODIF1 P3_E	ATENT DESC	DRIPTOR U				
n-19 n	_	-	CREATE/MODIFY PS_EXTENT DESCRIPTOR X							

The PS\_EXTENT STRIPE LENGTH field specifies the number of contiguous ps\_extents the target shall count before looping back to the first ps\_extent of the current stripe. The looping shall continue until all the units of a ps\_extent are used up or the value in the PS\_EXTENT INTERLEAVE DEPTH field is reached.

If the number of ps\_extents within the current create volume set request is not an exact multiple of the PS\_EXTENT STRIPE LENGTH field the command shall be terminated with a CHECK CONDITION status. The sense key shall be set to ILLEGAL REQUEST, and the additional sense code set to INVALID FIELD IN PARAMETER LIST. It is not an error if the PS\_EXTENT STRIPE LENGTH field is not an even multiple of stripes and a modify volume set was requested.

The PS\_EXTENT INTERLEAVE DEPTH field specifies the number of stripes the target shall count before continuing the mapping into the next consecutive ps\_extent beyond the current stripe. If the current stripe is the last ps\_extent the target shall continue the mapping at the first ps\_extent. The mapping shall continue until all the units of all the ps\_extents are mapped.

If the value in the PS\_EXTENT STRIPE LENGTH field is equal to the number of ps\_extents within the current modify/create volume set request, the PS\_EXTENT INTERLEAVE DEPTH field shall be ignored.

The CREATE/MODIFY PS\_EXTENT DESCRIPTOR contains information the target shall use to control the user data mapping (see 5.2.2.14) within the ps\_extent. See table 92 for the format of the CREATE/MODIFY PS\_EXTENT DESCRIPTOR.

Bit 7 6 5 4 3 2 1 0 Byte 0 PS\_EXTENT DESCRIPTOR 11 12 **INCDEC RESERVED** 13 **RESERVED** 14 LUN\_R 15 16 (MSB) 17 **USER DATA STRIPE DEPTH** 18 19 (LSB)

Table 92 - Data format of **CREATE/MODIFY PS EXTENT DESCRIPTOR** 

The PS\_EXTENT DESCRIPTOR defines the boundaries of the user data mapping information contained in the CREATE/MODIFY PS\_EXTENT DESCRIPTOR. See table 67 for a description of the PS\_EXTENT DESCRIPTOR.

All bits and fields within the CREATE/MODIFY PS\_EXTENT DESCRIPTOR shall be bounded by the ps\_extent. It is not an error for a group of ps\_extents that define a volume set to contain different parameters within the CREATE/MODIFY PS\_EXTENT DESCRIPTORS.

An increment/decrement bit (INCDEC) of zero indicates the target shall map logical blocks within the ps\_extent in ascending order. When INCDEC is zero logical blocks after the START LBA\_PS field value in the PS\_EXTENT DESCRIPTOR shall be assigned in ascending order. An INCDEC bit of one indicates the target shall map the logical blocks within the ps\_extent in descending order. When INCDEC is one logical blocks starting with the START LBA\_PS field value in the PS\_EXTENT DESCRIPTOR shall be assigned in descending order.

NOTE 24 - When the INCDEC bit is one the START LBA\_PS field contains the largest logical block in the p extent.

The LUN\_R field specifies the address of the redundancy group that caused the formation of the ps\_extent.

The USER DATA STRIPE DEPTH field contains the number of contiguous units to count within a ps\_extent before proceeding to the next ps\_extent. Any units defined as check data shall not be counted to determine when the user data stripe depth is reached.

#### 6.6.1.4 DELETE VOLUME SET service action

The DELETE VOLUME SET service action (see table 93) requests that the selected volume set be deleted. If the remove operation fails to complete successfully the command shall be terminated with a CHECK CONDITION status. The sense key shall be set to HARDWARE ERROR, and the additional sense code set to REMOVE OF LOGICAL UNIT FAILED.

Table 93 - DELETE VOLUME SET service action

Bit Byte	7	6	5	4	3	2	1	0		
0	OPERATION CODE (BFh)									
1		RESERVED			SERV	ICE ACTION	(03h)			
2				RESE	RVED					
3		RESERVED								
4	(MSB)									
5		LUN_V(LSB)								
6				RESE	RVED					
7				RESE	RVED					
8				RESE	RVED					
9		RESERVED								
10	RESERVED									
11				CON	ΓROL					

The LUN\_V field specifies the address of the volume set that the target shall delete. If the requested logical unit has not been configured the command shall be terminated with a CHECK CONDITION status. The sense key shall be set to ILLEGAL REQUEST, and the additional sense code set to LOGICAL UNIT NOT CONFIGURED.

## 6.6.1.5 RECALCULATE VOLUME SET CHECK DATA service action

The RECALCULATE VOLUME SET CHECK DATA service action (see table 94) requests the target to recalculate check data within the portion of any redundancy group(s) overlaid by the selected a volume set. If the recalculate operation fails to complete successfully the command shall be terminated with a CHECK CONDITION status. The sense key shall be set to HARDWARE ERROR, and the additional sense code set to RECALCULATE FAILURE OCCURRED.

Table 94 - RECALCULATE VOLUME SET CHECK DATA service action

Bit Byte	7	6	5	4	3	2	1	0		
0		OPERATION CODE (BFh)								
1		RESERVED SERVICE ACTION (04h)								
2		RESERVED								
3		RESERVED								
4	(MSB)									
5		-	LUN_V (LSE							
6	(MSB)									
7		<u>.</u>		LIST LI	NOTH					
8		<u>.</u>		LIST LI	ENGIH					
9		=	(LSB							
10		RESERVED ALLVLU						IMMED		
11	CONTROL									

The LUN\_V field specifies the address of the volume set that shall have all or part of the check data associated with protected space contained within any underlaying redundancy group(s) recalculated. If the requested logical unit has not been configured the command shall be terminated with a CHECK CONDITION status. The sense key shall be set to ILLEGAL REQUEST, and the additional sense code set to LOGICAL UNIT NOT CONFIGURED.

An immediate (IMMED) bit of zero indicates that status shall be returned after the recalculate operation has completed. An IMMED bit value of one indicates that the target shall return status as soon as the command descriptor block has been validated, and the entire RECALCULATE VOLUME SET CHECK DATA parameters list has been transferred.

An all volume set bit (ALLVLU) of zero indicates that only check data associated with protected space within any underlaying redundancy group(s) of the selected range of LBA\_Vs shall be recalculated. An ALLVLU bit of one indicates that check data associated with protected space within any underlaying redundancy group(s) of the selected volume set shall be recalculated. The RECALCULATE VOLUME SET CHECK DATA parameter list shall be ignored when the ALLVLU bit is one.

The RECALCULATE VOLUME SET CHECK DATA parameter list (see table 95) contains the range of LBA\_Vs to be recalculated.

Table 95 - RECALCULATE VOLUME SET CHECK DATA parameter list

Bit Byte	7	6	5	4	3	2	1	0				
0	(MSB)											
1		•	START LBA_V									
2		•										
3		•	·									
4	(MSB)											
5		•										
6		•	NUMBER OF LBA_V(S)									
7		•										

The START LBA\_V field specifies the LBA\_V(s) the target shall use to begin the recalculation.

The NUMBER OF LBA\_V(s) field specifies the number of consecutive LBA\_V(s) the target shall use for the recalculation.

## 6.6.1.6 VERIFY VOLUME SET CHECK DATA service action

The VERIFY VOLUME SET CHECK DATA service action (see table 96) requests that check data be verified consistent with the protected space within any redundancy group(s) overlaid by the selected range of LBA\_V(s).

Table 96 - VERIFY VOLUME SET CHECK DATA service action

Bit Byte	7	6	5	4	3	2	1	0		
0		OPERATION CODE (BFh)								
1	RESERVED SERVICE ACTION (05h)									
2		RESERVED								
3		RESERVED								
4	(MSB)	LUN V								
5		-	LUN_V (LSB)							
6	(MSB)									
7		-		LICTLI	-NOTH					
8		-		LIST LI	ENGTH					
9		-	(LSB)							
10		RESERVED CONTVER VERIFY RANGE					IMMED			
11		CONTROL								

The LUN\_V field specifies the address of the volume set that shall have any check data associated with protected space contained within any underlaying redundancy group(s) be verified. If the requested logical unit has not been configured the command shall be terminated with a CHECK CONDITION status. The sense key shall be set to ILLEGAL REQUEST, and the additional sense code set to LOGICAL UNIT NOT CONFIGURED.

An immediate (IMMED) bit of zero indicates that status shall be returned after the verification operation has completed at least one time regardless of the CONTVER fields value. An IMMED bit value of one indicates that the target shall return status as soon as the command descriptor block has been validated, and the entire VERIFY VOLUME SET CHECK DATA parameters list has been transferred.

The VERIFY RANGE field is defined in table 97.

Table 97 - VERIFY RANGE

Codes	Description
00b	Verify all volume sets within the selected target. The LUN_V field and the VERIFY VOLUME SET CHECK DATA parameter list shall be ignored.
01b	Verify the entire selected volume set. The VER- IFY VOLUME SET CHECK DATA parameter list shall be ignored.
10b	Only verify the selected LBA_V range within the selected volume set.
11b	Reserved

If any part of the selected volume set(s) has an underlaying redundancy group protection with a redundancy type of no redundancy the VERIFY VOLUME SET CHECK DATA service action shall terminate with CHECK CONDITION status. The sense key shall be set to ILLEGAL REQUEST, and the additional sense code to INVALID FIELD IN CDB.

A continuous verification bit (CONTVER) of zero indicates the check data shall be verified only once. A CONTVER bit of one indicates the check data shall be continuously verified. Verification shall continue until a VERIFY VOLUME SET CHECK DATA service action is requested with the CONTVER bit set to zero and the VERIFY RANGE field set to 00h or the VERIFY RANGE field set to 01h or 10h and the LUN\_V field set to the address of the volume set that is equal to the LUN\_V from the original VERIFY VOLUME SET CHECK DATA service action.

NOTE 25 - If continuous verification is selected the verification executes as a background operation within the target in a vendor specific manner. Continuously may be defined as only verifying check data that underlay the LBA\_V range of any write commands that occur within the range of LBA\_V(s) that overlay a redundancy group that has continuous verification enabled.

Any verification failures occurring before the VERIFY VOLUME SET CHECK DATA service action has completed shall cause the target to terminate the command with a CHECK CONDITION status. The sense key shall be set to MEDIUM ERROR, and the additional sense code shall be set to MISCOMPARE DURING VERIFY OPERATION.

Any verification failures occurring after the VERIFY VOLUME SET CHECK DATA service action has completed the target shall generate a unit attention condition for all initiators. When reporting the unit attention condition the additional sense code shall be set to MISCOMPARE DURING VERIFY OPERATION.

The VERIFY VOLUME SET CHECK DATA parameter list (see table 98) contains the range of LBA\_V(s) to be verified.

The relationship between the VERIFY VOLUME SET CHECK DATA service action and the VERIFY CHECK DATA service action when both service actions have requested the same area be verified is vendor specific. This standard only requires the requested area be verified.

Table 98 - VERIFY VOLUME SET CHECK DATA parameter list

Bit Byte	7	6	5	4	3	2	1	0				
0	(MSB)											
1		•	START LBA_V									
2		•										
3		•										
4	(MSB)											
5			NUMBER OF LBA_V(S)  (									
6		•										
7		•										

The START LBA\_V field specifies the LBA\_V the target shall use to begin the verification.

The NUMBER OF LBA\_V(S) field specifies the number of consecutive LBA\_V(s) the target shall use for the verification.

# 6.7 SPARE (IN) command

## 6.7.1 SPARE (IN) command service actions

The service actions for the SPARE (IN) command are listed in table 99.

Table 99 - Service actions for SPARE (IN) command

Service name	Service actions	Туре	Subclause
REPORT P_EXTENT SPARE REPORT PERIPHERAL DEVICE/COMPONENT DEVICE	00h	М	6.7.1.1
SPARE RESERVED VENDOR SPECIFIC	01h 02h-17h 18h-1Fh	M	6.7.1.2
Key: M = Service action implementation is mandatory. O = Service action implementation is optional.			

# 6.7.1.1 REPORT P\_EXTENT SPARE service action

The REPORT P\_EXTENT SPARE service action (see table 100) requests that information regrading p\_extent spares within the target be sent to the application client.

Table 100 - REPORT P\_EXTENT SPARE service action

Bit Byte	7	6	5	4	3	2	1	0				
0		OPERATION CODE (BCh)										
1		RESERVED SERVICE ACTION (00h)										
2		RESERVED										
3		RESERVED										
4	(MSB)	LUN_S -										
5		•		LUI	N_S			(LSB)				
6	(MSB)											
7		•		ALLOCATIO	NI I FNOTU							
8		•		ALLOCATIO	IN LENGTH							
9		•	-									
10		RESERVED										
11				CON	ΓROL			'				

The LUN\_S field specifies the address of the p\_extent spare that shall be reported per table 101. If the requested logical unit has not been configured the command shall be terminated with a CHECK

CONDITION status. The sense key shall be set to ILLEGAL REQUEST, and the additional sense code set to LOGICAL UNIT NOT CONFIGURED.

A report selected bit (RPTSEL) of zero indicates the target shall report all the p\_extent spare(s) within the target. The LUN\_S field shall be ignored when the RPTSEL bit is zero. A RPTSEL bit of one indicates the target shall report only on the p\_extent spare indicated in the LUN\_S field.

The REPORT P\_EXTENT SPARE parameter list (see table 101) contains a four-byte header that contains the length in bytes of the parameter list and a list of REPORT P\_EXTENT SPARE DESCRIPTORS.

Table 101 - REPORT P\_EXTENT SPARE parameter list

Bit Byte	7	6	5	4	3	2	1	0				
0	(MSB)		REPORT P_EXTENT SPARE LIST LENGTH (n-3)									
1		•										
2		•										
3		•	-									
		REPORT P_EXTENT SPARE DESCRIPTORS(S) (if any)										
4			REPORT P_	EXTENT SPA	RE DESCRIP	TOR (First)						
x+3				(Len	gth x)							
		- - - - -										
n-y+1			REPORT P_EXTENT SPARE DESCRIPTOR (Last)									
n				(Lenç	gth y)							

The REPORT P\_EXTENT SPARE LIST LENGTH field specifies the length in bytes of the following REPORT P\_EXTENT SPARE DESCRIPTOR(s).

The REPORT P\_EXTENT SPARE DESCRIPTOR is defined in table 102.

Table 102 - Format of REPORT P\_EXTENT SPARE DESCRIPTOR

Bit Byte	7	6	5	4	3	2	1	0			
0	(MSB)		LUN_S								
1				LOI	<b>1</b> _0			(LSB)			
2				RESE	RVED						
3				RESE	RVED						
4				D EYTENT F	NESCRIPTOR						
15			P_EXTENT DESCRIPTOR								
16			RESERVED								
17	RESERVED		STATE OF THE SPARE								
18	(MSB)		CO	WEDED I IST	I ENGTH (n.	10)					
19			COVERED LIST LENGTH (n-19)								
20				RESE	RVED						
21				RESE	RVED						
22	(MSB)		00/5050 1/10 0 1/07 (5/07) (5/07)								
23			COVERED LUN_R LIST LENGTH (m-23)								
			С	OVERED LUI	N_R(S) (if an	y)					
24				RESE	RVED						
25				RESE	RVED						
26				COVEDER	LUN_R 0						
27				COVERE	ZON_K O						
					-						
					•						
m-3				RESE	RVED						
m-2				RESE	RVED						
m-1				COVERE	LUN_R X						
m											
			COVERED	P_EXTENT D	ESCRIPTOR	(S) (if any)					
m+1		COVERED P_EXTENT DESCRIPTOR 0									
m+12											
n-11			COVE	RED P_EXTE	NT DESCRIP	TOR y					
n						· ·					

The LUN\_S field specifies the address of the p\_extent spare that covers the listed P\_EXTENT SPARE DESCRIPTOR(s).

The P\_EXTENT DESCRIPTOR contains the position and range of the p\_extent spare addressed in the LUN\_S field. See table 14 for a description of the P\_EXTENT DESCRIPTOR.

The STATE OF THE SPARE field is defined in table 41. If the STATE OF THE SPARE field contains the state 'spare in use' then the device server shall only report the redundancy group or p\_extent being covered by the p\_extent spare indicated in the LUN\_S field of the REPORT P\_EXTENT SPARE DESCRIPTOR.

The COVERED LIST LENGTH field specifies the length in bytes of the following COVERED P\_EXTENT DESCRIPTOR(s) and COVERED LUN\_R fields.

The COVERED LUN\_R LIST LENGTH field specifies the length in bytes of the following COVERED LUN\_R FIELD(s).

The COVERED LUN\_R field contains the address of a redundancy group covered by the p\_extent spare addressed in the LUN\_S field.

The COVERED P\_EXTENT DESCRIPTOR contains the position and range of a p\_extent covered by the p\_extent spare addressed in the LUN S field. See table 14 for a description of the COVERED P\_EXTENT DESCRIPTOR.

#### 6.7.1.2 REPORT PERIPHERAL DEVICE/COMPONENT DEVICE SPARE service action

The REPORT PERIPHERAL DEVICE/COMPONENT DEVICE SPARE service action (see table 103) requests that information regarding peripheral device spares or component device spares within the target be sent to the application client.

Bit 7 6 5 3 2 4 1 0 Byte 0 OPERATION CODE (BCh) 1 **RESERVED** SERVICE ACTION (01h) 2 RESERVED 3 **RESERVED** 4 (MSB) LUN S 5 (LSB) 6 (MSB) 7 ALLOCATION LENGTH 8 9 (LSB) 10 PORCSEL **RPTSEL RESERVED** 11 CONTROL

Table 103 - REPORT PERIPHERAL DEVICE/COMPONENT DEVICE SPARE service action

The LUN\_S field specifies the address of the peripheral device spare or the component device spare that shall be reported per table 104. If the requested logical unit has not been configured the command shall be terminated with a CHECK CONDITION status. The sense key shall be set to ILLEGAL REQUEST, and the

#### X3T10/1047D revision 6c

additional sense code set to LOGICAL UNIT NOT CONFIGURED.

A report selected bit (RPTSEL) of zero indicates the target shall report all the peripheral device spare(s) or component device spare(s) within the target. The LUN\_S field shall be ignored when the RPTSEL bit is zero. A RPTSEL bit of one indicates the target shall report only on the peripheral device spare or the component device spare indicated in the LUN\_S field.

The report peripheral device spare or component device spare selection bit (PORCSEL) of zero indicates the target shall report on all the peripheral device spares within the target. A PORCSEL bit of one indicates the target shall report on all the component device spares within the target.

The REPORT COMPONENT DEVICE/PERIPHERAL DEVICE SPARE parameter list (see table 104) contains a four-byte header that contains the length in bytes of the parameter list and a list of REPORT PERIPHERAL DEVICE/COMPONENT DEVICE SPARE DESCRIPTORS.

Table 104 - REPORT PERIPHERAL DEVICE/COMPONENT DEVICE SPARE parameter list

Bit Byte	7	6	5	4	3	2	1	0			
0	(MSB)										
1		REPOR	T PERIPHER	AL DEVICE/C	OMPONENT	DEVICE SPA	RE LIST				
2		•		LENGT	H (n-3)						
3		<u></u> -									
	REPORT PERIPHERAL DEVICE/COMPONENT DEVICE SPARE DESCRIPTORS(S) (if any)										
4		REPORT PERIPHERAL DEVICE/COMPONENT DEVICE SPARE DESCRIP-									
x+3				TOR (First)	(Length x)						
		· ·									
n-y+1		REPORT P	ERIPHERAL	DEVICE/CON		VICE SPARE	DESCRIP-				
n				TOR (Last)	(Length y)						

The REPORT PERIPHERAL DEVICE/COMPONENT DEVICE SPARE LIST LENGTH field specifies the length in bytes of the following REPORT PERIPHERAL DEVICE/COMPONENT DEVICE SPARE DESCRIPTOR(s).

The REPORT PERIPHERAL DEVICE/COMPONENT DEVICE SPARE DESCRIPTOR is defined in table 105.

Table 105 - Format of REPORT PERIPHERAL DEVICE/COMPONENT DEVICE SPARE DESCRIPTOR

Bit Byte	7	6	5	4	3	2	1	0		
0	(MSB)			LUI						
1				LUI	N_S			(LSB)		
2				RESE	RVED					
3				RESE	RVED					
4				I I IN D	/LUN C					
5		LUN_P/LUN_C								
6			RESERVED							
7	RESERVED	/ED STATE OF THE SPARE								
8				RESE	RVED					
9				RESE	RVED					
10	(MSB)		COVERED	LOGICAL UN	IT I IST I ENG	этн (n-11)				
11			OOVERED	LOGIOAL OIV	II LIOI LLING	, , , , , , , , , , , , , , , , , , ,		(LSB)		
			COVERED LO	OGICAL UNIT	DESCRIPTO	R(S) (if any	)			
12			COVER	ED LOGICAL	INIT DESCR	IPTOR ()				
15										
		· ·								
n-3			00)/55:	-D 1 001041	I INIT DECCE	IDTOD V				
n			COVERI	ED LOGICAL	UNII DESCR	ігток у				

The LUN\_S field specifies the address of the peripheral device spare or component device spare that covers the listed PERIPHERAL DEVICE/COMPONENT DEVICE SPARE DESCRIPTOR(s).

The LUN\_P/LUN\_C field contains the address of the logical unit that defines the peripheral device spare or the component device spare addressed in the LUN\_S field.

The STATE OF THE SPARE field is defined in table 41. If the STATE OF THE SPARE field contains the state 'spare in use' then the device server shall only report the logical unit being covered by the peripheral device spare or component device spare indicated in the LUN\_S field of the REPORT PERIPHERAL DEVICE/COMPONENT DEVICE SPARE DESCRIPTOR.

The COVERED LOGICAL UNIT LIST LENGTH field specifies the length in bytes of the following COVERED LOGICAL UNIT DESCRIPTORS.

The COVERED LOGICAL UNIT DESCRIPTOR (see table 106) contains the list of logical units covered by the

#### X3T10/1047D revision 6c

peripheral device or component device spare addressed in the LUN\_S field.

Table 106 - Data format of COVERED LOGICAL UNIT DESCRIPTOR

Bit Byte	7	6	5	4	3	2	1	0			
0		RESERVED									
1		RESE	RVED			LOGICAL (	JNIT TYPE				
2	(MSB)										
3				LU	JIN			(LSB)			

The LOGICAL UNIT TYPE field (see table 107) indicates the type of logical unit addressed in the LUN field.

Table 107 - LOGICAL UNIT TYPES

Codes	Descriptions
0h	Physical logical unit (peripheral device)
1h	Reserved
2h-3h	Reserved
4h	Component logical unit (component device)
5h	Redundancy group
6h	Reserved
7h-Bh	Reserved
Ch-Fh	Vendor specific

The LUN field contains the logical unit number of the logical unit indicated by the LOGICAL UNIT TYPE field.

# 6.8 SPARE (OUT) command

## 6.8.1 SPARE (OUT) command service actions

The service actions for the SPARE (IN) command are listed in table 108.

Table 108 - Service actions for spare (out) command

Service name	Service actions	Туре	Subclause
CREATE/MODIFY P_EXTENT SPARE CREATE/MODIFY PERIPHERAL DEVICE/COMPONENT	00h	0	6.8.1.1
DEVICE SPARE	01h	0	6.8.1.2
DELETE SPARE	02h	0	6.8.1.3
RESERVED	03h-17h		
VENDOR SPECIFIC	18h-1Fh		
Key: M = Service action implementation is mandatory. O = Service action implementation is optional.			

## 6.8.1.1 CREATE/MODIFY P EXTENT SPARE service action

The CREATE/MODIFY P\_EXTENT SPARE service action (see table 109) requests the target to create a p\_extent spare or modify an existing p\_extent spare. If the create operation fails to complete successfully the command shall be terminated with a CHECK CONDITION status. The sense key shall be set to HARDWARE ERROR, and the additional sense code set to CREATION OF LOGICAL UNIT FAILED. If the modification operation fails to complete successfully the command shall be terminated with a CHECK CONDITION status. The sense key shall be set to HARDWARE ERROR, and the additional sense code set to MODIFICATION OF LOGICAL UNIT FAILED.

Table 109 - CREATE/MODIFY P\_EXTENT SPARE service action

Bit Byte	7	6	5	4	3	2	1	0			
0		OPERATION CODE (BDh)									
1		RESERVED SERVICE ACTION (00h)									
2		RESERVED									
3		RESERVED									
4	(MSB)		LUN_S -								
5				LON	v_5			(LSB)			
6	(MSB)										
7				LIST LE	NOTH						
8				LIST LE	INGIA						
9											
10	RESERVED	SETLUN RESERVED						IMMED			
11				CON	ΓROL						

The LUN\_S field specifies the address of the p\_extent spare that shall be created or modified. If the requested logical unit is not configurable the command shall be terminated with a CHECK CONDITION

#### X3T10/1047D revision 6c

status. The sense key shall be set to ILLEGAL REQUEST, and the additional sense code set to LOGICAL UNIT NOT SUPPORTED.

An immediate (IMMED) bit of zero indicates that status shall be returned after the create/modify p\_extent spare operation has completed. An IMMED bit value of one indicates that the target shall return status as soon as the command descriptor block has been validated, and the entire CREATE/MODIFIY P\_EXTENT SPARE parameters list has been transferred.

A set LUN (SETLUN) bit of zero indicates the target shall assign to the p\_extent spare being created the logical unit number contained in the LUN\_S field. A SETLUN bit of one indicates that the target shall assign a logical unit number to the p\_extent spare. The LUN\_S field shall be ignored when the SETLUN bit is set to one.

The CREATE/MODIFY P\_EXTENT SPARE parameter list (see table 110) contains a list of COVERED P\_EXTENT DESCRIPTORS that shall be used to create or modify the addressed p\_extent spare.

Table 110 - CREATE/MODIFY P\_EXTENT SPARE parameter list

Bit Byte	7	6	5	4	3	2	1	0		
0			en/	ADE D EVTEN	IT DESCRIP	rop.				
11		•	5P <i>F</i>	ARE P_EXTEN	II DESCRIP	IOR				
12	(MSB)		CO	VERED LIST	I ENGTH (n.	13)				
13			00	VERED LIST	LENGTH (II-	13)		(LSB)		
14	(MSB)		COVERED LUN_R LIST LENGTH (m-15)							
15		COVERED LON_R LIST LENGTH (III-13)								
		COVERED LUN_R(S) (if any)								
16				RESE	RVED					
17		RESERVED								
18		COVERED LUN_R 0								
19				OOVERED	2011_11 0					
m-3				RESE	RVED					
m-2				RESE	RVED					
m-1				COVERED	ALUN D.V					
m				COVEREL	LON_R X					
			COVERED	P_EXTENT D	ESCRIPTOR	(S) (if any)				
m+1		COVERED B. EVTENT RECORDINGS O								
m+12		- COVERED P_EXTENT DESCRIPTOR 0								
		· ·								
n-11			2017	DED D. 51/75	NT DECOS:	TODA				
n		-	COVE	RED P_EXTE	NT DESCRIP	ток у				

The SPARE P\_EXTENT DESCRIPTOR contains the position and range of the p\_extent spare that shall be created or modified. See table 14 for a description of the SPARE P\_EXTENT DESCRIPTOR.

The COVERED LIST LENGTH field specifies the length in bytes of the following COVERED LUN\_R fields and COVERED P\_EXTENT DESCRIPTOR(s).

#### X3T10/1047D revision 6c

The COVERED LUN\_R LIST LENGTH field specifies the length in bytes of the following COVERED LUN\_R FIELD(s).

The COVERED LUN\_R field contains the address of a redundancy group that shall be covered by the p\_extent spare addressed in the LUN\_S field.

The COVERED P\_EXTENT DESCRIPTOR contains the position and range of a p\_extent that shall be covered by the p\_extent spare addressed in the LUN\_S field. See table 14 for a description of the COVERED P\_EXTENT DESCRIPTOR.

## 6.8.1.2 CREATE/MODIFY PERIPHERAL DEVICE/COMPONENT DEVICE SPARE service action

The CREATE/MODIFY PERIPHERAL DEVICE/COMPONENT DEVICE SPARE service action (see table 111) requests the target to create a peripheral device spare or a component device spare or modify an existing peripheral device spare or a component device spare. If the create operation fails to complete successfully the command shall be terminated with a CHECK CONDITION status. The sense key shall be set to HARDWARE ERROR, and the additional sense code set to CREATION OF LOGICAL UNIT FAILED. If the modification operation fails to complete successfully the command shall be terminated with a CHECK CONDITION status. The sense key shall be set to HARDWARE ERROR, and the additional sense code set to MODIFICATION OF LOGICAL UNIT FAILED.

Table 111 - CREATE/MODIFY PERIPHERAL DEVICE/COMPONENT DEVICE SPARE service action

Bit Byte	7	6	5	4	3	2	1	0		
0		OPERATION CODE (BDh)								
1		RESERVED	RESERVED SERVICE ACTION (01h)							
2	(MSB)		LUN POPULIN C							
3			LUN_P or LUN_C -							
4	(MSB)		LUN_S -							
5				LOI	v_5		•	(LSB)		
6	(MSB)									
7				LIST LE	NOTH		•			
8				LIST LE	INGTH		•			
9			<del>-</del>							
10	RESERVED	SETLUN RESERVED PORCSEL					IMMED			
11		CONTROL								

The LUN\_P or LUN\_C field contains the address of the logical unit that defines the peripheral device spare or the component device spare addressed in the LUN\_S field. If the requested logical unit is not configurable the command shall be terminated with a CHECK CONDITION status. The sense key shall be set to ILLEGAL REQUEST, and the additional sense code set to LOGICAL UNIT NOT SUPPORTED.

The LUN\_S field specifies the address of the peripheral device spare or the component device spare that shall be created or modified.

An immediate (IMMED) bit of zero indicates that status shall be returned after the create/modify peripheral device/component device spare operation has completed. An IMMED bit value of one indicates that the target shall return status as soon as the command descriptor block has been validated, and the entire CREATE/MODIFIY PERIPHERAL DEVICE/COMPONENT DEVICE spare parameters list has been transferred.

The peripheral device spare or component device spare selection bit (PORCSEL) of zero indicates the target shall create or modify a peripheral device spare. When PORCSEL is zero the LUN\_P or LUN\_C field shall contain a lun\_p value. A PORCSEL bit of one indicates the target shall create or modify a component device spare. When PORCSEL is one the LUN\_P or LUN\_C field shall contain a lun\_c value.

A set LUN (SETLUN) bit of zero indicates the target shall assign to the peripheral device spare or component device spare being created the logical unit number contained in the LUN\_S field. A SETLUN bit of one indicates that the target shall assign a logical unit number to the peripheral device spare or component device spare. The LUN\_S field shall be ignored when the SETLUN bit is set to one.

The CREATE/MODIFY PERIPHERAL DEVICE/COMPONENT DEVICE SPARE parameter list (see table 112) contains a list of COVERED LOGICAL UNIT DESCRIPTORS that shall be used to create or modify the addressed peripheral device spare or component device spare.

Table 112 - CREATE/MODIFY PERIPHERAL DEVICE/COMPONENT DEVICE SPARE parameter list

Bit Byte	7	6	5	4	3	2	1	0			
		COVERED LOGICAL UNIT(S) (if any)									
0											
3		COVERED LOGICAL UNIT DESCRIPTOR 0									
n-3		COVERED LOGICAL UNIT DESCRIPTOR X									
n		-	COVER	LD LOGICAL	DIVIT DESCR	II TOICX					

The COVERED LOGICAL UNIT DESCRIPTOR contains the address of a logical unit that shall be covered by the peripheral device spare or component device spare being created or modified. See table 106 for a description of the COVERED LOGICAL UNIT DESCRIPTOR.

#### 6.8.1.3 DELETE SPARE service action

The DELETE SPARE service action (see table 113) requests the target delete the addressed spare.

Table 113 - DELETE SPARE service action

Bit Byte	7	6	5	4	3	2	1	0		
0	OPERATION CODE (BDh)									
1		RESERVED		SERVICE ACTION (02h)						
2	RESERVED									
3	RESERVED									
4	(MSB)									
5		LUN_S								
6	RESERVED									
7	RESERVED									
8	RESERVED									
9	RESERVED									
10	RESERVED									
11	CONTROL									

The LUN\_S field specifies the address of the spare that shall be deleted. If the requested logical unit has not been configured the command shall be terminated with a CHECK CONDITION status. The sense key shall be set to ILLEGAL REQUEST, and the additional sense code set to LOGICAL UNIT NOT CONFIGURED. If the addressed spare has covered one of the redundancy groups, peripheral devices, component devices, or p\_extents the command shall be terminated with a CHECK CONDITION status. The sense key shall be set to ILLEGAL REQUEST, and the additional sense code set to REMOVE OF LOGICAL UNIT FAILED.

#### 6.9 Parameters for direct-access devices

## 6.9.1 Mode parameters

This subclause defines the descriptors and pages for mode parameters used with SCSI-3 storage array devices.

The mode parameter list, including the mode parameter header and mode block descriptor are described in the SCSI-3 Primary Commands Standard.

The MEDIUM TYPE field is contained in the mode parameter header (see SCSI-3 Primary Commands Standard). For SCSI-3 storage array devices the MEDIUM TYPE field is reserved.

The DEVICE SPECIFIC PARAMETER field is contained in the mode parameter header (see SCSI-3 Primary Commands Standard). For SCSI-3 storage array devices the DEVICE SPECIFIC PARAMETER field is reserved.

The DENSITY CODE field is contained in the mode parameter block descriptor (see SCSI-3 Primary Commands Standard). For SCSI-3 storage array devices the DENSITY CODE field is reserved.

The mode page codes for SCSI-3 storage array devices are shown in table 114.

Page Code Description Subclaus 0Ah Control mode page SPC 02h Disconnect-reconnect page SPC LUN mapping page 1Bh 6.9.1.1 09h Peripheral device page SPC 0Dh Power condition page SPC Key: SPC = SCSI-3 Primary Commands Standard.

Table 114 - Mode page codes

### 6.9.1.1 LUN mapping page

The LUN mapping page (see table 115) is only required for protocols that do not support 8 byte LUN addressing (see 5.2.1). The LUN mapping page contains a list of LUN mappings that may be used to address peripheral devices and volume sets within a target that conforms to the SCSI-3 Interlocked Protocol Standard. When the LUN mappings are being used LUNs 1-31 of the IDENTIFY message (See A.1) shall each point to a specific LUN mapping within the LUN mapping page. The LUN mapping shall be used by the target to determine to which bus/target/LUN to send the command attached to the IDENTIFY message.

Table 115 - LUN mapping page

Bit Byte	7	6	5	4	3	2	1	0		
0	PS	RESERVED	PAGE CODE (1Bh)							
1	PAGE LENGTH (FAh)									
2	RESERVED									
3	RESERVED									
4	(MSB)	- LUN 1 MAPPING (L								
11										
	· :									
244	(MSB)	LUN 31 MAPPING (								
251										

The parameters savable (PS) bit is only used with the MODE SENSE command. This bit is reserved with the MODE SELECT command. A PS bit of one indicates that the target is capable of saving the page in a non-volatile vendor-specific location.

A LUN mapping active bit (ACTIVE) of zero indicates the LUN XX MAPPING fields shall not be used to address any peripheral devices or volume sets. An ACTIVE bit of one indicates a LUN XX MAPPING field shall be used to determine to which bus/target/LUN to send the command. LUN field addresses 1-31 of the IDENTIFY message (see A.1) shall reference a specific LUN XX MAPPING field within the LUN mapping page when the ACTIVE bit is one. (e.g., A LUN field value of 3 would cause the target to use the LUN 3 MAPPING field to determine the bus/target/LUN per addressing rules (see 5.2.1).

The LUN XX MAPPING fields specify the bus/target/LUN of a peripheral device or volume set. See table 3 for a definition of the LUN XX MAPPING field. A value of zeros in the LUN XX MAPPING field shall indicate an undefined bus/target/LUN.

Any request from an application client to change a LUN XX MAPPING field shall be delayed until all tasks using the LUN XX MAPPING field to be changed have completed. The MODE SELECT command shall not complete until all the LUN XX MAPPING fields being changed have been changed.

Any attempt by an application client to address an undefined bus/target/LUN shall be terminated with a CHECK CONDITION status. The sense key shall be set to ILLEGAL REQUEST and the additional sense code shall be set to LOGICAL UNIT NOT SUPPORTED.

Annex A (normative)

## A.0 SCSI-3 storage array IDENTIFY message format

This annex defines a modification from the description in the SCSI-3 Interlocked Protocol Standard of the IDENTIFY message LUN field. In addition to the requirements and definitions listed in this annex, all requirements and definitions of the IDENTIFY message contained within the SCSI-3 Interlocked Protocol Standard shall be followed by all SCSI-3 storage arrays that conform to the SCSI-3 Interlocked Protocol Standard.

# A.1 IDENTIFY message

The IDENTIFY message (see table A.1) shall be used between SCSI devices that conform to the SCSI-3 Interlocked Protocol Standard.

 Bit Byte
 7
 6
 5
 4
 3
 2
 1
 0

 0
 IDENTIFY
 DISCPRIV
 VOLSEL
 LUN

Table A.1 - IDENTIFY message format

See the SCSI-3 Interlocked Protocol Standard for the definition of the IDENTIFY bit.

See the SCSI-3 Interlocked Protocol Standard for the definition of the DISCPRIV bit.

A volume select bit (VOLSEL) bit of zero indicates that the target shall use the LUN field as either a pointer to a LUN XX MAPPING field of the LUN mapping mode page (see 6.9.1.1) or as the address of a peripheral device within the target. If the ACTIVE bit of the LUN mapping mode page is set to zero or there is no LUN mapping mode page then the LUN field indicates the address of a peripheral device. If the ACTIVE bit of the LUN mapping mode page is set to one then the LUN field is a pointer to a LUN XX MAPPING field of the LUN mapping mode page.

A VOLSEL bit of one indicates that the target shall use the LUN field as the address of a volume set. If the VOLSEL bit is set to one the LUN mapping mode page shall not be used.

The logical unit number (LUN) field indicates the address of a peripheral device, the address of a volume set or the pointer to a LUN XX MAPPING field. The response to an invalid value in the LUN field is described in SCSI-3 Architecture Model Standard.

Annex B (informative)

# B.0 SCSI-3 storage array addressing examples

This annex contains several examples addressing an SCSI-3 storage array.

## B.1 Addressing Examples for the 8-byte LUN structure

Several addressing examples follow. The conventions used within these examples are:

Layer 1 M:Ts:Ps:Ls or M:P:T or M:L or u Layer 2 M:Ts:Ps:Ls or M:P:T or M:L or u Layer 3 M:Ts:Ps:Ls or M:P:T or M:L or u Layer 4 M:Ts:Ps:Ls or M:P:T or M:L or u

Where:M is the address method (2 bit field)

P is the bus number (6 bit field)
Ps is the bus number (3 bit field)
T is the target (8 bit field)
Ts is the target (6 bit field)
L is the logical unit number (14 bit field)
Ls is the logical unit number (5 bit field)
u is unused and set to zero (16 bit field)

NOTE 26 - P and Ps is a value that starts at one, since the zero value is reserved for the SCSI-3 storage array and devices that have no external path.

NOTE 27 - T and Ts is a value that starts at zero and is limited to one less than the number of attachable SCSI devices, since the path initiator's address is also included in that address space.

## B.1.1 Example 1:

Addressing the first layer SCSI-3 storage array (for all control, creation, management functions and for identify)

Layer 1 0:0:0 Layer 2 u Layer 3 u Layer 4 u

Addresses will appear on the first level paths as required by the function.

## B.1.2 Example 2:

Addressing a fan at address 7 within the first layer SCSI-3 storage array (a component device not physically on an identifiable SCSI path.)

Layer 1 0:0:0 Layer 2 u Layer 3 u Layer 4 u

The address on the component device is within the CDB of the command.

### B.1.3 Example 3:

Addressing a local peripheral device

The address of the second peripheral device on the third path would be:

Layer 1 0:3:1 Layer 2 u Layer 3 u Layer 4 u

The second level path would use path 3 to access target 1. The LUN value is 0.

### B.1.4 Example 4:

Addressing any volume set controlled by the first SCSI-3 storage array (including volume sets constructed from ps extents defined by lower SCSI-3 storage arrays)

Layer 1 1:L Layer 2 u Layer 3 u Layer 4 u

Addresses will appear on the first level paths as required by the function.

## B.1.5 Example 5:

Addressing an SCSI-3 storage array at the second layer of the hierarchy.

NOTE 28 - The second layer SCSI-3 storage array is also a peripheral device on the first layer path. In this example the SCSI-3 storage array is on the fourth path and is the third target address.

Layer 1 0:4:2 Layer 2 0:0:0 Layer 3 u Layer 4 u

A LUN address of the following form would be emitted on the fourth path to target address 2 (following the shift the address rules per 5.2.1.2) to get at the SCSI-3 storage array.

Layer 1 0:0:0 Layer 2 u Layer 3 u Layer 4 u

## B.1.6 Example 6:

Addressing a peripheral device of the above second level SCSI-3 storage array (the second peripheral device on the third path of that second level SCSI-3 storage array).

Layer 1 0:4:2 Layer 2 0:3:1 Layer 3 u Layer 4 u

The LUN address emitted on the fourth path to target address 2 (following the shift the address rules per 5.2.1.2). This peripheral device could be used as a component of a volume set defined by the first level

#### X3T10/1047D revision 6c

SCSI-3 storage array or the second level SCSI-3 storage array.

```
Layer 1 0:3:1
Layer 2 u
Layer 3 u
Layer 4 u
```

The LUN address emitted on the third path of the second level SCSI-3 storage array to target address 1 would be 0.

#### B.1.7 Example 7:

Addressing any volume set of the above second level SCSI-3 storage array.

NOTE 29 - The second level SCSI-3 storage array's entry path is being addressed directly. This volume set could be used as a component of a volume set defined by the first layer SCSI-3 storage array.

```
Layer 1 0:4:2
Layer 2 1:L
Layer 3 u
Layer 4 u
```

Address emitted on the fourth path to target address 2 (following the shift the address rules per 5.2.1.2). This is a standard volume set address.

```
Layer 1 1:L
Layer 2 u
Layer 3 u
Layer 4 u
```

Addresses will appear on the second level paths as required by the function.

### B.1.8 Example 8:

Addressing a peripheral device that has LUN's behind a standard target. As an example, LUN 4 behind the second target on the third path of the first level SCSI-3 storage array.

```
Layer 1 2:1:3:4
Layer 2 u
Layer 3 u
Layer 4 u
```

### B.1.9 Example 9:

NOTE 30 - Fourth layer devices must be single LUN devices.

As a peripheral device addressing example, if the first layer was P=3,T=7; the second layer was P=4, T=6; the third layer was P=1, T=5; and the fourth layer was P=7, T=2 then the address would be:

```
Layer 1 0:3:7
Layer 2 0:4:6
Layer 3 0:1:5
Layer 4 0:7:2
```

The LUN issued on the first layer path 3, target 7 would be:

```
Layer 1 0:4:6
```

```
Layer 2 0:1:5
Layer 3 0:7:2
Layer 4 u
```

The LUN issued on the second layer path 4, target 6 would be:

```
Layer 1 0:1:5
Layer 2 0:7:2
Layer 3 u
Layer 4 u
```

The LUN issued on the third layer path 1, target 5 would be:

```
Layer 1 0:7:2
Layer 2 u
Layer 3 u
Layer 4 u
```

The LUN issued on the fourth layer path 7, target 2 would be 0.

# B.2 Addressing Examples for the 6-bit LUN structure

The following examples assume the LUN mapping page is not active.

Several addressing examples follow. The conventions used within these examples are:

```
Layer 1 V:L
```

Where: V is the Volume Select (1 bit field)
L is the Logical Unit Number (5 bit field)

NOTE 31 - Information on logical units at layers below layer 1 is not available to the application client when the 6-bit LUN structure is used. Logical units below layer 1 may only be addressed directly using a vendor specific translation of the 6-bit LUN.

## B.2.10 Example 1:

Addressing the first layer SCSI-3 storage array (for all control, creation, management functions and for identify)

Layer 1 0:0

Addresses will appear on the first level paths as required by the function.

## B.2.11 Example 2:

Addressing a fan at address 7 within the SCSI-3 storage array.

Layer 1 0:7

No first level path will be used.

### B.2.12 Example 3:

Addressing any peripheral device.

The address of a drive in the SCSI-3 storage array:

## X3T10/1047D revision 6c

Layer 1 0:L

Addresses will appear on the first level paths as required by the function.

B.2.13 Example 4:

Addressing any volume set:

Layer 1 1:L

Addresses will appear on the first level paths as required by the function.

# Annex C (informative)

# C.0 Examples of check data and user data mappings

# C.1 Example XOR redundancy mapping

Figure C.1 contains an example of how XOR redundancy check data would be interleaved with user data.




Figure C.1 - XOR redundancy mapping example

# C.2 User data mapping examples

## C.2.1 Example of user data mapped in a RAID 5 configuration

Figure C.2 contains an example of how user data would be mapped in a RAID 5 configuration.




Figure C.2 - User data mapping for a RAID 5 configuration

## C.2.2 Example of user data mapping in a RAID 3 configuration

Figure C.3 contains an example of how user data would be mapped in a RAID 3 configuration.



Figure C.3 - User data mapping for a RAID 3 configuration