FITS: TRIUMPH T509/595, 955i,

PART# 86602R-42:520

SUPERLITE RS7 SERIES 520 CONVERSION BLACK STEEL REAR SPROCKET - TRIUMPH