FM9003 - Application Note

Layout and thermal guidelines for FM9003

1. Scope
  This application note is a demo artifact for website preview.

2. Recommended layout
  Keep the input capacitor loop as small as possible.
  Use a solid ground plane under the device.

3. Thermal considerations
  Provide sufficient copper area on the drain / VOUT pads.

4. Measured values (demo)

Charge Current	1A?????
Boost Output	5V / 1A
Input Voltage	3.0V - 5.5V
CV Accuracy	+/-1%
Package	QFN-16 3x3