

## Instructions for mounting the Mini Button Pad Set (part #08963) to an enclosure

- 1) Carefully cut out one of the patterns (drawing #1)
- 2) Tape the pattern to your enclosure in the location you wish to mount the buttons
- 3) If you are mounting the three button set, drill ONLY the centers of the GREEN crosses (skip to step number five)
- 4) If you are breaking the pad, bezel and break out board appart and mounting sparately follow these instructions-
  - 4a) Cut out the three sections of the pattern
  - 4b) Tape each section to the location you wish to mount the buttons on your enclosure
  - 4c) Carefully drill out the eight extra mounting holes marked on the underside of the bezel and top side of the button pad with a 3/32" drill bit
- 5) Center punch and drill the solid crosses with a 3/32" drill bit
- 6) Center punch and drill the dashed crosses with a 1/2" drill bit
- 7) Remove pattern from your enclosure
- 8) Install the button pad and circuit board from the inside of your enclosure
- 9) We reccomend securing the set with 2-56 button head machine screws (if you are not using the bezel) or 2-56 flat head machine screws (if you are using the bezel on the outside of the enclosure)





Drawing #1

Tolerances, Unless noted-0.0 +/-0.00 +/-0.000 +/-

SM_BUTTON_PAD_INSTALLATION	
03 Nov 08	Drawn by Spark Fun Electronics
	for Customer Reference
	Drafter CH Scale 1.00