

# **Pre-filtration for Sample Preservation**

### D. Vaulot, R. Edern, C. Romero

## **Abstract**

Citation: D. Vaulot, R. Edern, C. Romero Pre-filtration for Sample Preservation. protocols.io

dx.doi.org/10.17504/protocols.io.nupdevn

Published: 15 Mar 2018

## **Materials**

Filtration Tower 300-4000 by Thermo Fisher Scientific

Nuclepore Filter WHA111112 by Sigma Aldrich

#### **Protocol**

#### Installation

#### Step 1.

Install two filters on top of each other in the filtration tower to ensure maximum filtration efficiency.



#### **Filtration**

# Step 2.

Filter 200 ml of sample by gravity without exercising any depression.



200 ml Additional info: sample

#### Collection

#### Step 3.

Collect the filtered sample.

# Cleaning

# Step 4.

Rince very thoroughly filtration tower before proceeding to the next sample.