

May 09, 2019

Working

U Mass - Amylase 👄

Jason Kim¹

¹University of Massachusetts

dx.doi.org/10.17504/protocols.io.xq4fmyw

Mouse Metabolic Phenotyping Centers

 $Tech. \ support\ email: \textbf{info@mmpc.org}$



Lili Liang 6

ABSTRACT

Summary:

This experiment involves a spectrophotometric measurement using Roche Cobas Clinical Chemistry Analyzer.

EXTERNAL LINK

https://mmpc.org/shared/document.aspx?id=175&docType=Protocol

MATERIALS

NAME ~	CATALOG #	VENDOR V	CAS NUMBER V RRID V
a-Amylase EPS Pancreatic	05401771190	Roche	
Calibrator f.a.s.	10759350 360	Roche	
Precinorm U Plus	12149435 160	Roche	
Precipath U Plus	12149443 160	Roche	
NaCl Diluent 9%	04774230 190	Roche	
Cleaner	04774248 190	Roche	
Micro Sample cups	11406680 001	Roche	
NERL High Quality Water	9805	Fisher Scientific	

MATERIALS TEXT

Note:

Roche, RRID:SCR_001326

Fisher Scientific, RRID:SCR_008452

BEFORE STARTING

Notes:

- $\sqrt{}$ Try to use freshly prepared serum and plasma samples for this assay.
- \checkmark No dilution or treatment of the sample is required, but plasma samples should be centrifuged to remove any fibrin/fibrinogen
- √ Samples should be stored at 2-8°C for 24 hours prior to analysis. For longer periods, store samples at -70°C, and avoid repeated
- √ A 50 µl dead volume is required in addition to sample volume for multi-protein analysis (typically 1-5 µl).

1	Perform daily quality control assessment of instrumentation before analysis.
2	Load each sample into a specialized micro-sample cup for the clinical chemistry analyzer.

4 Collect and analyze the data.

Select Amylase test on display and run the analysis.

3

This is an open access protocol distributed under the terms of the Creative Commons Attribution License, which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited