

# SensiFAST™ Probe Hi-ROX One-Step Kit

#### **Bioline**

## **Abstract**

The SensiFAST™ Probe Hi-ROX One-Step Kit has been formulated for highly reproducible first-strand cDNA synthesis and subsequent real-time PCR in a single tube. The kit is formulated for use with probe-detection technology, including TaqMan®, Scorpions® and molecular beacon probes. A combination of the latest advances in buffer chemistry together with a reverse transcriptase and hot-start DNA polymerase system, ensures that SensiFAST Probe Hi-ROX One-Step Kit produces fast, highly-specific and ultra-sensitive one-step real-time RT-PCR.

The SensiFAST Probe Hi-ROX One-Step Kit consists of a 2x SensiFAST Probe Hi-ROX One-Step mix, separate reverse transcriptase and RiboSafe RNase Inhibitor.

Citation: Bioline SensiFAST™ Probe Hi-ROX One-Step Kit. protocols.io

dx.doi.org/10.17504/protocols.io.fyubpww

Published: 24 Nov 2016

#### **Guidelines**

#### **Kit Components**

Reagent	100 x 20 µL reactions 500 x 20 µL reactions
Neugent	TOO A EO ME I CUCCIONS SOO A EO ME I CUCCIONS

SensiFAST™ Probe Hi-ROX One-Step mix (2:	x) 1 x 1 mL	5 x 1 mL
RiboSafe RNase Inhibitor	1 x 40 μL	1 x 200 μL
Reverse transcriptase	1 x 20 μL	1 x 100 μL
DEPC-H <sub>2</sub> O	1 x 1.8 mL	2 x 1.8 mL

## Instrument compatibility

The SensiFAST Probe Hi-ROX One-Step Kit has been optimized for use with all probe chemistries, including TaqMan, FRET, Scorpions and molecular beacon probes on real-time PCR instruments listed in the following compatibility table, each of these instruments having the capacity to analyze the real-time PCR data with the passive reference signal either on or off. The kit is also compatible with

several instruments that do not require the use of ROX, such as the Qiagen (Corbett) Rotor-Gene™ 6000, the Bio-Rad CFX96 or the Roche LightCycler® 480.

#### **Manufacturer Model**

ABI (Invitrogen) 7000, 7300, 7700, 7900, 7900HT, StepOne™ and StepOne™ Plus

#### **General considerations**

When handling RNA, it is important to use RNase-free plasticware and reagents. We also recommend performing RNA work in an RNase-free area. To help prevent any carry-over DNA contamination, we recommend that separate areas are maintained for reaction set-up, PCR amplification and any post-PCR gel analysis. It is essential that any tubes containing amplified DNA product are not opened in the reaction set-up area.

**Primers and probe:** These guidelines refer to the use of dual-labeled probes. Please refer to the relevant literature when using other probe types. The sequence and concentration of the probe and primers, as well as amplicon length, can be critical for specific amplification, yield and overall efficiency of any real-time RT-PCR.

We strongly recommend taking the following points into consideration when designing and running your real-time RT-PCR:

- use primer-design software, such as Primer3 or visual OMP™ (<a href="http://frodo.wi.mit.edu/primer3/">http:// dnasoftware.com/</a>, respectively). Primers should have a melting temperature (Tm) of approximately 60°C. The Tm of the probe should be approximately 10°C higher than that of the primers
- optimal amplicon length should be 80-200 bp, and should not exceed 400 bp
- final primer concentration of 400 nM is suitable for most probe reactions. However, to determine the optimal concentration we recommend titrating in the range 0.2-1 μM
- use an equimolar primer concentration
- a final probe concentration of 100 nM is suitable for most applications. We recommend that the final probe concentration is at least 2-fold lower than the primer concentration
- Note: In multiplex real-time RT-PCR, probe concentrations in excess of 100 nM can result in cross-channel fluorescence
- where possible, use intron-spanning primers to avoid amplification from genomic DNA

**Template:** It is important that the RNA template is intact and devoid of DNA or contaminating inhibitors of both reverse transcription and PCR. For high purity RNA, we recommend using the Bioline ISOLATE II RNA Mini Kit (BIO-52073). RNA stocks and dilutions should be made in DEPC-treated Water to avoid any RNase-mediated degradation.

The recommended amount of template for one-step real-time RT-PCR is dependent upon the type of RNA used:

- total RNA: purified total RNA can be used in the range from 1 pg to 1 µg per 20 µL reaction
- mRNA: purified mRNA can be used from 0.01 pg per 20 μL reaction

**MgCl<sub>2</sub>:** The MgCl<sub>2</sub> concentration in the 1x reaction mix is 3 mM. In the majority of real-time RT-PCR conditions this is optimal for both the reverse transcriptase and the hot-start DNA polymerase. If necessary, we suggest titrating the MgCl<sub>2</sub> to a maximum of 5 mM.

**RT-PCR controls:** It is important to detect the presence of contaminating DNA that may affect the reliability of the data. Always include a no-RT control reaction, by omitting the reverse transcriptase from the reaction.

**Optional ROX:** The SensiFAST Probe Hi-ROX One-Step Kit is premixed with ROX (5-carboxy-X-rhodamine, single isomer), so that ROX fluorescence can be optionally detected on certain real-time instruments. If your real-time PCR instrument has the capability of using ROX and you wish to use this option, then this option must be selected by the user in the software.

#### **Troubleshooting Guide:**

See the Bioline full documentation for detailed troubleshooting instructions.

http://www.bioline.com/us/downloads/dl/file/id/3301/sensifast probe hi rox one step kit manual.pdf

#### **Materials**

SensiFAST™ Probe Hi-ROX One-Step Kit BIO-77001 by Bioline

### **Protocol**

## Reaction mix composition

#### Step 1.

Prepare an real-time RT-PCR mastermix. The volumes given below are based on a standard 20  $\mu$ L final reaction mix and can be scaled accordingly.

Reagent	Volume	Final concentration
2x SensiFAST Probe Hi-ROX One-Step Mix	10 μL	1x
10 μM Forward Primer	0.8 μL	400 nM
10 μM Reverse Primer	0.8 μL	400 nM
10 μM Probe	0.2 μL	100 nM
Reverse transcriptase	0.2 μL	-
RiboSafe RNase Inhibitor	0.4 μL	-
H <sub>2</sub> O	up to 16 μL	
Template	4 μL	
	2	0 μL Final volume

## Sensitivity testing and Ct values

## Step 2.

When comparing SensiFAST with a mix from another supplier we strongly recommend amplifying from a 10-fold template dilution series. Loss of detection at low template concentration is the only direct measurement of sensitivity. An early  $C_t$  value is not an indication of good sensitivity, but rather an indication of speed.

#### Suggested real-time RT-PCR conditions

# Step 3.

The following real-time RT-PCR conditions are suitable for the SensiFAST Probe Hi-ROX One-Step Kit with the majority of amplicons and real-time PCR instruments. However, the cycling conditions can be varied to suit different probe-based reactions or machine- specific protocols. The detection channel on the real-time instrument should be set to acquire at the appropriate wavelength(s). We recommend using the following cycling conditions for optimal results:

Cycling for Dual-Labeled Probes

## Cycles Temp. Time Notes

1	45°C	10 min	Reverse transcription
1	95°C	2 min	Polymerase activation
40	95°C 60°C	5s 20s	Denaturation Annealing/extension (acquire at end of step)

# Real-Time RT-PCR optimization

# Step 4.

The following optimization may be necessary to improve the efficiency of some reactions, such as multiplexing with more than two probes, or if the target amplicon is longer than 200 bp.

- The reverse transcription reaction time can be extended up to 20 minutes and/or the temperature can be increased up to 48°C
- The annealing/extension time can be extended up to 60 seconds and/or the temperature can be increased up to 65°C