

May 09, 2019

Working

U Mass - Aspartate Transferase 👄

Jason Kim¹

¹University of Massachusetts

dx.doi.org/10.17504/protocols.io.xr5fm86

Mouse Metabolic Phenotyping Centers

Tech. support email: info@mmpc.org



Lili Liang 69



Summary:

This experiment involves a spectrophotometric measurement using Roche Cobas Clinical Chemistry Analyzer. Serum levels of aspartate transferase reflect liver function.

EXTERNAL LINK

https://mmpc.org/shared/document.aspx?id=181&docType=Protocol

MATERIALS

NAME >	CATALOG #	VENDOR ~	CAS NUMBER $ imes$ RRID $ imes$
Aspartate amino- transferase (ALTL)	04657543 190	Roche	
Pyridoxal Phosphate	04774221 190	Roche	
Calibrator f.a.s.	10759350 360	Roche	
Precinorm U Plus	12149435 160	Roche	
Precipath U Plus	12149443 160	Roche	
NaCl Diluent 9%	04774230 190	Roche	
Cleaner	04774248 190	Roche	
Micro Sample cups	11406680 001	Roche	
NERL High Quality Water	9805	Fisher Scientific	

MATERIALS TEXT

Note:

Roche, RRID:SCR_001326

Fisher Scientific, RRID:SCR_008452

BEFORE STARTING

Notes:

- $\sqrt{}$ Try to use freshly prepared serum and plasma samples for this assay.
- √ No dilution or treatment of the sample is required, but plasma samples should be centrifuged to remove any fibrin/fibrinogen clumps.
- √ Samples should be stored at 2-8°C for 24 hours prior to analysis. For longer periods, store samples at -70°C, and avoid repeated freeze/thaw cycles.

Perform daily quality control assessment of instrumentation before analysis.

Load each sample into a specialized micro-sample cup for the clinical chemistry analyzer.

Select Aspartate Transferase test on display and run the analysis.

Collect and analyze the data.

This is an open access protocol distributed under the terms of the Creative Commons Attribution License, which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited

√ A 50 µl dead volume is required in addition to sample volume for multi-protein analysis (typically 1-5 µl).