



Aug 14, 2019

Biochemical Measures of Neuropathy - GSSG (Non-Enzymatic)

Eva Feldman¹

¹University of Michigan - Ann Arbor



Diabetic Complications Consortium
Tech. support email: rmcindoe@augusta.edu



ABSTRACT

Summary:

Oxidative stress is highly correlated with the metabolic changes caused by hyperglycemia. Increased levels of glucose overload mitochondria and result in the production of reactive oxygen species (ROS). In addition, the flow of excess glucose through cellular pathways decreases the cell's normal ability to detoxify ROS. As a result, the neurons and axons of the peripheral nervous system contain increased levels of ROS and decreased antioxidant capacity. The following assays are used to measure these changes in rodent models of diabetic neuropathy.

Diabetic Complication:



Neuropathy

EXTERNAL LINK

https://www.diacomp.org/shared/document.aspx?id=54&docType=Protocol

MATERIALS

NAME ~	CATALOG #	VENDOR ~
Perchloric Acid (Lot # 227044)	A469-500	Fisher Scientific
N-ethylmaleimide	34115-5GM	EMD Bioscience
KOH Potassium hydroxide		Fisher Scientific
Imidazole Base		Fisher Scientific
Potassium Chloride		
Tris		
HCL		
EDTA	16-004Y	BioWhittaker
O-phthaldialdehyde (Lot 80K25190)	P-0657	Sigma Aldrich

NAME CATALOG # VENDOR CATALOG # CATA

MATERIALS TEXT

Reagent Preparation:

3 MHClO₄ - 42 ml of 72% stock Perchloric acid into 58 ml ddH₂O

0.04M *N*- **ethylmaleimide** – 5mg in 1 mL ethanol (N- ethylmaleimide complexes with GSH (Hissin and Hilf, 1976) thus preventing interference from GSH oxidation Per Dr. Obrosova)

2NKOH, 0.4 M imidazole base, and 0.4 M KCl – 56.11 g KOH, 13.62 g Imidazole base and 14.91 g KCl. Add ddH₂O to bring up to 500 ml.

0.10.1~M imidazole-HCl buffer pH 7.6 with 20 mM EDTA – 68 mg in 50 ml ddH $_2$ O. Add 400 μ L 0.5 M EDTA and pH to 7.6 with HCl then bring volume up to 10 mL.

GSSG Standard 100mM - 61.26 mg in 1 mL ddH₂O.

0-Phthaldialdehyde - 10 mg in 1 ml of methanol.

Note:

Roche (RRID:SCR_001326)

Thermo Fisher Scientific (RRID:SCR_008452)

Sigma-Aldrich (RRID:SCR_008988)

Sample Preparation:

- 1 Prior to dissection, perfuse tissue with PBS pH7.4 with 0.16 mg/ml heparin.
 - 1. If using extract from GSH add 100 μ l 0.04 M N-ethylmaleimide to 200 μ l homogenate then skip to Performing the Assay or
 - 2. Label 3 sets 1.5 ml and 1 set of 0.6 ml micro centrifuge tubes.
 - 3. Prepare 3 MHClO₄ and freeze.
 - 4. Keeping labeled 1.5ml tubes on dry ice, add 3 volumes of 3 MHClO₄.
 - 5. Cut tissue into segments and weigh. (~10 mg)
 - 6. Place weighed segment in tube on top of HClO₄.
 - 7. Place tubes in an alcohol bath maintained at -8° to -10° C. and agitate 15 minutes or until the acid completely penetrates the tissue fragments. (Make sure the temperature does not go below -10° to completely extract the ice. (2 MHClO₄ will freeze at -12°C.)
 - 8. Add 333 μ l of ddH₂O for each 100 μ l HClO₄ and shake at 4°C for 10 min. (May include 1 mM EDTA in ddH₂O)
 - 9. Pull off 25 μ l and place in a 0.6 ml micro-centrifuge tube for protein analysis.
 - 10. Centrifuge samples at 5000 x g for 10 min at 4°.
 - 11. Transfer supernatant to a new labeled tube. Discard protein precipitate.
 - 12. Immediately neutralize with 290 µl/ml of a mixture of 2 N KOH, 0.4 Mimidazole base, and 0.4MKCl. (Leaving a solution at pH 7.)
 - 13. Centrifuge at 4000 x g for 5 min to precipitate insoluble KClO₄.

Performing the assay:

2 Prepare standards as follows: (0-1000uM)

Concentration µM/mL	H ₂ O	GSSG
0	500	NO GSSG
15.63	500	Take 500 μL from tube 3
31.25	500	Take 500 μL from tube 4
62.5	500	Take 500 μL from tube 5
125	500	Take 500 μL from tube 6
250	500	Take 500 μL from tube 7
500	500	Take 500 μL from tube 8
1000	990	10 μL 0.1M stock

- 1. On a clear 96 well plate add 40 μ l standards to each well in duplicate.
- 2. Add 40 μl sample extract to each sample well in duplicate or triplicate.
- 3. Add 160 μl imidazole-HCl buffer to each well. Add 0.2-10 μM NADPH
- 4. Begin reaction by adding 0.3 U of glutathione reductase.
- 5. Set up Fluroskan layout and area..
- 6. Read using 340 nm excitation and 460 nm emission.
- 7. Place plate into Fluroskan holder and click ${\bf START}.$
- 8. From the drop down menu under sheet select curve fit. Choose the appropriate data to organize (usually Measure1), then click **OK**. This calculates your standard curve.
- 9. Save the curve fit sheet as an Excel file into your data folder. Use the naming convention GSXXXXXX.xls, where XXXXXX is the date in yymmdd.xls.

This is an open access protocol distributed under the terms of the Creative Commons Attribution License, which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited