# Resuspension Buffer P1 Version 2

## Qiagen

## **Abstract**

This is a 0.05M Tris-Cl (pH 8.0), 0.01M EDTA resuspension buffer containing RNase A

Citation: Qiagen Resuspension Buffer P1. protocols.io

dx.doi.org/10.17504/protocols.io.hxgb7jw

Published: 11 May 2017

## **Guidelines**

Storage condition - 4°C after adding RNase A.

**Note**: Buffer compositions are given per liter of solution. Buffer calculations are based on Tris Base adjusted to pH 8.0 with HCl (Tris-Cl). Not recommended to be made with Tris-HCl due to acidity of solution (EDTA-Na<sub>2</sub>-2H<sub>2</sub>O needs a pH above 8.0 to dissolve), but if Tris-HCl is used, amount should be adjusted for correct molarity (0.05M) and NaOH should be used to bring pH up to 8.0. This buffer may be autoclaved prior to addition of RNase A or it may be 0.2  $\mu$ m filter-sterilized.

## **Protocol**

#### Step 1.

Dissolve 6.06g Tris Base in 800 mL MilliQ water

■ AMOUNT

6 g Additional info:



Tris Base <u>BP152-1</u> by <u>Fisher Scientific</u>

#### NOTES

#### Bonnie Poulos 11 May 2017

It can be made either way depending on what you have available in the lab. Some find it easier to use stock solutions, but it is not necessary as long as final pH is adjusted.

#### **ANNOTATIONS**

Chris Upton 11 May 2017

Isn't this usually made from stock Tris and EDTA solutions?

# Step 2.

Add 3.72g EDTA disodium salt, dihydrate to the 800 mL Tris base and stir to dissolve

AMOUNT

4 g Additional info:



EDTA, disodium salt, dihydrate S312-500 by Fisher Scientific

## Step 3.

Adjust the pH to 8.0 with HCl

# Step 4.

Adjust the volume to 1 liter with MilliQ water

#### Step 5.

Add 100mg RNase A per liter of buffer P1



100 mg Additional info: