



NanoAmpli-Seq - Sample processing and sequencing library preparation workflow 👄

Szymon T Calus¹, Umer Zeeshan Ijaz¹, Ameet Pinto²

¹University of Glasgow, ²Northeastern University

dx.doi.org/10.17504/protocols.io.u26eyhe

Pinto Lab



ABSTRACT

TAGS

sequencing

amplicon

Show tags

EXTERNAL LINK

https://www.biorxiv.org/content/early/2018/01/07/244517

PROTOCOLSTATUS

Working

We use this protocol in our group and it is working very well.

GUIDELINES

 $Workflow\ was\ designed\ and\ optimised\ for\ sample\ preparation\ of\ 16S\ rRNA\ gene\ amplicons\ with\ the\ use\ of\ random\ hexamer-free\ Rolling\ Circle\ Amplification\ followed\ by\ MinION\ MK1b\ sequencing.$

However, this protocol can be customised for amplification of any prokaryotic and eukaryotic gene from \sim 200 to \sim 2000bp.

MATERIALS

NAME ×	CATALOG #	VENDOR ~
T7 Endonuclease I- 250 units	M0302S	New England Biolabs
Blunt/TA Ligase Master Mix - 50 rxns	M0367S	New England Biolabs
NEBNext FFPE DNA Repair Mix - 24 rxns	M6630S	New England Biolabs
Magnetic stand for micrcentrifuge tubes	12321D	Life Technologies
ethanol		
NEBNext Ultra II Q5 Master Mix - 50 rxns	M0544S	New England Biolabs
NEBNext End repair / dA-tailing Module (E7546)		
Corning® Filtered Pipette Tips, 1000 µL 1000 Tips	38031	Stemcell Technologies
Corning® Filtered Pipette Tips, 200 µL 960 Tips	38032	Stemcell Technologies
Corning® Filtered Pipette Tips, 10 µL 960 Tips	38034	Stemcell Technologies
Qubit dsDNA HS Assay Kit	Q32851	Thermo Fisher Scientific

NAME ~	CATALOG #	VENDOR ~
DNA Lo Bind Tubes	#022431021	Eppendorf
PCR tubes, strips or plates		
HighPrep™ PCR	AC-60050	
Plasmid-SafeTM ATP-Dependent DNAse	E3101K	Epicentre
Sygnis TruePrime™ RCA Kit	SYG390100	Lucigen
g-TUBE	520079	Covaris
1D ² Sequencing Kit	SQK-LSK308	
Flow Cell R9.5	View	
Molecular Grade Water	60-2450	ATCC

MATERIALS TEXT

Equipment required:

- 1. PCR thermocycler from any vendor
- 2. PCR cabinet/hood with UV sterilization
- 3. Thermal mixer with appropriate blocks from any vendor
- 4. Pipettes with varying volumes range from any vendor
- 5. Centrifuge for 2 ml and 0.2 ml tubes from any vendor
- 6. $MinION^{TM}$ MK1b device and compatible personal computer

Primers for PCR amplification of 16S rRNA gene can be ordered from any provider.

SAFETY WARNINGS


BEFORE STARTING

Make sure you have all necessary equipment, reagents and PCR primers before begining the protocol.

For preparation of multiple samples please, use 'START EXPERIMENT' then 'SCALE PROTOCOL'.


PCR amplification of 16S rRNA gene

1 Master Mix - combine the following reagents using volumes below:



Aliquot $24\,\mu l$ of Master Mix reagents in 0.2ml PCR tubes then add $1\,\mu l$ of DNA to each tube. Final volume: $25\,\mu l$ of reagents in 0.2ml PCR tubes.

Incubate the reaction at the thermocycler according to the following conditions:



This PCR assay requires 20 cycles of Denaturation, Annealing and Extention.

During the PCR assay running go to Step 2 (prepare 70% ethanol) then to Step 3 (prepare Qubit reagents). Finally remove tubes from PCR machine and continue with Step 2.

NOTE

Amplification of samples can be performed in duplicates or triplicates as use of replicates will help reduce PCR biases.

Make sure both primers are 5' PHO positive. If protocol is used for the first time or was modified to amplify different gene/s than 16S rRNA, we recommend verifying the results of the PCR assay. To confirm the correct size of the amplicons, we advise using standard agarose gel or automated capillary electrophoresis.

PCR product clean up

Prepare 5-10ml of 70% ethanol depending on the number of samples, e.g. 3.5ml of 100% ethanol with 1.5ml of Molecular Grade Water and keep it on ice.

Combine replicates (3x20µl) into single 2ml tube, then add 30µl of magnetic beads (0.5x ratio) to the 60µl of PCR product and incubate for © 00:02:00 min at room temp. The place tube in the magnetic rack, allow beads to set then discard the liquid. Subsequently, wash the pellet twice with 200µl of freshly prepared ice-cold 70% ethanol. Discard the ethanol and briefly centrifuge the tube at low speed, place the tube back on the magnetic rack, remove residuals of the ethanol and place the tube at the heat block for around © 00:00:10 sec at 50°C. Be careful not to overdry the beads. Use 20µl Molecular Grade Water kept at the heat block § 50 °C to resuspend the beads, incubate the tube for © 00:02:00 min at room temp. Then place the tube back on the rack, allow beads to set and transfer the 20µl PCR product into a fresh 2ml tube.

NOTE

To expand the lifespan of HighPrep $^{\text{TM}}$ reagents and reduce the chance of contaminating 50ml stock reagents, we recommend to aliquot the beads in 2ml tubes, e.g. 1500 μ l. That will decrease a need for moving the stock reagents from the fridge every time a small volume of magnetic beads is used and reduce a time needed for the reagents to reach room temperature.

PCR product concentration estimation

3 Prepare Qubit™ dsDNA HS reagents and related standards, according to the vendor instructions (1). i.e., 199µl dsDNA HS Buffer with 1µl dsDNA HS Reagent e.g., 995µl dsDNA HS Buffer and 5µl dsDNA HS Reagent for 5 reactions

To determine the concentration of cleaned amplicons combine:

1μl of PCR product with 199μl Qubit reagents.

EXPECTED RESULT

The concentration of samples should be \sim 50ng in a total (depending on assay efficiency) of cleaned amplicons per sample.

1) https://assets.thermofisher.com/TFS-Assets/LSG/manuals/Qubit_dsDNA_HS_Assay_UG.pdf

Self-ligation for the formation of plasmid-like structure

4 If multiple amplicon pools are being used, normalized their concentration to 2ng/μl and transfer 45μl of each sample to new **0.2ml**PCR grade tube. Then add 5μl of Blunt/TA Ligase Master Mix to the **0.2ml** PCR containing purified amplicons. Gently mix the reagents by pipetting up and down and incubate the tube for **(30:15:00 min at 10°C)** and

© 00:10:00 min at 25°C in a PCR thermocycler (make sure lid heating is turned off).

Initate Step 5 while the ligation reaction is ongoing in the thermocycler.

Reverse phase cleanup

Vortex HighPrep™ reagents and transfer 150µl of magnetic beads into a clean 2ml tube. Place the tube on a magnetic rack for ○00:02:00 min or until beads separate from the liquid. While the tube is on the magnetic rack, remove 90µl of clear buffer without disturbing the beads and place it inside the lid of the 2ml tube. Then discard remaining 60µl of the buffer without disturbing the beads. Subsequently, transfer exactly 75µl of clear buffer (concentrate beads by 50%) from the lid into the tube and discard the remaining wastes from the tube's lid. Remove the tube from magnetic rack and gently vortex to resuspend the beads. Keep 50% concentrated beads at room temperature until needed.

Add precisely $17.5\mu l$ concentrated beads (0.35x ratio) to $50\mu l$ of a self-ligation mix from Step 4. Gently mix the tube by pipetting up and down then, incubate the mixture for 00:02:00 min at room temp. Place the tube on a magnetic rack and allow the beads to separate. The beads will bind to long linear amplicons (i.e., chimeric amplicons) while the liquid contains short linear amplicon and plasmid-like structures. Finally, transfer $67.5\mu l$ of clear liquid to the new 2m l tube.

Remaining 57.5µl of concentrated beads will be used at Step 11 and 13 until that time keep the beads at room temp.

NOTE

Concentration of beads by 50% described for Step 5 has to be done every time reaction is performed. We do not recommend preparing a high volume of concentrated beads and storing them. Magnetic beads stored at high-concentration (i.e. -50%) for a long time clump and lose their efficiency.

ASAFETY INFORMATION

This approach of concentrating magnetic beads was optimised to remove long DNA structures i.e. >2000bp. However, the beads need to be prepared fresh and mixed with an **exact volume of PCR products**. That is why we recommend **using a pipette wheel** to measure the volume of liquids and **recalculate the number of reagents** added to the tube when necessary. This approach of concentrating beads is an improved version of (Additional file 6) https://doi.org/10.1186/1471-2164-15-645

Plasmid and short amplicon clean-up

Add 33.75µl of magnetic beads (0.5x ratio) to 67.5µl of clear liquid from Step 5, gently vortex and incubate the tube for © 00:02:00 min at room temp. Place the tube on the magnetic rack and allow beads to set, discard the liquid.

Subsequently, wash the pellet twice with 200µl of freshly prepared ice-cold 70% ethanol. Discard the ethanol and briefly centrifuge the tube at low speed, place tube back in the magnetic rack, remove residuals of the ethanol and place the tube at the heat block for around © 00:00:10 sec at 50°C. Remember to do not overdry the beads. Use 15µl of Molecular Grade

Water kept at the heat block & 50°C to resuspend the beads, incubate the tube for © 00:02:00 min at room temp

Then place the tube back on the rack, allow beads to set and transfer the 15µl of PCR product into a fresh 2ml tube.

Removal of linear molecules from plasmid mix

7 Combine the following reagents using volumes below:

15µl of self-ligated and purified amplicons 2µl of Molecular Grade Water 2µl of 25mM ATP 5µl of 10x Reaction Buffer 1µl of Plasmid-Safe DNase (10U) Total volume: 25µl of reagents in 0.2ml PCR grade tube.

For mini-preparation, incubate the reaction in a thermocycler according to the following conditions:

```
§ 37 °C Incubation © 00:15:00 min
```

After incubation, clean the products as described in Step 6 (elute in 10µl of Molecular Grade Water) and determine the concentration of DNA in the cleaned product as described in Step 3.

NOTE

Do not deactivate the Plasmid-safe DNase enzyme with 30min incubation at 70°C as recommended in the protocol. This process would take additional 30min. The subsequent magnetic bead cleanup will remove ATP, Reaction Buffer, nucleotide debris and active DNase enzyme.

Reagent volumes are followed according to a mini-preparation protocol (2), for higher volumes, please check Lucigen and Epicentre instructions.

2) https://www.lucigen.com/docs/manuals/MA044E-PlasmidSafe-DNase.pdf

Rolling Circle Amplification (RCA)

Perform RCA in triplicate for each pooled sample and include negative controls using **Molecular Grade Water** instead of cleaned product from Step 7. All reagents are included in the TruePrime ™ RCA kit and should be kept on ice unless specified otherwise.

#1 Below are conditions and volumes for a 1 and 5 RCA reactions:

Combine 3µl of cleaned product from Step 7 with 2.5µl of Buffer D (provided with TruePrime ™ RCA kit) in 0.2ml PCR grade tube. Pipette up and down to mix and incubate at room temperature for 3-5 minutes.

#2 While the sample is being incubated, prepare the amplification mix and keep on ice until needed.

```
1 sample 5 samples
                              Reagents
             9.3µl
                        46.5µl of Molecular Grade Water
             2.5µl
                        12.5µl of Reaction buffer
             2.5µl
                        12.5µl
                                of dNTPs
             2.5ul
                        12.5µl
                                  of Enzyme 1
             0.7µl
                         3.5µl
                                  of Enzyme 2
Total volume: 17.5µl
                     87.5µl of Amplification Mix
```

#3 After 3-5 minutes, add 2.5µl of Buffer N to 5µl of incubated sample #1 and pipette up and down to mix.

Finally, add 17.5µl of amplification mix #2 to the 7.5µl of DNA mix #3, pipette up and down to homogenise the reaction then incubate the 0.2ml PCR grade tube at 29.5°C on a heat block or thermocycler for 120-150 minutes - depending on assay efficiency.

After **90min**, the efficiency of the assay can be tested according to Step 3. If RCA resulted in appropriate concentration of amplification product, then the amplification mix can be followed by enzymatic fragmentation (Step 9). However, if the concentration of the RCA products is lanow, then reagents c incubated for another **30-60min** and quantified according to Step 3.

Incubation time takes around 2 hours. Take a break!

■NOTE

Reagent volumes are used according to TruePrime $^{\text{TM}}$ RCA kit (3). An increase of incubation temperature will boost the efficiency of phi29 polymerase, however, that in turn will trigger an increase of unspecific product formation in the negative controls. Higher incubation temperatures (i.e. 32-36°C) may be investigated to reduce incubation time (by 40-60%) and shorten overall workflow. However, we recommend to perform reaction at ~29.5°C that makes the RCA protocol slightly longer (120-150min) but more reliable as negative control sample will have no unwanted amplification.

3) https://p2v6h7b4.stackpathcdn.com/wp-content/uploads/2018/01/TruePrime%E2%84%A2-RCA-Kit.pdf

⊠EXPECT ED RESULT

After 120-150min, the concentration of samples should be \sim 30-40ng/µl that in turn gives: 25μ l x triplicate x 30-50ng = 2250-3000ng in total and is sufficient for subsequent steps.

 $The \ bare\ minimum\ concentration\ of\ RCA\ product\ at\ this\ step\ is\ 2000ng\ before\ fragmentation.$

** If the protocol is used for the first time or was modified to amplify different gene/s than 16S rRNA, we recommend verifying the results of the RCA assay. To confirm correct assay efficiency, we advise using standard agarose gel or automated capillary electrophoresis.

First step enzymatic de-branching

9 Combine all three 21 μl RCA replicates from Step 8 into a single 0.2ml PCR grade tube. Mix 63 μl of RCA product with 2 μl of T7 endonuclease I and mix with use of wide bore tips then incubate for 00:05:00 min at room temp.

Mechanical fragmentation

Transfer 65 µl of RCA product into a g-TUBE using wide bore pipette tips. Centrifuge the tube for

© 00:03:00 min at 1800 rpm or until the entire reaction mix passes through the fragmentation hole. Reverse the g-TUBE and centrifuge it for © 00:03:00 min at 1800 rpm or until the entire reaction mix passes through the fragmentation hole.

Cleanup of fragmented RCA products

11 The 57.5µl of concentrated beads from Step 5 is used for the cleanup of RCA fragmented products.

Gently vortex the concentrated beads (-50%) and add exactly 22.75µl of concentrated beads (0.35x ratio) to 65µl of RCA fragmented products (or recalculate the volume of concentrated beads if necessary). Mix the tube by pipetting up and down then, incubate the mixture for © 00:02:00 min at room temp. Subsequently, place the tube on a magnetic rack and allow the beads to separate. The beads contain long linear, concatemerized amplicons while the liquid contains short (<2000bp) fragments. Subsequently, wash the pellet twice with 200µl of freshly prepared ice-cold 70% ethanol. Discard the ethanol and briefly centrifuge the tube at low speed, place back the tube at the magnetic rack, remove residuals of the ethanol and place the tube at the heat block for around © 00:00:10 sec at 50°C. Remember to do not overdry the beads. Use 65µl of

Molecular Grade Water kept at the heat block & 50 °C to resuspend the beads, incubate the tube for

© 00:02:00 min at room temp. Then place the tube back on the rack, allow beads to set and transfer the 63µl of RCA product into a fresh 2ml tube. Remaining 2µl of RCA product can be used for Qubit dsDNA HS assay.

Remaining 34.75µl of concentrated beads will be used at Step 13 until that time keep the beads at room temp.

Secondary enzymatic de-branching

12 Mix 63μl of fragmented RCA products with 2μl of T7 endonuclease I and incubate for © 00:05:00 min at 37°C.

Cleanup of post fragmented RCA products

13 The 34.75µl of concentrated beads from Step 11 is used for cleanup of RCA fragmented products at this stage.

Add precisely 29.25µl of concentrated beads (0.45x ratio) to 65µl of RCA fragmented products (or recalculate the volume of concentrated beads if necessary). Gently mix the tube by pipetting up and down then, incubate the mixture for © 00:02:00 min at room temp. Then, place the tube on a magnetic rack and allow the beads to separate. The beads contain long linear, concatemerized amplicons while the liquid contains short fragments. Subsequently, wash the pellet twice with 200µl of freshly prepared ice-cold 70% ethanol. Discard the ethanol and briefly centrifuge the tube at low speed, place the tube back on the magnetic rack, remove residuals of the ethanol and place the tube at the heat block for sround © 00:00:10 sec at 50°C. Remember to do not overdry the beads. Use 55µl of Molecular Grade Water kept at the

heat block § 50 °C to resuspend the beads, incubate the tube for © 00:02:00 min at room temp. Then place the tube back on the rack, allow beads to set and transfer the 53µl RCA product into a fresh 0.2ml PCR grade tube. Remaining 2µl of RCA product can be used for Qubit dsDNA HS assay or verification of size fragments**.

NOTE

** If the protocol is used for the first time or was modified to amplify different gene/s than 16S rRNA, we recommend verifying the results of the PCR assay. To confirm the correct size of the amplicons, we advise using standard agarose gel or automated capillary electrophoresis.

Gap-filling and dA-tailing of fragmented RCA products

14 Combine the following reagents using volumes below:

53ul of RCA product

3.5µl of FFPE DNA Repair Buffer

 $3.5\mu I$ of NEBNext Ultra II End Prep Buffer

2μI of NEBNext FFPE DNA Repair Mix

3μl of Ultra II End Prep enzyme mix

Total volume: 65µl in 0.2ml PCR grade tube.

Mix the reaction mix by pipetting gently up and down (10-times) using wide bore tips then incubate the reaction at the thermocycler according to the following conditions:

```
8 20 °C © 00:10:00 min

8 65 °C © 00:10:00 min

8 4 °C © 00:00:00 Hold
```

NOTE

Reagent volumes are followed according to NEBNext® FFPE DNA Repair Mix https://www.neb.com/-/media/catalog/datacards-or-manuals/manualm6630.pdf - page 5

Cleanup of end-repaired and dA-tailed RCA products

Add 32.5µl of magnetic beads (0.5x ratio) to 65µl of RCA product from Step 14, gently vortex and incubate the tube for © 00:02:00 min at room temp. After that time place tube on the magnetic rack and allow beads to set, discard the liquid.

Subsequently, wash the pellet twice with 200µl of freshly prepared ice-cold 70% ethanol. Discard the ethanol and briefly centrifuge the tube at low speed, place back the tube at the magnetic rack, remove residuals of the ethanol and place the tube at the

heat block for around © 00:00:10 sec at 50°C. Remember to do not overdry the beads. Use 35µl of Molecular Grade

Water kept at the heat block & 50°C to resuspend the beads, incubate the tube for © 00:02:00 min at room temp

Then place the tube back on the rack, allow beads to set and transfer the 33µl of RCA product into a fresh 2ml tube.

Follow Step 3 to determine the concentration of DNA in samples and negative controls.

Library preparation and nanopore sequencing (Fig.11)

16 Prepare 1D² libraries for nanopore sequencing with SQK-LSK308 kit by Oxford Nanopore Technologies (4).

Combine the following reagents using volumes below:

33µl of ~500ng RCA products from Step 15

2.5µl of 1D² Adapter

14.5µl of Blunt/TA Ligase Master Mix

Total volume: 50µl in a 2ml tube

Homogenise the reagents by pipetting gently up and down (10-times) using wide bore tips then incubate for

© 00:10:00 min at room temp . Then add 24μl of magnetic beads (0.4x ratio) and incubate it for

Subsequently, place the tube on the magnetic rack and allow beads to set, discard the liquid. Wash the pellet twice with 200µl of freshly prepared ice-cold 70% ethanol. Discard the ethanol and briefly centrifuge the tube at low speed, place back the tube at the magnetic rack, remove residuals of the ethanol and place the tube at the heat block for ©00:00:10 sec at 50°C. Use 46µl of Molecular Grade Water kept at the heat block § 50 °C to resuspend the beads, incubate the tube for ©00:02:00 min at room temp. Then place the tube back on the rack, allow beads to set and transfer the 45µl of RCA product into a fresh2ml tube.

Combine the following reagents using volumes below:

45μl of 1D² adapted DNA 5μl of Barcode Adapter Mix (BAM) 50μl of Blunt/TA ligase

Total volume: 100µl in a 2ml tube

Homogenise the reagents by pipetting gently up and down (10-times) using wide bore tips then incubate for

. After that time add 40μl of magnetic beads (0.4x ratio) and incubate it for © 00:02:00 min at room temp . Subsequently, place the tube on the magnetic rack and allow beads to set, discard the liquid. Wash the pellet twice with 140μl of ABB buffer. Discard the ABB buffer and briefly centrifuge the tube at low speed, place the tube back in the magnetic rack, remove residuals of the ABB buffer. Use 15μl of Elution Buffer kept at the room temperature to resuspend the beads, incubate the tube for © 00:02:00 min at room temp. Then place the tube back on the rack, allow beads to set and transfer the 15μl of Elution Buffer into a fresh 2ml tube.

EXPECTED RESULT

Eluted $1D^2$ libraries can be quantified with the use of Qubit reagents according to Step 3. Expected concentration should be around 8-10ng/µl or 120-150ng in total.

Prime **R9.5 nanopore flow cell** (suitable for 1D² libraries) using protocols outlined by Oxford Nanopore Technologies (4). Load the libraries on the device and initiate 48h sequencing process.

■NOTE

Some of the reagent volumes at Step 16 have been modified when compared to $1D^2$ genomic protocol. 4) https://community.nanoporetech.com/protocols/1d%5E2-genomic-sequencing/v/lsd_9032_v11_revo_23mar2017/checklist-protocol

This is an open access protocol distributed under the terms of the Creative Commons Attribution License, which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited