	Rack01.Front		Rack01.Rear
U15	Spare	U15	
U14	Spare	U14	
U13	ISP NTE - Demarc Point	U13	ISP NTE - Demarc Point
U12	24 Port Patch Panel	U12	
U11	Cable MGMT Bar	U11	
U10	SW1 - Cisco 2960	U10	SW1 - Cisco 2960
U9	Spare	U9	
U8	Spare	U8	
U7	Spare	U7	
U6		U6	
U5	R1 - Cisco 2911	U5	R1 - Cisco 2911
U4	NVR1	U4	NVR1
U3	UPS	U3	UPS
U2	PDU 8-Way	U2	PDU 8-Way
U1	Power Cabling Routing	U1	Power Cabling Routing

Colour Code Key	
	Cabling Infra
	Power
	ISP
	Routing
	Switching
	Security

Cabling Notes

1. Cabinet - 15U double-section wall cabinet, 600 mm deep, fixed to a solid wall.

2. Segregation
- Fibre runs down the left-hand side only.
- Copper runs down the right-hand side only.
- Power runs at the rear of the rack only, kept away from data cabling to reduce EMI

3. Cable Entry - All horizontal copper enters through the top of the cabinet, runs straight down the right-hand side with a clean, gentle sweep, and is terminated on the rear of the U12 patch panel.

4. Patch Panel - The front of the U12 patch panel carries patch leads only.

5. Patching - Patch leads run from the patch panel through the U11 cable management bar into SW1 (U10)

6. Power - The mains feed enters through the top of the cabinet at the rear and runs down the rear to the UPS (U3), which feeds the 8-way PDU (U2). All device power cables are routed down through U1 and back up the rear of the rack to each device, kept clear of fibre and copper to avoid EMI.

7. Slack - No more than 1 ft (300 mm) of slack per cable where possible. Any slack must be neatly dressed.

8. Dressing - Velcro is fitted every 1 ft (300 mm), with strictly no use of cable ties.

8. Dressing - Velcro is fitted every 1 ft (300 mm), with strictly no use of cable ties.

9. Bend Radius - All cables follow a gentle curve, with no sharp bends or kinks.

10. Labelling - Each cable has a unique ID prefixed by media type: C = Copper, M = Multimode, S = Singlemode (e.g. C0001). The same ID is on both ends, positioned at the same distance from the connector on every cable.

11. Spare U's - U15, U14 and U9–U7 are reserved for future expansion and fitted with blanking panels. U1 is used for power cable routing.

12. Load - The cabinet's load rating has been checked to support the UPS and NVR.

13. Testing - All copper links are tested and certified with a Fluke DSX-5000, correctly set up for the project. Results are saved against each cable ID.

14. Fibre Handling - Fibre connectors are cleaned and inspected before connecting, and dust caps are fitted to unused ports.

15. Earthing - The cabinet is bonded to the building earth.